



TOTAL ACCESS 850 System Manual

1200375L1	Total Access 850 Chassis
1200373L1	T1 Bank Controller Unit (BCU)
1200373L2	T1 BCU with DSX Port
4203376L1#TDM	T1 Router Control Unit (RCU) with TDM Software
4203376L1#ATM	T1 RCU with ATM Software
1203376L1	3rd Generation T1 RCU
1200377L1	SDSL RCU
1200377L2	2nd Generation SDSL RCU
1203384L2	Echo Canceller with ADPCM
1175006L2	Power Supply Unit
1175043L3	AC Supply/Battery Charger

Trademarks

Any brand names and product names included in this manual are trademarks, registered trademarks, or trade names of their respective holders.

Total Access® is a registered trademark of ADTRAN, Inc.

To the Holder of the Manual

The contents of this manual are current as of the date of publication. ADTRAN reserves the right to change the contents without prior notice.

In no event will ADTRAN be liable for any special, incidental, or consequential damages or for commercial losses even if ADTRAN has been advised thereof as a result of issue of this publication.

About this Manual

This manual provides a complete description of the Total Access 850 system and system software. The purpose of this manual is to provide the technician, system administrator, and manager with general and specific information related to the planning, installation, operation, and maintenance of the Total Access 850. This manual is arranged so that needed information can be quickly and easily found.



901 Explorer Boulevard
P.O. Box 140000
Huntsville, AL 35814-4000
Phone: (256) 963-8000

© 2005 ADTRAN, Inc.
All Rights Reserved.
Printed in U.S.A.

Revision History

Document Revision	Date	Description of Changes
A	April 2004	This is the first issue of this manual. The previous version of this product was covered under document 64200376L1-1.
B	August 2004	Update licensing and warranty agreement; correct third generation part numbers.
C	August 2005	Delete PLAR option for FXS card. (PLAR is provided through E&M immediate mode.)

Conventions



Notes provide additional useful information.



Cautions signify information that could prevent service interruption or damage to the equipment.



Warnings provide information that could prevent endangerment to human life.

Safety Instructions

When using your telephone equipment, please follow these basic safety precautions to reduce the risk of fire, electrical shock, or personal injury:

1. Do not use this product near water, such as a bathtub, wash bowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.
2. Avoid using a telephone (other than a cordless-type) during an electrical storm. There is a remote risk of shock from lightning.
3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord, power supply, and/or batteries indicated in the manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for special disposal instructions.

Save These Important Safety Instructions

FCC-Required Information

FCC regulations require that the following information be provided in this manual:

1. This equipment complies with Part 68 of the FCC rules and requirements adopted by ACTA. On the equipment housing is a label showing the FCC registration number and ringer equivalence number (REN). If requested, provide this information to the telephone company.
2. If this equipment causes harm to the telephone network, the telephone company may temporarily discontinue your service. If possible, advance notification is given; otherwise, notification is given as soon as possible. The telephone company will advise the customer of the right to file a complaint with the FCC.
3. The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the proper operation of this equipment. Advance notification and the opportunity to maintain uninterrupted service are given.
4. If experiencing difficulty with this equipment, please contact ADTRAN for repair and warranty information. The telephone company may require this equipment to be disconnected from the network until the problem is corrected or it is certain the equipment is not malfunctioning.
5. This unit contains no user-serviceable parts.
6. An FCC compliant telephone cord with a modular plug is provided with this equipment. This equipment is designed to be connected to the telephone network or premises wiring using an FCC compatible modular jack, which is compliant with Part 68 and requirements adopted by ACTA.
7. The following information may be required when applying to your local telephone company for leased line facilities.

Part Number	Registration Number	Service Type	REN/SOC	FIC	USOC
1200373L2	HDCUSA35154DEN	1.544 Mbps - SF 1.544 Mbps - SF and B8ZS	6.0N	04DU9-BN 04DU9-DN	RJ-48C
1203376L1		1.544 Mbps - ESF 1.544 Mbps - ESF and B8ZS		04DU9-1KN 04DU9-1SN	
1175407L2	HDCUSA35118CNN	Analog Loop Start/Ground Start	2.9A	02LS2	RJ-21X
1175408L2	HDCUSA35102CNN				

8. The REN is used to determine the quantity of devices you may connect to your telephone line and still have all of those devices ring when your number is called. Excessive RENs on the telephone line may result in the devices not ringing in response to an incoming call. In most, but not all areas, the sum of RENs of all devices should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company.
9. This equipment may not be used on coin service provided by the telephone company. Connection to party lines is subject to state tariffs. Contact your state public utility commission or corporation commission for information.

Federal Communications Commission Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio frequencies. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



Shielded cables must be used with this unit to ensure compliance with Class A FCC limits.



Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Affidavit Requirements for Connection to Digital Services

- An affidavit is required to be given to the telephone company whenever digital terminal equipment without encoded analog content and billing protection is used to transmit digital signals containing encoded analog content which are intended for eventual conversion into voice band analog signal and transmitted on the network.
- The affidavit shall affirm that either no encoded analog content or billing information is being transmitted or that the output of the device meets Part 68 encoded analog content or billing protection specifications.
- End user/customer will be responsible to file an affidavit with the local exchange carrier when connecting unprotected CPE to a 1.544 Mbps or subrate digital service.
- Until such time as subrate digital terminal equipment is registered for voice applications, the affidavit requirements for subrate services are waived.

**AFFIDAVIT FOR CONNECTION OF CUSTOMER PREMISES EQUIPMENT
TO 1.544 MBPS AND/OR SUBRATE DIGITAL SERVICES**

For the work to be performed in the certified territory of _____ (telco name)

State of _____

County of _____

I, _____ (name), _____ (business address),
_____ (telephone number) being duly sworn, state:

I have responsibility for the operation and maintenance of the terminal equipment to be connected to 1.544 Mbps and/or _____ subrate digital services. The terminal equipment to be connected complies with Part 68 of the FCC rules except for the encoded analog content and billing protection specifications. With respect to encoded analog content and billing protection:

I attest that all operations associated with the establishment, maintenance, and adjustment of the digital CPE with respect to analog content and encoded billing protection information continuously complies with Part 68 of the FCC Rules and Regulations.

The digital CPE does not transmit digital signals containing encoded analog content or billing information which is intended to be decoded within the telecommunications network.

The encoded analog content and billing protection is factory set and is not under the control of the customer.

I attest that the operator(s)/maintainer(s) of the digital CPE responsible for the establishment, maintenance, and adjustment of the encoded analog content and billing information has (have) been trained to perform these functions by successfully having completed one of the following (check appropriate blocks):

A. A training course provided by the manufacturer/grantee of the equipment used to encode analog signals;
or

B. A training course provided by the customer or authorized representative, using training materials and instructions provided by the manufacturer/grantee of the equipment used to encode analog signals; or

C. An independent training course (e.g., trade school or technical institution) recognized by the manufacturer/grantee of the equipment used to encode analog signals; or

D. In lieu of the preceding training requirements, the operator(s)/maintainer(s) is (are) under the control of a supervisor trained in accordance with _____ (circle one) above.

I agree to provide _____ (telco's name) with proper documentation to demonstrate compliance with the information as provided in the preceding paragraph, if so requested.

_____ Signature

_____ Title

_____ Date

Transcribed and sworn to before me

This _____ day of _____, _____

Notary Public

My commission expires:

Industry Canada Compliance Information



The Industry Canada Certification label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational, and safety requirements. The Department of Commerce does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic waterpipe system, if present, are connected together. This precaution may be particularly important in rural areas.



Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or an electrician, as appropriate.

The Load Number (LN) assigned to each terminal device denotes the percentage of the total load to be connected to a telephone loop which is used by the device, to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the equipment that the total of the LNs of all devices does not exceed 100.

The ringer equivalence number (REN) assigned to each terminal adapter is used to determine the total number of devices that may be connected to each circuit. The sum of the RENs from all devices in the circuit should not exceed a total of 5.0.

Canadian Emissions Requirements

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus," ICES-003 of the Department of Communications.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Class A prescrites dans la norme sur le matériel brouilleur: "Appareils Numériques," NMB-003 édictée par le ministre des Communications.

Product Warranty

ADTRAN will repair and return this product within the warranty period if it does not meet its published specifications or fails while in service. Warranty information can be found at www.adtran.com/warranty.

Software Licensing Agreement

Each ADTRAN product contains a single license for ADTRAN supplied software. Pursuant to the Licensing Agreement, you may: (a) use the software on the *purchased* ADTRAN device only and (b) keep a copy of the software for backup purposes. This Agreement covers all software installed on the system as well as any software available on the ADTRAN website. In addition, certain ADTRAN systems may contain specific conditions for obtaining software upgrades. The full ADTRAN Software Licensing Agreement can be found at www.adtran.com/licensing.

Product Registration

Registering your product helps ensure complete customer satisfaction. Please take time to register your products online at www.adtran.com. Click *Service and Support* on the top of the page, and then click *Product Registration* under *Support*.

Customer Service, Product Support Information, and Training

ADTRAN will replace or repair this product within the warranty period if it does not meet its published specifications or fails while in service. Warranty information can be found at www.adtran.com/warranty.

A return material authorization (RMA) is required prior to returning equipment to ADTRAN. For service, RMA requests, training, or more information, use the contact information given below.

Repair and Return

If you determine that a repair is needed, please contact our Customer and Product Service (CAPS) department to have an RMA number issued. CAPS should also be contacted to obtain information regarding equipment currently in house or possible fees associated with repair.

CaPS Department (256) 963-8722

Identify the RMA number clearly on the package (below address), and return to the following address:

ADTRAN Customer and Product Service
901 Explorer Blvd. (East Tower)
Huntsville, Alabama 35806

RMA # _____

Pre-Sales Inquiries and Applications Support

Your reseller should serve as the first point of contact for support. If additional pre-sales support is needed, the ADTRAN Support web site provides a variety of support services such as a searchable knowledge base, latest product documentation, application briefs, case studies, and a link to submit a question to an Applications Engineer. All of this, and more, is available at:

<http://support.adtran.com>

When needed, further pre-sales assistance is available by calling our Applications Engineering Department.

Applications Engineering (800) 615-1176

Post-Sale Support

Your reseller should serve as the first point of contact for support. If additional support is needed, the ADTRAN Support web site provides a variety of support services such as a searchable knowledge base, updated firmware releases, latest product documentation, service request ticket generation and trouble-shooting tools. All of this, and more, is available at:

<http://support.adtran.com>

When needed, further post-sales assistance is available by calling our Technical Support Center. Please have your unit serial number available when you call.

Technical Support (888) 4ADTRAN

Installation and Maintenance Support

The ADTRAN Custom Extended Services (ACES) program offers multiple types and levels of installation and maintenance services which allow you to choose the kind of assistance you need. This support is available at:

<http://www.adtran.com/aces>

For questions, call the ACES Help Desk.

ACES Help Desk (888) 874-ACES (2237)

Training

The Enterprise Network (EN) Technical Training Department offers training on our most popular products. These courses include overviews on product features and functions while covering applications of ADTRAN's product lines. ADTRAN provides a variety of training options, including customized training and courses taught at our facilities or at your site. For more information about training, please contact your Territory Manager or the Enterprise Training Coordinator.

Training Phone (800) 615-1176, ext. 7500

Training Fax (256) 963-6700

Training Email training@adtran.com

Table of Contents

Section 1	System Description	15
	This section provides an overview of the Total Access 850 system.	
Section 2	Engineering Guidelines	23
	This section provides equipment dimensions, power requirements, front panel design, rear panel design, LEDs, and at-a-glance specifications.	
Section 3	Network Turnup Procedure	55
	This section provides shipment contents list, grounding instructions, mounting options, and specifics of supplying power to the unit.	
Section 4	User Interface Guide	65
	This section provides detailed descriptions of all menu options and configuration parameters available for the Total Access 850 when used with a Router Control Unit (RCU). This section does not apply to systems that employ a Bank Control Unit (BCU). This section of ADTRAN's Total Access 850 System Manual is designed for use by network administrators and others who will configure and provision the system. It contains information about navigating the VT100 user interface, configuration information, and menu descriptions.	
Section 5	Detail Level Procedures	213
	DLP-1	Connecting a VT100 Terminal or PC to the CRAFT Port 215
	DLP-2	Logging in to the System 217
	DLP-3	Setting IP Parameters for the Total Access 850 219
	DLP-4	Verifying Communications Over an IP LAN 221
	DLP-5	Connecting to the Total Access 850 Using Telnet 225
	DLP-6	Adding/Removing Users and Changing Password Security Levels 229
	DLP-7	Updating the Firmware using TFTP 233
	DLP-8	Updating the Firmware using XMODEM 237
	DLP-9	Saving the Current Configuration Using TFTP 239
	DLP-10	Loading a Configuration Using TFTP 241
	DLP-11	Saving and Transferring a Current Configuration Using XMODEM 245
	DLP-12	Loading a Configuration Using XMODEM 247
	DLP-13	Saving and Loading Text Configuration using Terminal Command Line 249
	DLP-14	A.03 to A.04 Firmware Upgrade 253
	DLP-15	Using the ADTRAN Utility Syslog 257
	DLP-16	Connecting the Alarm Contacts and the External Input 261
	DLP-17	Configuring the Total Access 850 for Dual T1 Maps 265
Section 6	ADTRAN Utilities	269
	This section provides instructions for configuring and using the ADTRAN Utilities software programs including Telnet, VT100, Syslog, and TFTP.	
Section 7	MIBs	279
	This section is divided into two parts: (1) SNMP information for TDM units and (2) SNMP information for ATM units. Each section details the Management Information Bases (MIBs) supported, MIB Compilation Order, Traps Supported, and MIB Variables supported.	

SYSTEM DESCRIPTION

This section provides an overview of the Total Access 850 system.

CONTENTS

Features and Benefits	17
Configuration and Management	17
Software Upgradeable	17
Signaling Support	17
Integrated Components (with RCU)	18
Testing	18
Performance Monitoring	18
Modules	18
Total Access 850 Bank Controller Unit (BCU) (P/N 1200373L1)	19
BCU with Fractional T1 (P/N 1200373L2)	19
T1 RCU (P/N 4203376L1#TDM, 4203376L1#ATM and 1203376L1)	19
SDSL RCU (P/N 1200377L1, 1200377L2)	19
Power Supply Unit (P/N 1175006L2)	20
Echo Canceller with ADPCM (P/N 1203384L2)	20
Nx56/64K (V.35) Module (P/N 1200372L1)	20
Quad FXS Access Module (P/N 1175408L2)	20
Quad FXO Access Module (P/N 1175407L2)	20
OCU DP Access Module (P/N 1180005L1)	21
U-BR1TE Access Module (P/N 1180020L1)	21
E&M/TO Access Module (P/N 1180402L1)	21
Dual V.35 Access Module (P/N 1180025L1)	21
DSX-1 Access Module (P/N 1200385L1)	21
Single DS0 DP Access Module (P/N 1180003L1)	21

1. SYSTEM OVERVIEW

The Total Access 850 is an integrated access device designed for cost-effective deployment of voice and data services at the customer premises. The Total Access 850 system benefits integrated communications providers, such as CLECs, ILECs, and ISPs, who require a customer premises device that integrates voice and data functions. It provides a viable migration path from TDM to packet-based technology (see *Modules* on page 18 for details). The Total Access 850 features remote management, an integrated IP router, and special services slots. Preconfigured Total Access 850 packages are available.

The Total Access 850 is a modular device with two common slots, six access slots for FXS, FXO, Dual V.35, and UBR1TE modules, and two slots for special access modules. The FXS, FXO, Dual V.35, and UBR1TE modules are supported in the Router Control Unit (RCU); however, the Bank Controller Unit (BCU) also supports E&M, OCU DP, Single DS0 DP, and Nx56/64 modules. Using local or remote inband management, carriers can turn features, functions, and access ports on and off. Easy access to modules, common modules, power supplies, and the battery back-up system simplifies maintenance procedures. Hot-swappable modules may be replaced without disrupting other units. The four-circuit-per-module design ensures that only four analog circuits are affected when replacing a module.

The Total Access 850 is a compact, NEBS-compliant cabinet suitable for the customer premises or the central office. The 2U design uses little rack space; or when wallmounted, the 8½-inch by 11-inch chassis occupies a space the size of a piece of notebook paper. Two Total Access 850 systems can be mounted side-by-side in either 19-inch or 23-inch relay racks.

2. FEATURES AND BENEFITS

The following list gives Total Access 850 features and benefits. Some features are module-dependent.

Configuration and Management

- VT100 Emulation
- SNMP Management (with RCU)
- Telnet (with RCU)
- Dial-up remote management via external analog modem
- Six levels of password protection and privileges for Telnet access (with RCU)

Software Upgradeable

- Flash memory
- TFTP download (with RCU)
- XMODEM via control port

Signaling Support

- T1/FT1 integrated access
- TDM to ATM migration (with RCU)
- Upgradeable to DSL using SDSL RCU
- TR-08 signaling support
- Analog FXS and FXO voice expansion (four per module)

Integrated Components (with RCU)

- IP router
- DSX-1 T1/PBX interface
- V.35 Nx56/64 DTE interface

Testing

- Local and remote: payload/line, V.54 (depending on installed modules)
- Patterns: 511, QRSS, all ones, all zeros (depending on installed modules)

Performance Monitoring

- Reports: Information stored for last 24 hours in 15 minute increments
- Performance statistics per TR54016, T1.403, RFC1406
- Alarm reporting per TR54016, T1.403

3. MODULES

The Total Access 850 system offers several different system modules (including the power supply), system resource modules, and access modules.

System Modules

- Bank Controller Unit (BCU) (P/N 1200373L1)
- BCU with Fractional T1 (P/N 1200373L2)
- T1 Router Control Unit (RCU) with TDM software (P/N 4203376L1#TDM)
- T1 Router Control Unit (RCU) with ATM software (P/N 4203376L1#ATM)
- 3rd Generation T1 Router Control Unit (RCU) (P/N 1203376L1)
- SDSL RCU (P/N 1200377L1)
- 2nd Generation SDSL RCU (P/N 1200377L2)
- Power Supply Unit (P/N 1175006L2)

Resource Modules

- Echo Canceller with ADPCM (P/N 1203384L2)
- Nx56/64K Data Service Unit (DSU) (P/N 1200372L1)

Access Modules

- Quad FXS Access Module (P/N 1175408L2)
- Quad FXO Access Module (P/ N 1175407L2)
- UBR1TE Access Module (P/N 1180020L1)
- Dual V.35 Access Module (P/N 1180025L1)
- DSX-1 Access Module (P/N 1200385L1)

Access Modules (Requiring a BCU)

- E&M/TO Access Module (P/N 1180402L1)
- OCU DP Access Module (P/N 1180005L1)
- Single DS0 DP Access Module (P/N 1180003L1)
- Nx56/64 (V.35) Access Module (P/N 1200372L1)

Each access module is hot-swappable, with configuration restored upon replacement.



Replacing an access module with a different module type will result in configuration loss.

Total Access 850 Bank Controller Unit (BCU) (P/N 1200373L1)

The BCU is a common module plug-in unit with a built-in CSU. The BCU provides all control functions for the Total Access 850 common units and all individual access modules. A faceplate DB-9 (**ADMIN**) interface provides access for a VT100 terminal for screen menu provisioning, and bantam test jacks provide transmit and receive monitoring. An additional DB-9 (**TEST**) interface provides timing for DS0 test equipment. Faceplate LEDs show status information for the network and Fractional T1 (DSX-1 on L2 only). The unit consists of a main circuit board and daughter card and inserts directly in the controller slot on the Total Access 850 shelf. An 8-position DIP-switch is mounted on the daughter card and is used for T1 provisioning and clocking.

BCU with Fractional T1 (P/N 1200373L2)

The BCU with Fractional T1 provides all the functionality of the traditional BCU as well as a DSX-1/Fractional T1 interface for additional T1 service.

T1 RCU (P/N 4203376L1#TDM, 4203376L1#ATM and 1203376L1)

The RCU is a dual board assembly that provides the network interface for the Total Access 850 system. The RCU can provision, test, and provide status for any card in the system. A faceplate DB-9 (**CRAFT**) interface provides access for a VT100 terminal for screen menu provisioning, and bantam test jacks provide transmit and receive monitoring capabilities. Terminal menu access is also provided through the RJ-45 **CRAFT** interface located on the rear of the chassis. Faceplate LEDs show status information for the network port and Ethernet port. In addition, the RCU has an integrated router access through the 10BaseT connector on the backplane of the chassis. (3rd Generation RCUs provide a 10/100BaseT interface.) A DSX-1/Fractional T1 interface for additional T1 service is also provided.

SDSL RCU (P/N 1200377L1, 1200377L2)

The SDSL RCU is a dual board assembly that includes an SDSL network interface, Nx56/64 V.35 interface, and built-in IP router. The SDSL RCU can provision, test, and provide status for any card in the system. The faceplate has a DB-9 (**CRAFT**) port connection, and network, V.35, and Ethernet LEDs. An additional RJ-45 terminal menu interface is located on the rear of the chassis and is labeled **CRAFT**. The SDSL RCU is only used in ATM applications. It supports vendor-specific SDSL protocols, ATM, and Copper Mountain Frame Relay. Therefore, the SDSL RCU can interoperate with a variety of DSLAMs, including Lucent, Nortel, Copper Mountain, Nokia, and Alcatel. It also supports several voice gateways, including Jetstream and Broadband Loop Emulation Services (BLES) gateways. The SDSL RCU has

built-in Echo Cancellation for up to 24 voice ports. Adaptive Differential Pulse Code Modulation (ADPCM) resources are also built-in for up to 16 ports.

Power Supply Unit (P/N 1175006L2)

The Total Access 850 PSU is a common module plug-in unit designed to supply power to the system. The faceplate contains a momentary ACO pushbutton, a ring voltage Enable/Disable pushbutton, a Bank Alarm LED, Ring LED, and a power LED. All power, ground, and timing signals are pre-wired, thus eliminating additional wiring requirements.

Echo Canceller with ADPCM (P/N 1203384L2)

An Echo Canceller Module is available for use with the legacy T1 RCU (P/N 1200376L1 - ATM firmware only). Echo cancellation and ADPCM resources are built into the 3rd Generation T1 (P/N 1203376L1) and SDSL (P/N 1200 377Lx) versions of the RCU, so this module is not required when using the SDSL RCU. The Echo Canceller Module provides G.168 echo cancellation for voice over ATM applications and includes Adaptive Differential Pulse Code Modulation (ADPCM). ADPCM is a speech coding method which uses fewer bits than traditional Pulse Code Modulation (PCM), allowing the user to get more analog voice calls on less bandwidth. This is a dual-slot module and must be installed in the system resource slots (A and B).



*The Echo Canceller module ADPCM functionality automatically shifts ON/OFF when fax or modem calls are placed. To find out the current status of the Echo Canceller functionality, check the current status of each FXS port. The path of the current status can be found at the following path: **L2 PROTOCOL (T1 ATM-T1-ATM) > STATUS > PVC STATUS > PROTOCOL STATUS > POTS STATS > CODING TYPE** (this will display either PCM or ADPCM).*

Nx56/64K (V.35) Module (P/N 1200372L1)

This module is only available in Total Access 850 systems using a BCU. The Nx56/64k (V.35) Module activates the V.35 port on the rear of the chassis. This is a dual-slot module and must be installed in the system resource slots (A and B).

Quad FXS Access Module (P/N 1175408L2)

The Quad Foreign Exchange Subscriber (FXS) Module provides analog voice extension for the Total Access 850 platform. Four analog voice ports are used to connect to analog phones. The Quad FXS Module supports Loop Start, Ground Start, TR08 UVG and single, Dial Pulse Originate (DPO), and Ear and Mouth (E&M) signaling capability. Both immediate and wink modes of E&M supervision are supported. The Quad FXS Module also supports Private Line Automatic Ringdown (PLAR) through E&M immediate mode.

Quad FXO Access Module (P/N 1175407L2)

The Foreign Exchange Office (FXO) module interfaces to the Central Office switch and to an FXS or RPOTS card over a T1 facility. Four analog voice ports on the FXO access module provide four individual connections to the switch. The FXO supports standard Loop Start and Ground Start options as well as Dial Pulse Terminate (DPT) functionality. Up to six Quad FXO Access Modules may be installed in the Total Access 850.

OCU DP Access Module (P/N 1180005L1)

This module is only available in Total Access 850 systems using a BCU. The OCU DP module is a single port access module used to provide the interface between a DS0 time slot on the T1 and a 4-wire DDS device at the customer premises. The OCU DP supports up to 18 kft of copper for remote DSU connectivity.

U-BR1TE Access Module (P/N 1180020L1)

The UBR1TE is a module that plugs into a single access slot of the Total Access 850. It provides an ISDN U-interface and allows transport of Basic Rate 2B+D information over T1 carriers and twisted pair wiring.

E&M/TO Access Module (P/N 1180402L1)

This module is only available in Total Access 850 systems using a BCU. The E&M/TO module is a single port Ear and Mouth/Transmit Only access module. The primary application for this module is to provide PBX foreign exchange at the customer premises or tandem central office applications. This module is intended for interface with intra-building wiring. The E&M/TO module supports both 2- and 4- wire operation.

Dual V.35 Access Module (P/N 1180025L1)

The Dual V.35 Access Module is a DSU data port with two circuits that each deliver serial data over a V.35 interface. The module is designed as a dual slot module; it requires two slots in the Total Access 850 chassis. Each circuit of the Dual V.35 Access Module provides up to 24 channels of data in 56 or 64 kbps increments. Design operation is to transmit or receive high rate synchronous data from data terminal equipment (DTE) over a T1 interface. This module is currently only supported by the TDM version of the T1 RCU.

DSX-1 Access Module (P/N 1200385L1)

This module is only available in Total Access 850 systems using a T1 RCU. The DSX-1 Module installs into the Total Access 850 system to provide an additional DSX-1 interface (RJ-45) for support of multiple PBXs or other equipment with a DSX-1/FT1 interface. The module is functional in any of the six Total Access 850 module slots.

Single DS0 DP Access Module (P/N 1180003L1)

This module is only available in Total Access 850 systems using a BCU. The DS0 Dataport is a single port access module that serves as an interface to the basic DDS DS0 (64 kbps) signal to a T-carrier line. This module is used in conjunction with an ADTRAN All-Rate Office Channel Unit (OCU) dataport or Total Reach DDS dataport located at the end office to extend the DDS network to an end office which has exclusively-served voice channels.

ENGINEERING GUIDELINES

This section provides equipment dimensions, power requirements, front panel design, rear panel design, LEDs, and at-a-glance specifications.

CONTENTS

Power Requirements	25
AC System	25
DC System	25
Reviewing the Front Panel Design	25
Bank Controller Unit (1200373L1 and 1200373L2)	26
T1 Router Controller Unit (4200376L1#TDM and 4200376L1#ATM)	28
3rd GEN T1 Router Controller Unit (1203376L1)	30
SDSL Router Controller Unit (1200377L1 and 1200377L2)	32
Reviewing the Rear Panel Design	33
10/100BaseT Connection (JP1)	34
T1 Connection (JP2)	35
DSX-1 Connection (JP3)	35
Rear CRAFT Port (JP4)	36
Nx56k/64k Port (J1)	37
Alarm Relay Connection (P5)	37
Clock Wire-Wrap Strip (P1)	38
Customer Connection (P2)	38
T1 Wire-Wrap Connection (P3)	39
Power Connections (P6 and P7)	39
Access Module Interfaces	40
Power Supply Unit (P/N 1175006L2)	40
Quad FXS Access Module (P/N 1175408L2)	41
Quad FXO Access Module (P/N 1175407L1)	43
UBR1TE Access Module (P/N 1180020L1)	45
OCU DP Access Module (P/N 1180005L1)	49
E&M/TO Access Module (P/N 1180402L1)	49
Dual V.35 Access Module (P/N 1180025L1)	50
DSX-1 Access Module (P/N 1200385L1)	52

FIGURES

Figure 1. Total Access 850 Front Panel Layout	25
Figure 2. BCU Bantam Jack Test Diagram	28
Figure 3. BCU DB-9 Test Connector	28
Figure 4. RCU Bantam Jack Test Diagram	30
Figure 5. 3rd GEN RCU Bantam Jack Test Diagram	31
Figure 6. Total Access 850 Rear Panel	33
Figure 7. Connector Pinout	38
Figure 8. Alternate Power Connection	40
Figure 9. Quad FXS Connector Pin Assignments	42
Figure 10. Quad FXO Connector Pin Assignments	44

TABLES

Table 1. BCU Faceplate LEDs	26
Table 2. BCU DIP-Switch S1 Options	26
Table 3. T1 RCU CRAFT (DB-9, Female) Pinout	29

Table 4.	T1 RCU Faceplate LEDs	29
Table 5.	3rd GEN T1 RCU CRAFT (DB-9, Female) Pinout	30
Table 6.	3rd GEN T1 RCU Faceplate LEDs	31
Table 7.	SDSL RCU CRAFT (DB-9, Female) Pinout	32
Table 8.	SDSL RCU Faceplate LEDs	32
Table 9.	SDSL RCU DIP-Switch S1 Options	33
Table 10.	Total Access 850 Backplane Connections	34
Table 11.	Ethernet Pinout	34
Table 12.	Network Connection Pinout	35
Table 13.	DSX-1 Network Connection Pinout	36
Table 14.	Rear CRAFT Pinout	36
Table 15.	V.35 Winchester Pinout	37
Table 16.	Alarm Relay Connector Pinout	37
Table 17.	Alarm Notification	38
Table 18.	T1 Wire-Wrap Connector Pinout	39
Table 19.	PSU Faceplate LEDs	41
Table 20.	Quad FXS Module Faceplate LEDs	41
Table 21.	Quad FXS Module Specifications	42
Table 22.	Quad FXS Module Compliance Codes	43
Table 23.	Quad FXO Module Faceplate LEDs	43
Table 24.	Quad FXO Module Specifications	44
Table 25.	Quad FXO Module Compliance Codes	45
Table 26.	UBR1TE Module Faceplate LEDs	45
Table 27.	UBR1TE Slot/Amphenol Assignment	46
Table 28.	BCU DIP-Switch S1 Options	46
Table 29.	UBR1TE Module Specifications	48
Table 30.	UBR1TE Module Compliance Codes	48
Table 31.	OCU DP Pinout	49
Table 32.	E&M/TO Pinout	49
Table 33.	Dual V.35 Module Faceplate LEDs	50
Table 34.	Dual V.35 Interface Pinout (DB-26 to V.35)	50
Table 35.	Dual V.35 Module Specifications	51
Table 36.	Dual V.35 Module Compliance Codes	52
Table 37.	DSX-1 Module Faceplate LEDs	53
Table 38.	DSX-1 Module Interface Pinout	53
Table 39.	DSX-1 Module Specifications	53

1. EQUIPMENT DIMENSIONS

The Total Access 850 chassis is 8.5" W, 11" D, and 3.5" H and can be mounted in a 19-inch or 23-inch rack (mounting brackets included in shipment). All other equipment (modules) fit inside the base unit.

2. POWER REQUIREMENTS

Regardless of the configuration of access modules installed in the chassis, the following power requirements apply:

AC System

90/130 VAC, 60 Hz, 50 Watt Max

DC System

40/56 VDC, 50 Watt Max

3. REVIEWING THE FRONT PANEL DESIGN

Figure 1 shows the Total Access 850 front panel. Refer to *Access Module Interfaces* on page 40 for a discussion of available modules and the front panel functions of each.




Figure 1. Total Access 850 Front Panel Layout



UL 60950/NEBS requires all Total Access 850 empty slots to be covered with blank panels (P/N 1175099L1).

Bank Controller Unit (1200373L1 and 1200373L2)

The following is operational information pertaining to the Bank Controller Unit when used with the Total Access 850 system.

Faceplate LEDs

The faceplate Network LEDs labeled **T1 NETWORK** and **T1 FRACTIONAL** provide status information using a color coded message format. Table 1 gives a description of all faceplate LEDs for the BCU when used with the Total Access 850 system.

Table 1. BCU Faceplate LEDs

For these LEDs...	This color light...	Indicates that...
Network/Frac T1	OFF	there is no power to the system.
	RED	the unit is in Red Alarm (meaning the T1 is down, not connected, or framing is improperly configured).
	YELLOW	the unit is receiving Yellow Alarm (meaning the far end unit is in Red Alarm).
	Solid GREEN	the unit is functioning normally.
	Blinking GREEN	the network T1 interface is in Test mode.

DIP-Switch Settings

The Total Access 850 BCU can be provisioned from DIP-switches (S1) mounted on the PCB, or through screen menus accessed via the faceplate **ADMIN** interface. Basic T1 provisioning, clock source, and CSU loopback options are found on the DIP-switch panel. Table 2 gives DIP-switch provisioning information. DIP-switch S1 must be provisioned without the BCU in the chassis. Once the BCU is installed, any software provisioning made will override the DIP-switch settings. If the BCU is withdrawn and reinserted (power-cycled), the software options remain in effect. If a DIP-switch setting is changed while the BCU is withdrawn, the new DIP-switch setting takes effect. If none of the DIP-switch settings were changed, the unit will be provisioned for the last software settings.

Table 2. BCU DIP-Switch S1 Options

Switch	Function	Description	
S1-1	Framing Format	Enables either Extended Superframe Format (ESF) or Superframe Format (SF). This option must be configured identically with all other T1 network equipment on this circuit.	
		ON*	SF
		OFF	ESF

Table 2. BCU DIP-Switch S1 Options (Continued)

Switch	Function	Description	
S1-2	Line Code	Enables Bipolar Eight-Zero Substitution (B8ZS), which allows for Clear Channel operation for the T1 carrier system, or enables Alternate Mark Inversion (AMI). This option must be configured identically with all other T1 network equipment on this circuit.	
		ON*	AMI
		OFF	B8ZS
S1-3	TR-08 Signaling	Enables or disables the TR-08 signaling option. When enabled, S1-1 is ignored.	
		ON*	Enabled
		OFF	Disabled
S1-4	CSU Loopback	Enables the CSU loopback function. When this switch is enabled, the Total Access 850 will respond to CSU loopbacks sent from a remote network device or test equipment.	
		ON	Disabled
		OFF*	Enabled
S1-5 S1-6	Timing Mode A Timing Mode B	Determines the clock source options for the Total Access 850 system.	
		S1-5/S1-6	Function
		OFF/OFF	Loop timing: Derives timing from the network T1.
		ON/OFF	External Timing: Derives timing from the external bits clock.
		OFF/ON	Local Timing: Clock generated from internal timing source.
		ON*/ON*	Loop Timing: Derives timing from the network T1.
S1-7 S1-8	Line Build Out A Line Build Out B	Sets the attenuation properties to configure the receiver sensitivity in decibels (dB).	
		Additional settings can be provisioned through the terminal menu interface.	
		S1-7/S1-8	Setting
		OFF/OFF	0 dB/0-133 ft
		ON/OFF	-7.5 dB
		OFF/ON	-15 dB
ON*/ON*	-22 dB		
* Denotes factory default settings.			

Faceplate Bantam Jack

The faceplate bantam jack provides a means to monitor the network T1 connected to the rear of the Total Access 850 chassis. The jacks accept standard 310-type bantam plugs. Figure 2 display the bantam jack monitoring points.




Figure 2. BCU Bantam Jack Test Diagram

Faceplate TEST Connector

The faceplate **TEST** connector provides the necessary clock output required by standard DS0 Logic Test equipment (such as a TPI 108/109 test set). Specifically, the Test connector outputs 8 kHz and 64 kHz clock reference signal. DS0 test equipment is used to test DS0 access modules such as the OCU DP, DS0 DP, or UBRITE. Once the test equipment is connected to the reference clock source, individual tests can be performed on DS0 access modules using the faceplate bantam jacks on each unit. Figure 3 on page 28 illustrates the DB-9 **TEST** connector.




Figure 3. BCU DB-9 Test Connector

T1 Router Controller Unit (4200376L1#TDM and 4200376L1#ATM)

The following is operational information pertaining to the T1 Router Controller Unit when used with the Total Access 850 system.

Faceplate CRAFT Interface

Use the **CRAFT** port located on the RCU faceplate to configure the system via an EIA-232 connection. Table 3 displays the **CRAFT** port pinout.

Table 3. T1 RCU CRAFT (DB-9, Female) Pinout

Pin	Name	Description
1, 4, 6-9	UNUSED	—
2	RD	Receive Data (Output)
3	TD	Transmit Data (Input)
5	SG	Signal Ground

Faceplate LEDs

The faceplate LEDs provide status information using a color coded message format. Table 4 gives a description of all faceplate LEDs for the T1 RCU when used with the Total Access 850 system.

Table 4. T1 RCU Faceplate LEDs

For these LEDs...	This color light...	Indicates that...
PWR	OFF	there is no power to the system.
	Solid GREEN	the system is connected to an active power source.
T1 ALARM	OFF	there are no active T1 alarms on the system.
	ON	there is an active T1 alarm (yellow, red, or blue alarm) on the system.
T1 TEST	AMBER	the network T1 is in test mode (loopback).
T1 ERROR	Blinking RED	there are errors on the network T1 (framing errors, bipolar violations, or CRC errors).
V.35 TD	Blinking GREEN	there is transmit data detected on the V.35 port. This LED blinks with data traffic.
V.35 RD	Blinking GREEN	there is received data detected on the V.35 port. This LED blinks with data traffic.
ETH LI	OFF	there is no active Ethernet link.
	Solid GREEN	there is a valid Ethernet link on the 10BaseT interface.
ETH TX/RX	Blinking GREEN	there is received or transmitted data detected on the Ethernet interface. This LED blinks with data traffic.

Faceplate Bantam Jack

The faceplate bantam jack provides a means to monitor the network T1 connected to the rear of the Total Access 850 chassis. The jacks accept standard 310-type bantam plugs. Figure 4 displays the bantam jack monitoring points.




Figure 4. RCU Bantam Jack Test Diagram

3rd GEN T1 Router Controller Unit (1203376L1)

The following is operational information pertaining to the 3rd Generation T1 Router Controller Unit when used with the Total Access 850 system.

Faceplate CRAFT Interface

Use the **CRAFT** port on the RCU faceplate to configure the system via an EIA-232 connection. Table 5 on page 30 displays the **CRAFT** port pinout.

Table 5. 3rd GEN T1 RCU CRAFT (DB-9, Female) Pinout

Pin	Name	Description
1, 4, 6-9	UNUSED	—
2	RD	Receive Data (Output)
3	TD	Transmit Data (Input)
5	SG	Signal Ground

Faceplate LEDs

The faceplate LEDs provide status information using a color coded message format. Table 6 gives a description of all faceplate LEDs for the T1 RCU when used with the Total Access 850 system.

Table 6. 3rd GEN T1 RCU Faceplate LEDs

For these LEDs...	This color light...	Indicates that...
T1	GREEN	the network T1 interface is operational.
	RED	the network T1 is in Red Alarm (meaning the T1 is down, not connected, or framing is improperly configured).
	AMBER	the network T1 is in test mode (loopback).
ETH	GREEN	there is a valid 10 Mbps Ethernet link.
	AMBER	there is a valid 100 Mbps Ethernet link.
	RED	there is no active Ethernet link.

Faceplate Bantam Jack

The faceplate bantam jack provides a means to monitor the network T1 connected to the rear of the Total Access 850 chassis. The jacks accept standard 310-type bantam plugs. Figure 5 display the bantam jack monitoring points.




Figure 5. 3rd GEN RCU Bantam Jack Test Diagram

SDSL Router Controller Unit (1200377L1 and 1200377L2)

The following is operational information pertaining to the SDSL Router Controller Unit when used with the Total Access 850 system.

Faceplate CRAFT Interface

Use the **CRAFT** port on the RCU faceplate to configure the system via an EIA-232 connection. Table 7 displays the **CRAFT** port pinout.

Table 7. SDSL RCU CRAFT (DB-9, Female) Pinout

Pin	Name	Description
1, 4, 6-9	UNUSED	—
2	RD	Receive Data (Output)
3	TD	Transmit Data (Input)
5	SG	Signal Ground

Faceplate LEDs

The faceplate LEDs provide status information using a color coded message format. Table 8 gives a description of all faceplate LEDs for the SDSL RCU when used with the Total Access 850 system.

Table 8. SDSL RCU Faceplate LEDs

For these LEDs...	This color light...	Indicates that...
PWR	OFF	there is no power to the system.
	Solid GREEN	the system is connected to an active power source.
DATA	Blinking GREEN	there is transmit data detected on the network interface
NET ALRM	OFF	there are no active network alarms on the system.
	ON	there is an active network alarm on the system.
TEST	AMBER	the network interface is in test mode (loopback).
V.35 TD	Blinking GREEN	there is transmit data detected on the V.35 port. This LED blinks with data traffic.
V.35 RD	Blinking GREEN	there is received data detected on the V.35 port. This LED blinks with data traffic.
ETH LI	OFF	there is no active Ethernet link.
	Solid GREEN	there is a valid Ethernet link on the 10BaseT interface.
ETH TX/RX	Blinking GREEN	there is received or transmitted data detected on the Ethernet interface. This LED blinks with data traffic.

DIP-Switch Settings

The Total Access 850 SDSL RCU uses DIP-switches to determine power-up start mode. Table 9 provides details for the DIP-switches.

Table 9. SDSL RCU DIP-Switch S1 Options

Switch	Function	Description
S1-1	Firmware Mode	ON* (down) The unit powers up in the firmware update mode. This mode is not used for normal operation.
		OFF Disables the firmware update mode.
S1-2	Factory Defaults	ON* (down) The unit powers up with the factory defaults loaded.

* Denotes factory default settings.

4. REVIEWING THE REAR PANEL DESIGN

All connections are made through terminals, jacks, and wire-wraps on the backplane. A removable rear cover provides access to the backplane, and an access panel that mounts to the rear cover allows access to wire-wrap strips P1, P3, and P5, power terminal strip (P7), and clock termination switch (SW1) without removing the main rear cover. Most CPE applications will not require removal of the rear cover.

WARNING

Before removing the rear cover, do the following:

For systems using PSU (P/N 1175006L1) –

Remove the 20 Hz fuse before exposing backplane or accessing channel unit.

For systems using PSU (P/N 1175006L2) –

Depress the Ring Enable pushbutton to isolate the ring voltage from the Total Access 850.

Figure 6 shows the Total Access 850 backplane, and Table 10 on page 34 gives the backplane connections.




Figure 6. Total Access 850 Rear Panel

Table 10. Total Access 850 Backplane Connections

Ref Des	Device/Label	Technology
P1	wire-wrap strip	clock/tests
P2	50 pin amphenol	FXO, FXS, etc.
P3	wire-wrap strip	alternate T1 interface
P5	wire-wrap strip	alarms
P6	4 pin jack	primary -48 V in
P7	3-lug terminal	alternate -48 V in
JP1	RJ-48/E-NET	10BaseT Ethernet
JP2	RJ-48/T1	primary T1 interface
JP3	RJ-48/FT1	DSX1 interface
JP4	RJ-48/MAINT	EIA-232 CRAFT interface
J1	V.35	Nx56K/64K

10/100BaseT Connection (JP1)

Only the 3rd Generation RCUs provide a 10/100BaseT connection. All other available RCU Ethernet interfaces are 10BaseT.

The 10/100BaseT port (RJ-48C) provides a 10/100BaseT Ethernet LAN connection for IP Routing, TFTP, SNMP, and Telnet connections. Table 11 shows the 10/100BaseT pinout.



The 10/100BaseT Ethernet LAN interface may be used for intra-building networks only. This interface should not be connected to public networks.

Table 11. Ethernet Pinout

Pin	Name	Description
1	TX1	Transmit Positive
2	TX2	Transmit Negative
3	RX1	Receive Positive
4, 5	UNUSED	—
6	RX2	Receive Negative
7, 8	UNUSED	—

T1 Connection (JP2)

WARNING

The Total Access 850 provides dual T1 connection points. In all cases, only one of the connection points is used. When wire-wrapping of the T1 is utilized (using P3), a blank plug must be placed in the primary T1 connection (JP2). There is a potential of Class A3 T1 Span Power Voltage coming from the network.

The Total Access 850 system provides a single T1 port (located on the rear panel) and complies with the applicable ANSI and AT&T™ standards. The T1 interface provides the following functions:

- AMI or B8ZS
- Manual line build-out
- D4 or ESF framing
- Network performance monitoring and reporting
- Test loopbacks with QRSS generation checking
- Extensive self-testing

The T1 connection pinout is shown in Table 12.

Table 12. Network Connection Pinout

Pin	Name	Description
1	RXDATA-RING	Receive data from the network
2	RXDATA-TIP	Receive data from the network
3	UNUSED	—
4	TXDATA-RING	Transmit data toward the network
5	TXDATA-TIP	Transmit data toward the network
6, 7, 8	UNUSED	—

DSX-1 Connection (JP3)

The Total Access 850 system provides a single DSX-1 port (located in the rear of the unit). The DSX-1 interface provides the following functions:

- AMI or B8ZS
- Manual line build-out
- D4 or ESF framing

The DSX-1 interface pinout is shown in Table 13.

Table 13. DSX-1 Network Connection Pinout

Pin	Name		Description
1	R	TXDATA-RING	Transmit data from the network.
2	T	TXDATA-TIP	Transmit data from the network.
3	—	UNUSED	—
4	R1	RXDATA-RING	Receive data toward the network.
5	T1	RXDATA-TIP	Receive data toward the network.
6, 7, 8	—	UNUSED	—

Rear CRAFT Port (JP4)

The **CRAFT** port (EIA-232) on the rear of the chassis connects to a computer or modem and provides the following functions:

- Accepts EIA-232 input from a PC or a modem for controlling the Total Access 850.
- Baud rate is user-configurable.
- Acts as input for either VT100 or PC control.
- Acts as an interface for flash memory software downloads using XMODEM.

Table 14 shows the rear **CRAFT** port pinout.

Table 14. Rear CRAFT Pinout

Pin	Name	Description
1	GND	Ground - connected to unit chassis
2	RTS	Request to send - flow control
3	RXDATA	Data received by the Total Access 850
4	DTR	Data terminal ready
5	TXDATA	Data transmitted by the Total Access 850
6	CD	Carrier detect
7	UNUSED	—
8	CTS	Clear to send - flow control

Nx56k/64k Port (J1)

The Total Access 850 system provides a single V.35 Winchester-style connection on the rear of the chassis (as defined in Table 15).

Table 15. V.35 Winchester Pinout

Pin/CCIT	Description	Pin/CCIT	Description
A/101	Protective ground (PG)	V/115	RX clock (RC-A) to DTE
B/102	Signal ground (SG)	X/115	RX clock (RC-B) to DTE
C/105	Request to send (RTS) from DTE	P/103	Transmitted data (TD-A) from DTE
D/106	Clear to send (CTS) to DTE	S/103	Transmitted data (TD-B) to DTE
E/107	Data set ready (DSR) to DTE	Y/114	TX clock (TC-A) to DTE
E/109	Data carrier detect	AA/114	TX clock (TC-B) to DTE
H/—	Data terminal ready (DTR) from DTE	U/113	External TX clock (ETC-A) from DTE
J/—	Ring indicator (RI)	W/113	External TX clock (ETC-B) from DTE
R/104	Received data (RD-A) to DTE	NN/—	Test mode (TM) to DTE
T/104	Received data (RD-B) to DTE		

Alarm Relay Connection (P5)

This connection alerts the user when a selected alarm condition exists. Alarm relay contacts are open during normal operation. The alarm relay contacts close in the event of a local alarm condition or the receipt of an alarm from the T1 carrier. In a carrier alarm condition such as a Red, Yellow, or Blue (unframed all 1s), various alarm contacts in the PSU close. Carrier alarm conditions cause the Total Access 850 to initiate trunk processing. The following chain of events then occur:

1. MJ will be directly shorted to MJR.
2. MJV will be directly shorted to MJVR.

Contacts MJ and MJR can be overridden manually during an alarm condition by pressing the ACO pushbutton on the PSU faceplate. If the 3-Amp power fuse on the PSU trips, the -48ALM relay will close, providing a -48 VDC signal on that pin. This alarm cannot be overridden by the ACO pushbutton. Refer to Table 17 for alarm notifications.

Table 16 shows the pinout for the Alarm Relay connector.

Table 16. Alarm Relay Connector Pinout

Pin	Name	Description
1	-48 ALM	DC alarm output.
2	MJVR	Closes when a selected alarm condition is present.
3	MJV	Common connection between external circuitry and NC or NO terminal.
4	MJR	Major alarm audible common
5	MJ	Major alarm audible

Table 17. Alarm Notification

Alarm Condition	Relays Activated		
	MJR	MJVR	-48 ALM
Red Alarm	X	X	
Yellow Alarm	X	X	
AIS Alarm	X	X	
PSU Power Fuse Fails	X	X	X
Alarms ACO Deactivates	X	X	
Note: ACO will not deactivate MJR after a power fuse failure.			

Clock Wire-Wrap Strip (P1)

A single wire-wrap strip is provided on the Total Access 850 backplane for connection to an external bits clock. The external bits clock may be used to provide master timing for the Total Access 850 system.

Customer Connection (P2)

One 50-pin female amphenol connector (P2) provides the interconnect wiring for the access modules located in slots 1 through 6 of the chassis. This connector is usually terminated with a punch-down block for premises wiring or connected directly to a cross-connect or main distribution frame. Figure 7 details the connector pinout.




Figure 7. Connector Pinout

T1 Wire-Wrap Connection (P3)

WARNING

Network T1 connections can have up to 140 VDC. Use caution when making T1 connections.

There are two termination points for connecting the network T1 to the chassis: the primary RJ-48 connector (JP2) and the alternate wire-wrap pins on terminal strip P3 (see Figure 6 on page 33). Only one connector type is used (not both). The T1 primary connection is via the RJ-48 connector labeled T1 (JP2). This arrangement provides a convenient T1 connection for those installations where a T1 Smart Jack is used. Table 18 on page 39 shows the pinout for the T1 wire-wrap connector.

WARNING

The Total Access 850 provides dual T1 connection points. In all cases, only one of the connection points is used. When wire-wrapping of the T1 is utilized (using P3), a blank plug must be placed in the primary T1 connection (JP2). There is a potential of Class A3 T1 Span Power Voltage coming from the network.

Table 18. T1 Wire-Wrap Connector Pinout

P3 Wire-Wrap Connections		
Pin	Name	Description
1	R1	DS1 Ring input from network
2	T1	DS1 Tip input from network
3	R	DS1 Ring output from network
4	T	DS1 Tip output from network
5	Gnd	Ground

Power Connections (P6 and P7)

There are two power connections on the backplane: a modular DC plug (P6), and a three-lug terminal strip (P7) (refer to Figure 8 on page 40). The primary connection is the modular plug, which receives -48 VDC from an approved ADTRAN power supply/battery charging unit (for example, P/N 1175043L2). The alternate connection is screw terminal P7, which can be used if -48 VDC is available as in central office applications. The screw terminal connection is shown in Figure 8 on page 40.



During installation, power should be the last connection made after all other wire-wrap connections are completed.




Figure 8. Alternate Power Connection

5. ACCESS MODULE INTERFACES

Power Supply Unit (P/N 1175006L2)

The PSU receives externally supplied -48 VDC from connectors P4 (normal) and P5 (alternate) on the rear of the unit. Connector P4 connects from an approved ADTRAN Power Supply and Battery Charger unit. P5 is a 3-lug terminal strip that receives -48 VDC from the customer-supplied office power. Through switchmode operation, the PSU converts the incoming -48 VDC to regulated +5 VDC, +3.3 VDC, -7.5 VDC, -26 VDC, and -48 VDC for distribution to other modules. Ring voltage circuitry within the PSU generates 105 Vrms, 20 Hz ring voltage for distribution to the system's FXS cards. Ring voltage is disabled by pushing the **RING ENABLE** button.

Faceplate LEDs

The faceplate LEDs provide status information using a color coded message format. Table 20 gives a description of all faceplate LEDs for the Quad FXS Module when used with the Total Access 850 system.

Table 19. PSU Faceplate LEDs

For these LEDs...	This color light...	Indicates that...
POWER	OFF	the system is disconnected from the power source or powered off.
	GREEN	the system is connected to a power source and is powered on.
RING	OFF	ring generation is disabled for the system.
	GREEN	ring generation is enabled for the system.
BANK ALM	OFF	the system is in normal operation.
	Solid RED	there is currently an active alarm condition.
	Blinking RED	there was an alarm condition, but it was acknowledged by pressing the ACO pushbutton (located on the PSU faceplate).

Quad FXS Access Module (P/N 1175408L2)

The Quad FXS Access Modules use the 50-pin female amphenol connector on the rear of the Total Access 850 chassis to provide the interconnect wiring for the four analog circuits on each access module.

Faceplate LEDs

The faceplate LEDs provide status information using a color coded message format. Table 20 gives a description of all faceplate LEDs for the Quad FXS Module when used with the Total Access 850 system.

Table 20. Quad FXS Module Faceplate LEDs

For these LEDs...	This color light...	Indicates that...
BUSY	OFF	the interface is currently on-hook and not in use.
	Solid GREEN	the interface is currently off-hook (busy).
	Blinking GREEN	the interface is ringing.
	Sequencing 1-4	the assigned network T1 time slot is unavailable for use by the module.

Interface Pinout

Figure 9 shows the pinout connection for the amphenol connector. See Figure 7 on page 38 for closer detail.




Figure 9. Quad FXS Connector Pin Assignments

Specifications

Table 21 provides the detailed specifications for the Total Access 850 Quad FXS Module.

Table 21. Quad FXS Module Specifications

Power	6 W (off-hook)
Loop Current	23 mA (nominal) 20 mA (minimum)
Loop Resistance	1200 Ω (nominal) 1650 Ω (maximum) – 900 Ω /1350 Ω (line), 300 Ω (phone)
Terminating Impedance	900 Ω + 2.16 μ F 600 Ω + 2.16 μ F 900 Ω 600 Ω
Return Loss	900 Ω + 2.16 μ F ERL > 28 dB SRL > 20 dB
Trans Hybrid Loss	900 Ω + 2.16 μ F ERL > 28 dB SRL > 20 dB
Longitudinal Balance	200, 500, and 1000 Hz: > 58 dB min, > 63 dB avg 3000 Hz: > 53 dB min, > 58 dB avg
Frequency Response	300 to 3400 Hz: -0.5 dB and 1.0 dB
Idle Channel Noise	< 20 dBnC

Table 21. Quad FXS Module Specifications (Continued)

Signal to Distortion Ratio	0 to -30 dBm0: > 33 dB -30 to -40 dBm0: > 27 dB -40 to -45 dBm0: > 22 dB
Relative Humidity	Up to 95% noncondensing
Temperature	Operate at -40 °C to +65 °C Store at -40 °C to +70 °C
Tests	Self-test, digital loopback, network on-hook/off-hook, customer ring, and 1000 Hz (1 kHz) tone generation

Compliance Codes

Table 22 provides the compliance codes for the Total Access 850 Quad FXS Module.

Table 22. Quad FXS Module Compliance Codes

CODE	IN	OUT
Power Code (PC)	C	C
Telecommunication Code (TC)	–	X
Installation Code	A	–

Quad FXO Access Module (P/N 1175407L1)

The Quad FXO Access Modules use the 50-pin female amphenol connector on the rear of the Total Access 850 chassis to provide the interconnect wiring for the four analog circuits on each access module.

Faceplate LEDs

The faceplate LEDs provide status information using a color coded message format. Table 23 gives a description of all faceplate LEDs for the Quad FXO Module when used with the Total Access 850 system.

Table 23. Quad FXO Module Faceplate LEDs

For these LEDs...	This color light...	Indicates that...
BUSY	OFF	the interface is currently on-hook and not in use.
	GREEN	the interface is currently off-hook (busy).
	Blinking GREEN	the interface is ringing.
	Sequencing 1-4	the assigned network T1 time slot is unavailable for use by the module.

Interface Pinout

Figure 10 shows the pinout connection for the amphenol connector. See Figure 7 on page 38 for closer detail.




Figure 10. Quad FXO Connector Pin Assignments

Specifications

Table 24 provides the detailed specifications for the Total Access 850 Quad FXO Module.

Table 24. Quad FXO Module Specifications

Power	2 W (off-hook)
Terminating Impedance	900 Ω + 2.16 μF
Return Loss	900 Ω + 2.16 μF ERL > 28 dB SRL > 20 dB
Trans Hybrid Loss	900 Ω + 2.16 μF ERL > 28 dB SRL > 20 dB
Longitudinal Balance	200, 500, and 1000 Hz: > 58 dB min, > 63 dB avg 3000 Hz: > 53 dB min, > 58 dB avg
Frequency Response	300 to 3400 Hz: -0.5 dB and 1.0 dB
Idle Channel Noise	< 20 dBmC
Signal to Distortion Ratio	0 to -30 dBm0: > 33 dB -30 to -40 dBm0: > 27 dB -40 to -45 dBm0: > 22 dB
Relative Humidity	Up to 95% noncondensing
Temperature	Operate at -40 °C to +65 °C Store at -40 °C to +70 °C
Tests	Self-test, digital loopback, network on-hook/off-hook, customer ring, and 100 Hz tone generation

Compliance Codes

Table 25 provides the compliance codes for the Total Access 850 Quad FXO Module.

Table 25. Quad FXO Module Compliance Codes

CODE	IN	OUT
Power Code (PC)	C	C
Telecommunication Code (TC)	–	X
Installation Code	A	–

UBR1TE Access Module (P/N 1180020L1)

Each port of the UBR1TE Access Module provides an ISDN U-interface and allows the transport of Basic Rate 2B+D information over the T1 carrier and twisted pair wiring.

Faceplate LEDs

The faceplate LEDs provide status information using a color coded message format. Table 26 gives a description of all faceplate LEDs for the UBR1TE Module when used with the Total Access 850 system.

Table 26. UBR1TE Module Faceplate LEDs

For these LEDs...	This color light...	Indicates that...
STATUS	OFF	both the loop and the carrier synchronization are established.
	Solid RED	neither the loop nor the carrier synchronization is established.
	Blinking RED (every two seconds)	loop synchronization is established, but carrier synchronization is not.
	Blinking RED (twice every second)	carrier synchronization is established, but loop synchronization is not.
	GREEN	Layer 1 is established from the ISDN switch to the customer ISDN terminal equipment.
	Solid AMBER	front panel test in progress or the unit is responding to a 2B + D loopback request.
	Blinking AMBER (every two seconds)	the unit is responding to a B1 loopback request or has been forced into a B1 loopback from the terminal menus.
	Blinking AMBER (twice every second)	the unit is responding to a B2 loopback request or has been forced into a B2 loopback from the terminal menus.
REM (Remote)	GREEN	the unit has been provisioned by the BCU/RCU.
	OFF	the unit is provisioned by DIP-switches.

Interface Pinout

Table 27 provides the interface pinout for the UBR1TE interface slot/amphenol connector assignment.

Table 27. UBR1TE Slot/Amphenol Assignment

Total Access 850 Slot	Port 1 T/R
1	26/1
2	30/5
3	34/9
4	38/13
5	42/17
6	46/21

DIP-Switch Settings

The Total Access 850 UBR1TE Module can be provisioned from either the DIP-switches (S1) mounted on the PCB, or through screen menus accessed via the faceplate **CRAFT** interface port. Table 28 provides the DIP-switch setting details.

Table 28. BCU DIP-Switch S1 Options

Switch	Function	Description	
S1-1	MODE	Sets the termination mode as LULT (RT Typical) or LUNT (COT Typical).	
		ON	Unit is installed as Adjacent-to-U-Repeater, Adjacent-to-Customer, or Tandem Office Source configuration.
		OFF	Unit is installed as Adjacent-to-Switch or Tandem Office Sink configuration.

Table 28. BCU DIP-Switch S1 Options (Continued)

Switch	Function	Description	
S1-2	Tandem Office Installation	Indicates whether the unit is installed in a Tandem Office installation.	
		ON	LULT Mode – indicates an Adjacent-to-Customer configuration and sealing current should be provided (S1-1 ON). LUNT Mode – indicates an Adjacent-to-Switch configuration and no wake-up tones are provided.
		OFF	LULT Mode – indicates a Tandem Office Sink configuration and sealing current is not provided. LUNT Mode – indicates a Tandem Office Sink configuration and wake-up tones are provided.
S1-3 S1-4 S1-5	Service for: S1-3: B1 S1-4: B2 S1-5: D	Selects the service level to option the U-BR1TE module to deliver full ISDN (2B+D) or any of the following levels:	
		Service Level	S1-3, S1-4, S1-5
		2B+D	ON, ON, ON
		2B	ON, ON, OFF
		B1+D	ON, OFF, ON
		B2+D	OFF, ON, ON
B1	ON, OFF, OFF		
B2	OFF, ON, OFF		
D	OFF, OFF, ON		
S1-6	Zero Byte Substitution	Sets the Zero Byte Substitution parameter. The ZBS option must be set the same for the COT and RT. Check local provisioning guidelines.	
		ON	AMI-provisioned carrier.
		OFF*	B8ZS-provisioned carrier.

Specifications

Table 29 provides the detailed specifications for the Total Access 850 UBR1TE Module.

Table 29. UBR1TE Module Specifications

Loop Interface (ANSI T1.601)	
Line	2-wire (tip and ring)
Operating Mode	full duplex
Data Rate	160 kbps total; 144 kbps available to customer
Signal Format	2B1Q
Transmit Power	13 dBm to 14 dBm nominal
DS1 Facility Interface	
BR1/10 compatible equipment.	
Network Compatibility	
Interface	ISDN and other digital service, according to TR-NWT-000397
Mechanical	
Dimensions	3.125" H x 0.62" W, 1.01" D
Weight	< 1 lb
Power	
Current Draw	0.023 A maximum (@ -48V)
Environmental	
Temperature	Operating: -40 °C to +70 °C Storage: -40 °C to + 85 °C
Relative Humidity	Up to 95% noncondensing
Heat Dissipation	1.10 W (maximum)

Compliance Codes

Table 30 provides the compliance codes for the Total Access 850 UBR1TE Module.

Table 30. UBR1TE Module Compliance Codes

CODE	IN	OUT
Power Code (PC)	C	C
Telecommunication Code (TC)	–	X
Installation Code	A	–

OCU DP Access Module (P/N 1180005L1)

The OCU DP Access Module may be used for intra-building networks only. This interface should not be connected to public networks.

The OCU DP module is a single port access module used to provide the interface between a DS0 time slot on the T1 and a 4-wire DDS device at the customer premises. The OCU DP supports up to 18 kft of copper for remote DSU connectivity. This module is currently only supported by BCU L1 and L2. Table 31 gives this pinout.

Table 31. OCU DP Pinout

Total Access 850 Slot	T/R RX	T1/R1 TX
1	26/1	27/2
2	30/5	31/6
3	34/9	35/10
4	38/13	39/14
5	42/17	43/18
6	46/21	47/22

E&M/TO Access Module (P/N 1180402L1)

The E&M/TO Access Module may be used for intra-building networks only. This interface should not be connected to public networks.

The E&M/TO module is a single port Ear and Mouth/Transmit Only access module. The primary application for this module is to provide PBX foreign exchange at the customer premises or tandem central office applications. The E&M/TO module supports both 2- and 4- wire operation. This module is currently only supported by BCU L1 and L2. Table 32 gives the E&M/TO module pinout.

Table 32. E&M/TO Pinout

	Slot 1	Slot 2	Slot 3	Slot 4	Slot 5	Slot 6	
Pin	1	5	9	13	17	21	RING
	2	6	10	14	18	22	RING 1
	3	7	11	15	19	23	SG LEAD
	4	8	12	16	20	24	SB LEAD
Pin	26	30	34	38	42	46	TIP
	27	31	35	39	43	47	TIP 1
	28	32	36	40	44	48	E LEAD
	29	33	37	41	45	49	M LEAD

Dual V.35 Access Module (P/N 1180025L1)

The Dual V.35 module provides additional V.35 interfaces for customer premises equipment. The module takes up two access slots; therefore three modules (six additional ports) can be added to an empty chassis. The Total Access 850 can support a maximum of seven V.35 interfaces. V.35 ports provided by the Dual V.35 module are accessed on the front of the Total Access 850. This module is currently only supported by the TDM version of the T1 RCU. An ADTRAN 35 ft DB-26/V.35 adapter cable is required (P/N 1200167L1).

Faceplate LEDs

The faceplate LEDs provide status information using a color coded message format. Table 33 gives a description of all faceplate LEDs for the Dual V.35 Module when used with the Total Access 850 system.

Table 33. Dual V.35 Module Faceplate LEDs

For these LEDs...	This color light...	Indicates that...
Status	GREEN	the module is operating normally.
	RED	there is a card failure, or the T1 is down, or there is no valid data transfer occurring.
	AMBER	there is a test in progress.
	Blinking AMBER	no DS0s have been assigned to the interface.
TD	GREEN	the module is transmitting data to the network interface.
RD	GREEN	the module is receiving data from the network and transmitting it out the V.35 interface (to the DTE equipment).

Interface Pinouts

Table 34 provides the interface pinout for the DB-26 and V.35 interfaces.

Table 34. Dual V.35 Interface Pinout (DB-26 to V.35)

Pin (DB-26)	Pin (V.35)	Description
1	A	Frame ground
2,3	–	Unused
4	C	Request to send (RTS)
5	D	Clear to send (CTS)
6	E	Data set ready (DSR)
7	B	Signal ground
8	F	Carrier detect (CD)
9	P	Transmitted data (TD-A) from DTE
10	S	Transmitted data (TD-B) to DTE
11	R	Received data (RD-A) to DTE

Table 34. Dual V.35 Interface Pinout (DB-26 to V.35) (Continued)

12	T	Received data (RD-B) to DTE
13	U	External TX clock (ETC-A) from DTE
14-16	–	Unused
17	J	Ring indicator (RI)
18	L	LL
19	NN	Test mode (TM) to DTE
20	H	Data terminal ready (DTR) from DTE
21	–	Unused
22	Y	TX clock (TC-A) to DTE
23	AA	TX clock (TC-B) to DTE
24	V	RX clock (RC-A) to DTE
25	X	RX clock (RC-B) to DTE
26	W	External TX clock (ETC-B) from DTE

Specifications

Table 35 provides the detailed specifications for the Total Access 850 Dual V.35 Module.

Table 35. Dual V.35 Module Specifications

Data Rates	56 kbps to 1.536 Mbps (per interface)	
Relative Humidity	Up to 95% noncondensing	
Cable Assembly	DB-26 to V.35 P/N 1200167L1	
Temperature	Operate at -40 °C to +65 °C Store at -40 °C to +85 °C	
Tests	Self-test, DTE loopback, Network Loopback, 511 Pattern generation	
Electrical	Voltage	Current
	-42 to -56 VDC +3.3 VDC ± 10% +5.0 VDC ± 5% -7.5 VDC ± 10% -24 to -30 VDC	0 mA 20 mA 160 mA 50 mA 0 mA
Dimensions	3 3/16" W x 1 5/16" H x 10 1/8" D	
Weight	4.8 ounces	

Compliance Codes

Table 36 provides the compliance codes for the Total Access 850 Dual V.35 Module.

Table 36. Dual V.35 Module Compliance Codes

CODE	IN	OUT
Power Code (PC)	C	C
Telecommunication Code (TC)	–	–
Installation Code	A	–

DSX-1 Access Module (P/N 1200385L1)



The DSX-1 interface provided on the DSX-1 Access Module may be used for intra-building networks only. This interface should not be connected to public networks.

The DSX-1 Module is a single port (RJ-45) access module that provides a DSX-1 connection for customer premises equipment. This module supports PBXs or other equipment with a DSX-1/FT1 interface. This module is currently supported by the T1 RCU only.



Robbed-Bit Signaling is only passed to the DSX-1 Module from the 3rd Generation RCUs. Older RCUs do not have this capability.

Faceplate LEDs

The faceplate LEDs provide status information using a color coded message format. Table 37 on page 53 gives a description of all faceplate LEDs for the DSX-1 Module when used with the Total Access 850 system.

Table 37. DSX-1 Module Faceplate LEDs

For these LEDs...	This color light...	Indicates that...
Online	OFF	there is no power to the system.
	GREEN	the DSX-1 signal is present and synchronized; the channel is configured for use.
	RED	there is a present channel alarm on the T1 interface.
	Solid AMBER	there is a channel test in progress.
	Blinking AMBER	the card is initializing (during startup).

Interface Pinout

Table 38 provides the interface pinout for the provided RJ-45 DSX-1 interface.

Table 38. DSX-1 Module Interface Pinout

Pin	Name	Description
1	R1 RXDATA-RING	Receive data from the network (RING)
2	T1 RXDATA-TIP	Receive data from the network (TIP)
3	UNUSED	—
4	R TXDATA-RING	Transmit data towards the network (RING)
5	T TXDATA-TIP	Transmit data towards the network (TIP)
6,7,8	UNUSED	—

Specifications

Table 39 provides the detailed specifications for the Total Access 850 DSX-1 Module.

Table 39. DSX-1 Module Specifications

Capacity	T1: 1 to 24 DS0s
Framing	ESF and SF(D4)
Line Build Out	DSX-1: 0 to 655 feet in 133-foot increments
Line Coding	AMI (alternate mark inversion) or B8ZS (bipolar 8 zero substitution)
Line Rate	1.544 Mbps, \pm 75 bps
Relative Humidity	Up to 95% noncondensing
Terminating Impedance	100 ohms \pm 5%
Temperature	Operate at -0 °C to +50 °C Store at -40 °C to +70 °C
Tests	Self-test, local line, local payload, remote line, and remote payload

NETWORK TURNUP PROCEDURE

This section provides shipment contents list, grounding instructions, mounting options, and specifics of supplying power to the unit.

CONTENTS

Tools Required	56
Unpack and Inspect the SYSTEM	56
Contents of ADTRAN Shipments	57
Telecommunications Codes	57
Grounding Instructions	57
Supplying Power to the Unit	58
AC Powered Systems	58
DC Powered Systems	59
Making Alternate Power Connections	59
Mounting Options	60
Required Clearances	60
Wallmounting the Chassis	60
Installing Modules	61
Instructions for Installing the Power Supply Unit (P/N 1175006L2)	61
Instructions for Installing the Total Access 850 Controller and Access Modules	62
Module Shipping Contents	62
Quad FXO Access Module (P/N 1175407L2)	62
Quad FXS Access Module (P/N 1175408L2)	62
UBR1TE Access Module (P/N 1180020L1)	62
OCU DP Access Module (P/N 1180005L1)	63
E&M/TO Access Module (P/N 1180402L1)	63
Dual V.35 Access Module (P/N 1180025L1)	63
DSX-1 Module (P/N 1200385L1)	63

FIGURES

Total Access 850 Slot Designation (Front View)	61
--	----

TABLES

Table 1. Total Access 850 System Codes	57
Table 2. Power Supply Unit Codes	57

1. INTRODUCTION

This section discusses Total Access 850 installation.

2. TOOLS REQUIRED

The tools required for wallmount installation of the Total Access 850 shelf are:

- Four #8 x 3/4 inch pan-head wood screws
- Drill and drill bit set
- Flat head screwdriver (medium)
- Two Phillips head screwdrivers (small/medium)
- Wire-wrap gun (optional)
- 5-pair male amphenol cable (customer connection)
- Selected punch-down block and tool

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



During installation, power should be the last connection made.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

3. UNPACK AND INSPECT THE SYSTEM

Each Total Access 850 is shipped in its own cardboard shipping carton. Open each carton carefully and avoid deep penetration into the carton with sharp objects.

After unpacking the unit, inspect it for possible shipping damage. If the equipment has been damaged in transit, immediately file a claim with the carrier, and then contact ADTRAN Customer Service (see *Customer Service, Product Support Information, and Training* in the front of this manual).

Contents of ADTRAN Shipments

Your ADTRAN shipment of the Total Access 850 chassis includes the following items:

- The Total Access 850 Base Unit
- The Total Access 850 Series System CD
- Wallmount brackets and screws
- RJ-45 to RJ-45 8-pin cable (15 ft) - ADTRAN P/N 3125M008
- UL 1950 Notice Card - ADTRAN P/N 61200375L1-17



Customer must supply Ethernet cable and the DB-9 serial cable for configuration via the VT100 CRAFT interfaces.

4. TELECOMMUNICATIONS CODES

The installation configurations codes are given below.

Table 1. Total Access 850 System Codes

CODE	IN	OUT
PC	F	C
IC	E	–
TC	X	X

Table 2. Power Supply Unit Codes

CODE	IN	OUT
PC	F	C
IC	E	–
TC	A	–

5. GROUNDING INSTRUCTIONS

To following paragraphs provide grounding instruction information from the Underwriters' Laboratory UL1950 Standard for Safety of Information Technology Equipment Including Electrical Business Equipment, of July 28, 1995.

An equipment grounding conductor that is not smaller in size than the ungrounded branch-circuit supply conductors is to be installed as part of the circuit that supplies the product or system. Bare, covered, or insulated grounding conductors are acceptable. Individually covered or insulated equipment grounding conductors shall have a continuous outer finish that is either green, or green with one or more yellow stripes. The equipment grounding conductor is to be connected to ground at the service equipment.

The attachment-plug receptacles in the vicinity of the product or system are all to be of a grounding type, and the equipment grounding conductors serving these receptacles are to be connected to earth ground at the service equipment.

A supplementary equipment grounding conductor shall be installed between the product or system and ground that is in addition to the equipment grounding conductor in the power supply cord.

The supplementary equipment grounding conductor shall not be smaller in size than the ungrounded branch-circuit supply conductors. The supplementary equipment grounding conductor shall be connected to the product at the terminal provided, and shall be connected to ground in a manner that will retain the ground connection when the product is unplugged from the receptacle. The connection to ground of the supplementary equipment grounding conductor shall be in compliance with the rules for terminating bonding jumpers at Part K or Article 250 of the National Electrical Code, ANSI/NFPA 70. Termination of the supplementary equipment grounding conductor is permitted to be made to building steel, to a metal electrical raceway system, or to any grounded item that is permanently and reliably connected to the electrical service equipment ground.

The supplemental grounding conductor shall be connected to the equipment using a number 8 ring terminal and should be fastened to the grounding lug provided on the rear panel of the equipment. The ring terminal should be installed using the appropriate crimping tool (AMP P/N 59250 T-EAD Crimping Tool or equivalent.)

6. SUPPLYING POWER TO THE UNIT



The Total Access 850 has two power connection points. In all cases, only one of the connection points is used. Adhere to the alternate connection instructions to ensure correct installation.

On the Total Access 850 chassis, the incoming power termination point is on either of two backplane connections, P6 or P7 (see *Power Connections (P6 and P7)* on page 39). Both sources connect directly to the PSU. Connector P6 is used when the chassis is powered by an approved ADTRAN AC/DC Power Supply and Battery Charger (for example, P/N 1175043Lx) which mounts directly to the chassis. Connector P7 is used when -48 VDC is available on site and screw-type terminal connections are required.

AC Powered Systems

As shipped, the Total Access 850 is set to factory default conditions. After installing the chassis and any access modules, the Total Access 850 is ready for power-up. To power-up the unit, ensure that the unit is properly connected to an appropriate power source.



- *This unit shall be installed in accordance with Article 400 and 364.8 of the NEC NFPA 70 when installed outside of a Restricted Access Location (i.e., central office, behind a locked door, service personnel only area).*
- *To comply with GR-1089-CORE, Issue 3, this equipment MUST only be installed in a DC-C bonding and grounding environment. It may not be utilized in a DC-I (isolated) bonding and grounding environment.*
- *Power to the Total Access 850 AC system must be from a grounded 90-130 VAC, 50/60 Hz source.*
- *Verify the power receptacle uses double-pole, neutral fusing.*
- *Maximum recommended ambient operating temperature is 45 °C.*

DC Powered Systems

The DC powered Total Access 850 comes equipped with a DC Power supply to furnish the voltages necessary for proper backplane operation. As shipped, the Total Access 850 is set to factory default conditions. After installing the chassis and any access modules, the Total Access 850 is ready for power-up.



- *This unit shall be installed in accordance with Article 400 and 364.8 of the NEC NFPA 70 when installed outside of a Restricted Access Location (i.e., central office, behind a locked door, service personnel only area).*
- *To comply with GR-1089-CORE, Issue 3, this equipment MUST only be installed in a DC-C bonding and grounding environment. It may not be utilized in a DC-I (isolated) bonding and grounding environment.*
- *Power to the Total Access 850 DC system must be from a reliably grounded -48 VDC source which is electrically isolated from the AC source.*
- *The branch circuit overcurrent protection shall be a fuse or circuit breaker rated minimum 48 VDC, maximum 20A.*
- *A readily accessible disconnect device, suitably approved and rated, shall be incorporated in the input source wiring.*
- *Maximum recommended ambient operating temperature is 45 °C.*

Making Alternate Power Connections

For wire-wrap or screw terminal connections, the rear cover does not need to be removed; only the terminal access cover needs to be removed. Make wire-wrap or screw terminal connections as follows:

1. Unscrew the access cover hold-down screw.
2. Slide the access cover down slightly to disengage the lock-tabs from their slots.



Use wire gauge suitable for the application.

3. Identify the wire-wrap pins designated for use, and make the connections starting with the pins closest to the exit port to avoid wiring interference as work progresses.
4. If alternate power connection to P7 is to be used, make those terminal connections last.
5. Carefully route wiring through the exit port.
6. Position and align the access cover tabs to the slots; insert the tabs and slide the cover up slightly until the screw holes are aligned. Ensure that exit wiring is not pinched or damaged.
7. Reinsert the hold-down screw.

7. MOUNTING OPTIONS

The Total Access 850 chassis may be wallmounted or installed in a 19-inch or 23-inch rack. Wallmount brackets are included with the chassis. For a rackmount installation, the Total Access 850 Base Unit allows flush-face mount, face-forward mount, center mount, and rear mount.



The Total Access 850 chassis includes wallmount brackets. If rack mount brackets are needed, use part number 1175045L1 or 1175046L1 for 19 inch or 23 inch, respectively.



Be careful not to upset the stability of the equipment mounting rack when installing this product.

Required Clearances

A minimum 10-inch clearance is required on the front end for access module insertion and withdrawal. On the backplane end, a five-inch clearance is required for wiring access to the V.35 connector. For those units installed in a communications bay, standard bay clearances are satisfactory.

Wallmounting the Chassis

Tools Needed

The Total Access 850 chassis mounts and connects with standard fasteners and hand tools:

- Four #8 x 3/4-inch pan-head wood screws
- Drill and drill bit set
- Flat head screwdriver (medium)
- Two Phillips head screwdrivers (small/medium)
- Wire-wrap gun (optional)
- 25-pair male amphenol cable (customer connection)
- Selected punch-down block and tool

Installing the Chassis

1. Position the chassis at the desired location; observe required clearances and ensure cable plugs reach their designated sockets.
2. Ensure the chassis is plumb; then mark through the flange mounting holes to identify where the pilot holes will be drilled.
3. Using a 1/16-inch drill bit, drill pilot holes at the marked locations.
4. Mount the chassis using the four #8 x 3/4-inch pan-head wood screws.

8. INSTALLING MODULES

Figure 11 shows the slot numbering designation as viewed from the front of the Total Access 850 chassis. The functionally identical option slots only accept Total Access 850 access modules, and the controller slots only accept Total Access 850 controller modules.




Figure 11. Total Access 850 Slot Designation (Front View)

WARNING

Access modules are intended to be serviced by qualified service personnel only.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Instructions for Installing the Power Supply Unit (P/N 1175006L2)

Follow the steps below to install the Power Supply Unit.

1. The Power Supply Unit inserts directly into the common card area in the position labeled PSU. The unit is mechanically keyed to prevent insertion in any other slot.



Prior to circuit card installation, remove the chassis card-lock safety bar by disengaging the captured screw and lifting the safety bar away from the chassis.

2. To install the PSU, grasp the unit by the faceplate while supporting the bottom side.

3. Align the card edges to the guide grooves and insert the unit until the edge connector seats firmly into the backplane.
4. Lock the card in place by pushing in on the lock lever.
5. Reinstall the card-lock safety bar.

Instructions for Installing the Total Access 850 Controller and Access Modules

Individual access modules insert from the front. A locking bar holds the modules in place for added security. Disengaging the captured screw allows removal of the locking bar. To install Controller Resource and Access Modules for the Total Access 850, follow the steps outlined below.

1. Hold the access module by the faceplate while supporting the bottom side.
2. Align the module edges to the guide grooves for the designated slot.
3. Insert the module until the edge connector seats firmly into the backplane.
4. Lock the module in place by pushing in on the locking lever.
5. Connect the cables to the associated device(s). All wiring connections terminate on the backplane of the chassis.

9. MODULE SHIPPING CONTENTS

Quad FXO Access Module (P/N 1175407L2)

Shipping Contents

The ADTRAN shipment of the Quad FXO Access Module includes the following:

- Quad FXO Access Module

Quad FXS Access Module (P/N 1175408L2)

Shipping Contents

The ADTRAN shipment of the Quad FXS Access Module includes the following:

- Quad FXS Access Module

UBR1TE Access Module (P/N 1180020L1)

Shipping Contents

The ADTRAN shipment of the UBR1TE Access Module includes the following items:

- UBR1TE Access Module
- UBR1TE Access Module Job Aid

OCU DP Access Module (P/N 1180005L1)***Shipping Contents***

The ADTRAN shipment of the OCU DP Access Module includes the following items:

- OCU DP Access Module
- OCU DP Access Module Job Aid

E&M/TO Access Module (P/N 1180402L1)***Shipping Contents***

The ADTRAN shipment of the E&M/TO Access Module includes the following items:

- E&M/TO Access Module
- E&M/TO Access Module Job Aid

Dual V.35 Access Module (P/N 1180025L1)***Shipping Contents***

The ADTRAN shipment of the Dual V.35 Access Module includes the following items:

- Dual V.35 Access Module
- Dual V.35 Access Module Job Aid

DSX-1 Module (P/N 1200385L1)

The ADTRAN shipment of the DSX-1 Module includes the following:

- DSX-1 Module

USER INTERFACE GUIDE

This section provides detailed descriptions of all menu options and configuration parameters available for the Total Access 850 when used with a Router Control Unit (RCU). This section does not apply to systems that employ a Bank Control Unit (BCU).

This section of ADTRAN's Total Access 850 System Manual is designed for use by network administrators and others who will configure and provision the system. It contains information about navigating the VT100 user interface, configuration information, and menu descriptions.

CONTENTS

Navigating the Terminal Menu	67
Terminal Menu Window	67
Navigating using the Keyboard Keys	69
MAIN Menu and System Control	71
Selecting the Appropriate Menu	71
Security Levels	72
Menu Descriptions	72
System Info	73
System Config	75
System Utility	88
Interfaces	94
Interfaces (Network T1)	94
Interfaces (DSX)	98
Interfaces (ETH)	101
Interfaces (V35)	102
Interfaces (FXS)	103
Interfaces (FXO)	107
Interfaces (DSX-1 Module)	109
Interfaces (UBR1TE Module)	111
L2 Protocol (T1 TDM Firmware)	116
L2 Protocol (T1 TDM Firmware) – T1 Interface	117
L2 Protocol (T1 TDM Firmware) – T1 Interface > PPP	118
L2 Protocol (T1 TDM Firmware) – T1 Interface > FRE Protocol	121
L2 Protocol (T1 TDM Firmware) – T1 Interface > HDLC Protocol	125
L2 Protocol (T1 TDM Firmware) – T1 Interface > Auto Protocol	126
L2 Protocol (T1 ATM Firmware)	128
L2 Protocol (T1 ATM Firmware) – T1 Interface	129
L2 Protocol (T1 ATM Firmware) – T1 Interface > ATM	129
L2 Protocol (T1 ATM Firmware) – T1 Interface > CuMTN	139
L2 Protocol (T1 ATM Firmware) – V.35 Interface	141
L2 Protocol (T1 ATM Firmware) – DSX Interface	143
L2 Protocol (All Firmware) – ETH Interface > 802.3 Protocol	144
Bridge	145
Router	148
Security	170
DS0 Maps	179
Appendices (T1 TDM Applications)	182
Appendices (T1 ATM Applications)	199

FIGURES

Figure 1.	Top-Level Terminal Menu Window	67
Figure 2.	Alternate Menu View	68
Figure 3.	System Info Menu	73
Figure 4.	System Config Menu	75
Figure 5.	System Utility Menu	88
Figure 6.	Interfaces Menus	94
Figure 7.	UBR1TE Network Configurations.....	112
Figure 8.	L2 Protocol (T1 TDM) Menu.....	116
Figure 9.	L2 Protocol (T1 TDM) Menu.....	128
Figure 10.	Bridge Menu.....	145
Figure 11.	Router Menu	148
Figure 12.	Security Menu	171
Figure 13.	DS0 Maps Menu	179
Figure 7.	Application Diagram.....	199
Figure 10.	Application Diagram.....	204

TABLES

Table 1.	Password Security Level	72
Table 2.	Instructions for Changing Passwords	76
Table 3.	Telnet Security Levels	78

horizontally across the window. To change the view, move your cursor to an index number and press <ENTER>. Figure 2 shows this alternate view. Fields and submenu names may vary slightly in this view.




Figure 2. Alternate Menu View

Window Pane Navigation

Use the following chart to assist you in moving between and within the two window panes.

To do this...	Press this key...
Move from left pane to right pane	Tab Enter Right arrow
Move from right pane to left pane	Tab Escape Left arrow Backspace
Move within each pane	Up arrow Down arrow Left arrow Right arrow

Right Window Pane Notation

The right window pane shows the contents of the currently selected menu. These contents include both submenu items and data fields. Some submenus contain additional submenus and some data fields contain additional data fields. The following chart explains the notation used to identify these additional items.

This notation...	Means that...
[+]	more items are available when selected.
[DATA]	more items are available when selected.
<+>	an action is to be taken, such as activating a test.
Highlighted menu item	you can enter data in this field.
Underlined field	the field contains read-only information.

Additional Terminal Menu Window Features

- DS0 Status – displays the current mapping of DS0s in the Total Access 850 system. DS0s mapped to the router display **r**, unmapped DS0s display **–**, and all other DS0s display *****.
- Tool Tip – provides a brief description of the currently selected mode.
- Slot Status – displays type of module installed in each slot. No entry will appear for slots not containing a module.
- Telnet Info – displays information pertaining to the active Telnet session. This information is not displayed when connecting to the system via the **CRAFT** interface.
- Ethernet Link Status – displays the current status of the integrated Ethernet interface (located on the rear of the chassis). This information is only available when using a 3rd Generation RCU.
- Extended Help – displays information about selected commands (CTRL+A).
- Navigation Help – lists characters used for navigating the terminal menu and session management (CTRL+Z).
- System Time – displays the current time.
- Network Status – displays network status information as **UP** or **DOWN**.

Navigating using the Keyboard Keys

You can use various keystrokes to move through the terminal menu, to manage a terminal menu session, and to configure the system. Press <CTRL+Z > to activate a pop-up screen listing the navigation keystrokes.

Moving through the Menus

To do this...	Press this key...
Return to the home screen	H
Jump between two menu items Press <J> while the cursor is located on a menu item, and you jump back to the main screen. Go to another menu item, press <J>, and you jump back to the screen that was displayed the first time you pressed <J>. Press <J> anytime you want to jump between these items.	J

To do this...	Press this key...
Select items	Arrows
Edit a selected menu item	Enter
Cancel an edit	Escape
Close pop-up help screen	Escape
Move between the left and right panes	Tab Arrows
Move to the top of a screen	A
Move to the bottom of a screen	Z
Ascend one menu level	Backspace
Jump to terminal mode	CTRL+T
Jump to NAT menu	CTRL+N

Session Management Keystrokes

To do this...	Press this key...
Log out of a session	CTRL+L
Refresh the screen To save time, only the portion of the screen that has changed is refreshed. This option should only be necessary if the display picks up incorrect characters caused by disconnecting and reconnecting the terminal session.	CTRL+R

Configuration Keystrokes

To do this...	Press this key...
Restore factory default settings This setting restores the factory defaults based on the location of the cursor. If the cursor is on an interface line (in the INTERFACES menu), then only the selected interface is updated to factory defaults.	F
Copy selected items to the clipboard The amount of information you can copy depends on the cursor location when you press <C>: If the cursor is over an editable field, only that item is copied. If the cursor is over the index number of a list, then all of the items in the row of the list are copied. For example, if the cursor is over the selection # field in the INTERFACES screen, all of the information associated with the interface is copied.	C
Paste the item stored in the clipboard, if the information is compatible You must confirm all pastes — except those to a single editable field.	P

To do this...	Press this key...
Increment the value of certain types of fields by one when you paste information into those fields	>
Decrement the value of certain types of fields by one when you paste information into those fields	<
Save the current configuration immediately to RAM	CTRL+W
Insert a new list item For example, add a new item to the TELNET USER connection list by pressing <I> while the cursor is over the index number.	I
Delete a list item For example, delete an item from the TELNET USER connection list by pressing <D> while the index number is active.	D

Getting Help

The bottom line of the terminal menu window contains context-sensitive help information. When the cursor is positioned over a set of configuration items, a help message displays (when available) providing a description of the item. When more detailed help is available for a particular item, ^A displays at the bottom of the window. At this point, pressing <CTRL+A> displays a pop-up help screen with information about the item.

Press <CTRL+Z> to activate a help screen that displays the available keystrokes you can use to navigate the main menu system. Press <Exit> to remove these help screens.

2. MAIN MENU AND SYSTEM CONTROL

Selecting the Appropriate Menu

The main menu system is the access point to all other operations. Each menu item has several functions and submenus that identify and provide access to specific operations and parameters. Use the following chart to help select the appropriate menu.

To do this...	Go to this menu...
Review and monitor general system information for the Total Access 850	SYSTEM INFO
Set up the operational configuration for the Total Access 850	SYSTEM CONFIG
Upgrade firmware, perform config transfers, ping, and access terminal mode	SYSTEM UTILITY
Review and configure settings for all interfaces (including installed modules)	INTERFACES
Configures the Layer 2 protocol for the various interfaces (T1, Ethernet, etc.) and provides all applicable L2 status information	L2 PROTOCOL
Configure the bridging parameters and view applicable bridging statistics	BRIDGE

To do this...	Go to this menu...
Define, configure, and monitor all Total Access 850 Router functions	ROUTER
Configure security filters for L2 traffic and define RADIUS server parameters	SECURITY
Map data and voice ports (from integrated interfaces as well as installed modules) to network time slots	DS0 MAPS

Security Levels



*Password security levels only apply to Telnet connections. Connecting to the system through the RCU faceplate **CRAFT** or rear **CRAFT** interface automatically provides maximum rights.*

To edit main menu system items, you must have a password and the appropriate security level. Table 1 describes the security levels.

Table 1. Password Security Level

Security Level	Description
Full	Permission to edit every menu item, including creating and editing passwords - maximum rights
Support	Access to all commands except passwords
Config	Access to all commands except passwords, flash/firmware download, configuration transfers, authentication methods, terminal mode, and unit reset
Router	Read/write access to all Router menu items
Voice	Read/write access to all Voice menu items
Status	Read-only permission for all menu items - minimum rights

3. MENU DESCRIPTIONS

The remainder of this section describes Total Access 850 menu and submenu options.



To help you follow the terminal menu hierarchy, the following notations are used:

MENUS > SUBMENUS > SUB-SUBMENUS

SYSTEM INFO

The **SYSTEM INFO** menu provides basic information about the unit as well as data fields for editing information. Figure 3 displays the submenus that are available when you select this menu item.




Figure 3. System Info Menu

SYSTEM INFO > SYSTEM NAME

Provides a user-configurable text string for the name of the unit. This name can help you distinguish between different installations. You can enter up to 127 alpha-numeric characters in this field, including spaces and special characters (such as an underscore). This name will appear on the top line of all screens.

SYSTEM INFO > SYSTEM LOCATION

Provides a user-configurable text string for the location of the unit. This field is to help you keep track of the actual physical location of the unit. You can enter up to 127 alphanumeric characters in this field, including spaces and special characters (such as an underscore).

SYSTEM INFO > SYSTEM CONTACT

Provides a user-configurable text string for a contact name. You can use this field to enter the name, phone number, or E-mail address of a person responsible for the unit. You can enter up to 127 alpha-numeric characters in this field, including spaces and special characters (such as an underscore).

SYSTEM INFO > UNIT NAME

(Read only) Displays a product-specific name for the unit (such as TA 850 RCU).

SYSTEM INFO > CLEI CODE

(Read only) Displays the registered CLEI code for the unit.

SYSTEM INFO > PART NUMBER

(Read only) Displays the ADTRAN-specific part number for the unit.

SYSTEM INFO > SERIAL NUMBER

(Read only) Displays the serial number for the unit. The serial number of the Total Access 850 will automatically display in this field. This serial number matches the serial number located on the bottom of the unit's chassis.

SYSTEM INFO > FIRMWARE REVISION

(Read only) Displays the current firmware revision level of the unit.

SYSTEM INFO > BOOTCODE REVISION

(Read only) Displays the current bootcode revision.

SYSTEM INFO > SYSTEM UPTIME

Displays the length of time the Total Access 850 system has been running. Each time you reset the system, this value resets to 0 days, 0 hours, 0 min and 0 secs.

SYSTEM INFO > DATE/TIME

Displays the current date and time, including seconds. To edit this field, place the cursor on the field and press <ENTER>. Then, enter the time in a 24-hour format (such as 23:00:00 for 11:00 pm), and the date in mm-dd-yyyy format (for example, 10-30-1998). Press <ENTER> when you are finished to accept the change.



The System Date and Time will reset to 12:00 January 1, 1990 after a system power loss. If accurate system date and time information is crucial, consider using a time server to prevent the clock reset.

SYSTEM CONFIG

Set up the unit's operational configuration from the **SYSTEM CONFIG** menu. Figure 4 shows the items included in this menu.




Figure 4. System Config Menu

SYSTEM CONFIG > MANAGEMENT

Set up the **CRAFT PORT**, **TELNET ACCESS**, **SNMP MANAGEMENT**, and **FDL MANAGEMENT** from this menu.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT

Set up the **CRAFT PORT** parameters from this menu. The unit's VT100 **CRAFT** port can be accessed via an RJ-48 connector located on the rear of the unit, or via the DB-9 connector on the front of the unit.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > PASSWORD PROTECT

When **PASSWORD PROTECT** is set to **NO**, the **CRAFT** port is not password protected. When set to **YES** (def), the unit will prompt for a password upon startup.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > PASSWORD

Enter the user-defined password (up to 30 alphanumeric characters including spaces and special characters) to protect the **CRAFT** port. By default, no password is entered. Table 2 on page 76 provides instructions for changing the password.



*Connecting directly to the **CRAFT** port provides full access to all menus. Enable the password on the **CRAFT** port to protect against unauthorized access.*

Table 2. Instructions for Changing Passwords

Step	Action
1	Select the PASSWORD field—a new PASSWORD field displays.
2	Type the new password in the ENTER field.
3	Type the new password again in the CONFIRM field.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > IDLE TIME

This option defines the amount of time in minutes user may stay connected without any activity on the **CRAFT** port before the user is automatically logged out of the system. A value of **0** disables this inactivity timer function enabling users to stay connected until manually logged out. The value range is **0** (def) to **255** (minutes).

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > BAUD RATE

This is the asynchronous rate that the **CRAFT** port will run. The possible values are **300, 1200, 2400, 4800, 9600, 19200, 38400, 57600, and 115200**. The default value is **9600**.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > DATA BITS

This is the asynchronous bit rate that the **CRAFT** port will run. The possible values are **7** or **8** (def) bits.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > PARITY

This is the asynchronous parity that the **CRAFT** port will run. The possible values are **NONE** (def), **ODD**, or **EVEN**.

SYSTEM CONFIG > MANAGEMENT > CRAFT PORT > STOP BITS

This is the number of stop bits used for the **CRAFT** port. The possible values are **1** (def), **1.5** or **2**.

SYSTEM CONFIG > MANAGEMENT > TELNET ACCESS

Activate the Telnet access and set up the various Telnet parameters from this menu. The Total Access 850 supports up to five simultaneous Telnet sessions.



The Total Access 850 ships with default Telnet Access parameters of: guest (user), password (password). Change this password during the initial configuration to protect your unit.

SYSTEM CONFIG > MANAGEMENT > TELNET ACCESS > ACCESS

Sets **ACCESS** to **ON** or **OFF**. The factory default value for this parameter is **ON**.

SYSTEM CONFIG > MANAGEMENT > TELNET ACCESS > AUTHEN METHOD

Set up the Telnet authentication method from this menu. The choices are **LOCAL PASSWORD**, **RADIUS**, **LOCAL/RADIUS**, and **RADIUS/LOCAL**. **LOCAL/RADIUS** indicates that the unit will try Local Password Authentication first, and if that fails, it will try Radius Authentication. **RADIUS/LOCAL** indicates that the unit will try Radius authentication first, and if that fails, it will try Local Password authentication. The default is **LOCAL PASSWORD**.

SYSTEM CONFIG > MANAGEMENT > TELNET PORT

Defines the TCP port number used when establishing a Telnet session. Normal Telnet port is 23. Enter a customized port number if desired.

SYSTEM CONFIG > MANAGEMENT > TELNET ACCESS > USER LIST

Add Telnet users and control the Telnet access conditions through this menu.

#

Display the index number of the Telnet users. Up to four users can be configured for access to the unit. Each user can be assigned a security level and idle time.

NAME

The name is a text string of the user name for this session. You can enter up to 15 characters in this field. The factory default is no entry in the **NAME** field.

PASSWORD

When the authenticating method is password, or password radius, this text string is used for the password. You can enter up to 30 characters in this field. The factory default is no entry in this field.

IDLE TIME (MINS)

This sets the amount of time in minutes you can be idle before you are automatically logged off. The factory default is **10 MINUTES**. The range is **1 TO 255 MINUTES**.

LEVEL

This is the security level granted to the user. Table 3 on page 78 gives a brief description of each level. The factory default is **FULL**.

Table 3. Telnet Security Levels

Security Level	Description
Full	The user has all access to view and configure all menus (same as logging in to the CRAFT port)
Support	The user has read only access to view the SYSTEM INFO menu. The user has privileges to view and change everything under the SYSTEM CONFIG menu except for the CRAFT port settings, Telnet access lists, and the SNMP management communities. The user has full access to the SYSTEM UTILITY menu, including the ability to upgrade firmware and reset the unit. The user has full access to the INTERFACES, L2 PROTOCOL, BRIDGE, ROUTER, and DS0 menus. The user does not have the ability to set RADIUS SERVER settings under the SECURITY menu.
Config	The same privileges as support, except that the user does not have privileges to download firmware or configuration from the SYSTEM UTILITY menu. The user additionally does not have the privilege to reset the unit remotely, or enter the terminal menu.
Router	The user has read only privileges for the SYSTEM INFO menu. There is no access to the SYSTEM CONFIG menu. The user has PING and TRACEROUTE access from the SYSTEM UTILITY menu. The user is limited to Ethernet configuration and status from the INTERFACES menu. The user has full access to the BRIDGE and ROUTER menus. Access is limited to filters only from the SECURITY menu.
Voice	The user has read only privileges for the SYSTEM INFO menu. The user has access to the PING and TRACEROUTE utilities from the SYSTEM UTILITIES menu. The user has full access to the FXS module from the INTERFACES menu.
Status	The user has read access of all menus except for the following: SYSTEM CONFIG/CRAFT PORT, SYSTEM CONFIG/TELNET ACCESS, SYSTEM CONFIG/SNMP MANAGEMENT, and SECURITY/ RADIUS SERVER . The user does not have access to UPGRADE FIRMWARE, UPGRADE CONFIG, PING, or TRACEROUTE menus. The user cannot reset the unit or enter terminal mode.

SYSTEM CONFIG > MANAGEMENT > TELNET ACCESS > ACTIVE SESSIONS

Provides a list of all Telnet sessions currently active on the Total Access 850 system.

#

Displays the index number of the Telnet user.

NAME

Displays the text string entered in the Telnet configuration for this user.

PORT

Displays the TCP port used for this Telnet session.

TIME TO LIVE

Displays the amount of time (in minutes) before this Telnet session is terminated by the Total Access 850.

SYSTEM CONFIG > MANAGEMENT > TELNET ACCESS > IP ACCESS LIST

Set up the list of allowed Telnet managers.

NETWORK ADDRESS

Enter network addresses from which Telnet access to the unit is allowed. When a remote unit requests Telnet access to the unit, if the access list is empty or the remote's IP address matches a list entry, remote access is granted. A network address of 0.0.0.0 with corresponding netmask 255.255.255.255 blocks all host Telnet access.

The factory default is **0.0.0.0**. (with a 0.0.0.0 subnet mask), which allows all users Telnet IP access.

MASK

Enter a subnet mask corresponding to the entered network address. When a remote unit requests Telnet access to the unit, if the access list is empty or the remote's IP address matches a list entry, remote access is granted. A subnet mask of 0.0.0.0 will allow any host Telnet access, regardless of the network address. A network address of 0.0.0.0 with corresponding netmask 255.255.255.255 blocks all host Telnet access.

The factory default is **0.0.0.0**. for both parameters, which allows all users Telnet IP access.

SYSTEM CONFIG > MANAGEMENT > SNMP MANAGEMENT

Active the SNMP management and configure the SNMP communities and traps from this menu.

SYSTEM CONFIG > MANAGEMENT > SNMP MANAGEMENT > ACCESS

When set to **OFF**, SNMP access is denied. When set to **ON**, the unit will respond to SNMP managers based on the configuration. The factory default is **ON**.

SYSTEM CONFIG > MANAGEMENT > SNMP MANAGEMENT > TRAP DELAY

When enabled, the Total Access 850 inserts a delay before transmitting a created trap for the SNMP session.

SYSTEM CONFIG > MANAGEMENT > SNMP MANAGEMENT > COMMUNITIES

Set up the SNMP communities parameters from this menu.

#

Displays the index number of the SNMP Communities.
This list is used to set up to 8 SNMP communities that the unit will allow.

NAME

This is the text string used to identify the SNMP community. The factory default is no entry in the name parameter.

PRIVILEGE

The access for this manager can be assigned three levels. The factory default is **NONE**.

NONE	No access is allowed for this community or manager.
GET	Manager can only read items.
GET/SET	Manager can read and set items.

MANAGER IP

This may be used in conjunction with the Netmask field to define a range of manager IPs. A netmask of 255.255.255.255 defines a single IP as the manager host IP. The default value is **0.0.0.0**.

NETMASK

The mask is used to determine which bits of the **MANAGER IP** are significant. A "0" bit means "don't care." A "1" bit means that the corresponding address bits in the incoming SNMP packet must match the address bit in the defined **MANAGER IP**. The netmask of 255.255.255.255 defines a single IP as the manager host IP. The default value is **0.0.0.0**.

SYSTEM CONFIG > MANAGEMENT > SNMP MANAGEMENT > TRAPS

Sets up the trap manager name and IP from this menu.

#

Displays the index number in the SNMP traps table.
This list allows up to 20 managers to be listed to receive traps.

MANAGER NAME is the text string describing the name of the entry. It is intended for easy reference and has no bearing on the SNMP trap function. You can enter up to 31 characters in this field. The factory default is no entry in the manager name field.

MANAGER IP

This is the IP address of the manager that is to receive the traps. The factory default is **0.0.0.0**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT

Enables the FDL management and configures mode and IP addresses from this menu.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > MODE

This enables the FDL (only in ESF mode) to be used for management. Learning mode can also be enabled so the unit can "learn" its IP configuration to be used for its FDL management. Once it learns this information from, for example a Total Access 4303, the configuration items populate. The factory default is **ON**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > LINK IP ADDRESS

This is the local IP address used for FDL management. The FDL uses a separate IP network for communication, distinct from the customer data that is configured under the **ROUTER** menus. The factory default is **0.0.0.0**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > IP NETMASK

This is the subnet mask defining the IP network used for FDL management. The factory default is **0.0.0.0**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > FAR-END IP ADDRESS

This is the far-end IP address used for the FDL management. The FDL is a separate IP network from the customer data that is configured under the **ROUTER** menus. The factory default is **0.0.0.0**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > LEARN ADDRESS

When set to **ON**, the destination address on each received packet is assumed to be the FDL interface address. A 255.255.255.254 netmask is used, which determines the far-side address as well (since there can be only two addresses on a subnet with that netmask). When set to **OFF**, the user must input the IP address assigned to the FDL interface. Default is **ON**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > ACCEPT ALL SNMP

When set to **ON**, SNMP gets/sets received over the FDL link are always accepted regardless of the community table. When set to **OFF**, the community table is searched for valid manager IP addresses and the SNMP traffic is rejected if a match is not found. Default is **ON**.

SYSTEM CONFIG > MANAGEMENT > FDL MANAGEMENT > MTU

(Maximum Transmit Unit) Defines the largest packet size sent over the FDL. All packets greater in size than the MTU are fragmented.

SYSTEM CONFIG > SYSLOG

Configure the unit Syslog client for use with a Syslog server (supplied with ADTRAN Utilities or available on most Unix platforms) from this menu.



For additional information, reference RFC3164: The BSD Syslog Protocol.

SYSTEM CONFIG > SYSLOG > SYSLOG IP

IP address of the syslog daemon to which log message should be sent. The values must be dotted decimal notation.

SYSTEM CONFIG > SYSLOG > SYSLOG FORMAT

The **SYSLOG FORMAT** is the format of log messages. "**ADTRAN**" uses a format that is compatible with ADTRAN Utilities and forces the Syslog Facility to LOCAL0. **UNIX** uses the traditional Unix format and reports at the configured facility level.



ADTRAN Utilities may malfunction if messages are received in the Unix format.

SYSTEM CONFIG > SYSLOG > SYSLOG FACILITY

The choices are: **LOCAL0**, **LOCAL1**, **LOCAL2**, **LOCAL3**, **LOCAL4**, **LOCAL5**, **LOCAL6**, **LOCAL7**. **SYSLOG FACILITY** is the facility level for all messages forwarded from the unit to the syslog server. This allows all messages received from the IAD to be filtered by facility level. See *RFC3164: The BSD Syslog Protocol*.



*This does not have to correspond to the facility level shown in the terminal mode option. See **SYSLOG** using Terminal Mode on page 83.*

The remaining Syslog parameters have the following level choices:

- FATAL (Highest priority)
- ALERT
- CRITICAL
- ERROR
- WARNING
- NOTICE
- INFO
- DEBUG (Lowest priority)

Every log message generated by the IAD has a reporting level priority. If the message priority is lower than the configured priority for the destination log, the message is not forwarded to the syslog daemon. See *RFC3164: The BSD Syslog Protocol*. The lower the log level, the more messages that will be generated. Setting reporting levels to DEBUG may negatively affect the performance of the IAD, including causing the IAD to reset.



*ADTRAN recommends using **DEBUG** for only short periods of time, and for debug purposes only.*

SYSLOG using Terminal Mode

Another option for configuring syslog is using the terminal mode command **log dump <logname>**. The logname must be all CAPS and be one of the following names:

- FATAL
- ALERT
- CRITICAL
- ERROR
- WARNING
- NOTICE
- INFO
- FILTER
- DEBUG

The command will dump all messages for the indicated log (**ALL LEVEL** shows all log messages) stored in the internal log buffer to the command line display.

SYSTEM CONFIG > SYSLOG > ALL LEVEL

This entry allows setting the default reporting level for all log entries. If **ALL LEVEL** is a lower priority than the individual log entry level, **ALL LEVEL** overrides the individual log reporting level.

SYSTEM CONFIG > SYSLOG > KERNEL LEVEL

Minimum required level for sending KERNEL log messages.

SYSTEM CONFIG > SYSLOG > DHCP LEVEL

Minimum required level for sending DHCP log messages.

SYSTEM CONFIG > SYSLOG > NTP LEVEL

Minimum required level for sending NTP log messages.

SYSTEM CONFIG > SYSLOG > TFTP LEVEL

Minimum required level for sending TFTP log messages.

SYSTEM CONFIG > SYSLOG > TELNET LEVEL

Minimum required level for sending TELNET log messages.

SYSTEM CONFIG > SYSLOG > IP LEVEL

Minimum required level for sending IP log messages.

SYSTEM CONFIG > SYSLOG > PPP LEVEL

Minimum required level for sending PPP log messages.

SYSTEM CONFIG > SYSLOG > NAT LEVEL

Minimum required level for sending NAT log messages.

SYSTEM CONFIG > SYSLOG > ARP LEVEL

Minimum required level for sending ARP log messages.

SYSTEM CONFIG > SYSLOG > UDP LEVEL

Minimum required level for sending UDP log messages.

SYSTEM CONFIG > SYSLOG > NETWRITE LEVEL

This parameter is for ADTRAN internal use only.

SYSTEM CONFIG > SYSLOG > TCP LEVEL

Minimum required level for sending TCP log messages.

SYSTEM CONFIG > SYSLOG > COMPSYS LEVEL

This parameter is for ADTRAN internal use only.

SYSTEM CONFIG > SYSLOG > CONSOLE LEVEL

This parameter is for ADTRAN internal use only.

SYSTEM CONFIG > SYSLOG > CFGXFER LEVEL

Minimum required level for sending configuration transfer log messages.

SYSTEM CONFIG > SYSLOG > ROUTER LEVEL

Minimum required level for sending router log messages.

SYSTEM CONFIG > SYSLOG > NONVOL LEVEL

Minimum required level for sending nonvolatile memory log messages.

SYSTEM CONFIG > SYSLOG > NOKIA LEVEL

Minimum required level for sending log messages about communication with the Nokia DSLAM. Messages are only generated for products with an SDSL WAN interface.

SYSTEM CONFIG > SYSLOG > AUTOBAUD LEVEL

Minimum required level for sending log messages about communication with the Lucent Stinger DSLAM. Messages are only generated for products with an SDSL WAN interface.

SYSTEM CONFIG > SYSLOG > TOLLBRG LEVEL

Minimum required level for sending log messages about communication with the Tollbridge Voice Gateway. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > CMCP LEVEL

Minimum required level for sending log messages about communication with the CopperMountain DSLAM. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > SDSL LEVEL

This parameter is for ADTRAN internal use only.

SYSTEM CONFIG > SYSLOG > L1 LEVEL

Minimum required level for sending log messages about WAN physical or Layer 1 connection.

SYSTEM CONFIG > SYSLOG > ETH LEVEL

Minimum required level for sending log messages about Ethernet physical connection.

SYSTEM CONFIG > SYSLOG > ICMP LEVEL

Minimum required level for sending ICMP log messages.

SYSTEM CONFIG > SYSLOG > CONFIG LEVEL

This parameter is for ADTRAN internal use only.

SYSTEM CONFIG > SYSLOG > DSO LEVEL

Minimum required level for sending log messages about DSO mapping.

SYSTEM CONFIG > SYSLOG > SELFTEST LEVEL

Minimum required level for sending log messages about selftest.

SYSTEM CONFIG > SYSLOG > VOICE LEVEL

Minimum required level for sending log messages about AAL2 voices services. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > JETSTREAM LEVEL

Minimum required level for sending log messages about communication with the JetStream Voice Gateway. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > POTS LEVEL

Minimum required level for sending log messages about POTS line cards and services.

SYSTEM CONFIG > SYSLOG > LESCAS LEVEL

Minimum required level for sending messages about communication with LESCAS compatible Voice Gateways. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > ATM LEVEL

Minimum required level for sending ATM log messages. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > COPPERCOM LEVEL

Minimum required level for sending log messages about communication with the CopperCom Voice Gateway. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > VOFR LEVEL

Minimum required level for sending voice-over-frame-relay log messages about communication with the CopperMountain DSLAM. Messages are only generated for ATM products.

SYSTEM CONFIG > SYSLOG > XMODEM LEVEL

Minimum required level for sending XMODEM log messages for firmware and configuration transfers.

SYSTEM CONFIG > SYSLOG > EMWEB LEVEL

This parameter is for ADTRAN internal use only.

SYSTEM CONFIG > SYSLOG > FRELAY LEVEL

Minimum required level for sending frame relay log messages.

SYSTEM CONFIG > SYSLOG > BRIDGE LEVEL

Minimum required level for sending bridge mode log messages.

SYSTEM CONFIG > SYSLOG > MAINT LEVEL

Minimum required level for sending **CRAFT** port log messages.

SYSTEM CONFIG > SYSLOG > HDLC LEVEL

Minimum required level for sending low level HDLC log messages.

SYSTEM CONFIG > SYSLOG > VOATM LEVEL

Minimum required level for sending Voice-over-ATM log messages.

SYSTEM CONFIG > SYSLOG > PPPOA LEVEL

Minimum required level for sending PPP-over-ATM log messages.

SYSTEM CONFIG > SYSLOG > FDL LEVEL

Minimum required level for sending FDL log messages.

SYSTEM CONFIG > NETWORK TIME

Activate the network time and configure the server type, time zone and various other network time parameters from this menu.

SYSTEM CONFIG > NETWORK TIME > SERVER TYPE

The unit time can be entered manually from the **SYSTEM INFO** menu, or the unit can receive time from an NTP/SNTP server. The **NETWORK TIME** menu includes all parameters relating to how the unit communicates with the time server.

The server type defines the port on which the unit will listen to receive timing information from the time server. The choices are **NT TIME** and **SNTP**. When set to **NT TIME**, the unit will receive time from an NT server running SNTP software on its TIME port. When set to **SNTP**, the unit will receive time directly from an SNTP server. The factory default is **SNTP**.

SYSTEM CONFIG > NETWORK TIME > ACTIVE

This network timing feature can be turned on and off. It determines whether the unit will request and receive time from a time server. The factory default is **No**.

SYSTEM CONFIG > NETWORK TIME > TIME ZONE

All time zones are based off of Greenwich Mean Time (GMT). The choices are listed below.

- GMT**
- GMT -5 (EASTERN)**
- GMT -6 (CENTRAL)**
- GMT -7 (MOUNTAIN)**
- GMT -8 (PACIFIC)**
- GMT -9 (ALASKA)**
- GMT -10 (HAWAII)**

The factory default is **GMT-6 (CENTRAL)**.

SYSTEM CONFIG > NETWORK TIME > ADJUST FOR DAYLIGHT SAVING

Since some areas of the world use Daylight Savings Time, the unit is designed to adjust the time on the first Sunday in April and the last Sunday in October accordingly if this option is turned on. The factory default is **YES**.

SYSTEM CONFIG > NETWORK TIME > HOST ADDRESS

This is the IP address of the time server that the unit will request and receive time from. The factory default is no entry in the host address field.

SYSTEM CONFIG > NETWORK TIME > REFRESH

This is the interval of time between each request the unit sends out to the time server. A smaller refresh time guarantees that the unit receives the correct time from the server and corrects possible errors more quickly. This may be more taxing on the machine. A range of refresh times is available for the user to decide which is best for their unit. Choices include **5 MINS, 10 MINS, 15 MINS, 20 MINS, 25 MINS, 30 MINS, 35 MINS, 40 MINS, 45 MINS, 50 MINS, 55 MINS, and 60 MINS**. The factory default is **60 MINS**.

SYSTEM UTILITY > UPGRADE FIRMWARE > TRANSFER STATUS

This appears when TFTP is used. It displays the status of the transfer as it happens. Any error or success message will be displayed here.

SYSTEM UTILITY > UPGRADE FIRMWARE > START TRANSFER

This activator is used when the configurable items in this menu are complete. This will initiate the transfer for either TFTP or XMODEM upgrades.



*Before using **START TRANSFER**, the unit should have a valid IP address, subnet mask, and default gateway (if required). See DLP-3, Setting IP Parameters for the Total Access 850, for more information.*

SYSTEM UTILITY > UPGRADE FIRMWARE > ABORT TRANSFER

Use this activator to cancel any TFTP transfer in progress.

SYSTEM UTILITY > CONFIG TRANSFER

Select the config transfer method and perform the transfer from this menu.

SYSTEM UTILITY > CONFIG TRANSFER > TRANSFER METHOD

Sends a file containing the unit configuration to a PC connected to the **CRAFT** port using XMODEM protocol or to a file on a TFTP server using the TFTP protocol.

CONFIG TRANSFER also lets you save the unit configuration as a backup file, so you can use the same configuration with multiple units. In addition, **CONFIG TRANSFER** can retrieve a configuration file from a TFTP server.

To support these transfers, ADTRAN delivers a TFTP program with the unit called TFTP Server. You can configure any PC running Microsoft Windows with this software, and store a configuration file.



*Before using **START TRANSFER**, the unit should have a valid IP address, subnet mask, and default gateway (if required). See DLP-3, Setting IP Parameters for the Total Access 850, for more information.*

Only one configuration transfer session (upload or download) can be active at a time. **XMODEM** and **TFTP** are supported.

SYSTEM UTILITY > CONFIG TRANSFER > TFTP SERVER IP ADDRESS

Specifies the IP address of the TFTP server. Get this number from your system administrator. If using the ADTRAN Utilities TFTP server, this number appears in the TFTP server status window. The factory default value is **0.0.0.0**.

SYSTEM UTILITY > CONFIG TRANSFER > TFTP SERVER FILENAME

Defines the name of the configuration file that you transfer to or retrieve from the TFTP server. The default name is **ta_iad.cfg**, but you can edit this name.

SYSTEM UTILITY > CONFIG TRANSFER > CURRENT TRANSFER STATUS

Indicates the current status of the update.

SYSTEM UTILITY > CONFIG TRANSFER > PREVIOUS TRANSFER STATUS

Indicates the status of the previous update.

SYSTEM UTILITY > CONFIG TRANSFER > LOAD AND USE CONFIG

Retrieves the configuration file specified in the **TFTP SERVER FILENAME** field from the server. To start this command, enter **Y** to begin or enter **N** to cancel.



If you execute this command, the unit retrieves the configuration file, reboots, then restarts using the new configuration.

SYSTEM UTILITY > CONFIG TRANSFER > SAVE CONFIG REMOTELY

Saves the configuration file specified in **TFTP SERVER FILENAME** to the server identified in **TFTP SERVER IP ADDRESS**. To start this command, enter **Y** to begin or enter **N** to cancel.



*Before using this command, you must have identified a valid TFTP server in **TFTP SERVER IP ADDRESS**.*

SYSTEM UTILITY > SYSTEM UTILIZATION

View the CPU utilization stats from this menu.

SYSTEM UTILITY > SYSTEM UTILIZATION > PERFORMANCE

Clear the system utilization stats and view the total and current CPU utilization stats from this menu.

SYSTEM UTILITY > SYSTEM UTILIZATION > PERFORMANCE > CPU UTILIZATION

Provides maximum CPU utilization percentages for the following intervals:

FROM POWER-UP	Max CPU utilization since the last Total Access 850 restart.
LAST SECOND	Max CPU utilization in the last second. This is the most current CPU utilization information.
FROM LAST CLEAR	Max CPU utilization since the last manual clear of the performance statistics using the CLEAR STATS command.

SYSTEM UTILITY > SYSTEM UTILIZATION > PERFORMANCE > CLEAR STATS

This activator will clear all the system utilization performance stats.

SYSTEM UTILITY > PING

Activate the ping test and define the ping packet characteristics from this menu.

SYSTEM UTILITY > PING > START/STOP

Activator to start and cancel a ping test.



Only one ping session can be active at a time.



*Diagnostic features such as ping, extended ping, traceroute, extended traceroute, and Telnet client can also be performed via **TERMINAL MODE** (see page 92).*

SYSTEM UTILITY > PING > HOST ADDRESS

IP address or domain name (if DNS is configured) of device to receive the ping. The factory default is no entry in the host address field.

SYSTEM UTILITY > PING > SIZE (40-1500)

Total size of the ping to send. Range is **40** to **1500** bytes. The default is **64**.

SYSTEM UTILITY > PING > # OF PACKETS

Total packets to send every 2 seconds. Setting this to **0** allows the client to ping continuously. The default is **5**.

SYSTEM UTILITY > PING > # TRANSMITS

Total packets sent (read only).

SYSTEM UTILITY > PING > # RECEIVES

Total packets received (read only).

SYSTEM UTILITY > PING > % LOSS

Percentage loss based on ping returned from host (read only).

SYSTEM UTILITY > TRACEROUTE

Utility program used to trace a data path to a final destination.

SYSTEM UTILITY > TRACEROUTE > TRACE TARGET

Specifies the IP address of the remote system to trace the routes to.

SYSTEM UTILITY > TRACEROUTE > MAXIMUM HOPS

Specifies the maximum number of router exchanges allowed when traveling to the final destination (specified using the **TRACE TARGET** field) Range is **1** to **30**. Default is **30**.

SYSTEM UTILITY > TRACEROUTE > TIMEOUT (IN SECS)

Specifies the maximum delay (in milliseconds) given to a host (along a path to the final destination) to respond to the probe datagram sent before considering the packet a failure.

SYSTEM UTILITY > TRACEROUTE > RETRIES

Specifies the number of times the probe datagram is sent to each host (along the path to the final destination).

SYSTEM UTILITY > TRACEROUTE > BEGIN TRACEROUTE

Activates the traceroute process by sending a probe datagram with a Time To Live (TTL) value of 1.

SYSTEM UTILITY > RESET UNIT

Selecting this activator will power reset the unit.

SYSTEM UTILITY > TERMINAL MODE

Selecting the terminal mode gives the user a command-line prompt to perform utilities such as pings, traceroutes, resets, firmware updates, configuration, and more. **TERMINAL MODE** can also be accessed by using the shortcut keys <CNTRL+T> from other menu screens. From this command-line prompt, you can:

- Perform a reset with the command "reset"
- Perform a **complete** factory restore with the command "factory_reset"
- Configure the unit. The unit has the ability to download a text file which contains the configuration of the entire unit. This configuration may then be altered in a text editor, and then uploaded to a unit. (See DLP-13, *Saving and Loading Text Configuration using Terminal Command Line*, for further assistance.)
- Debug and troubleshoot. This function would be carried out with the assistance of ADTRAN Technical Support.
- Start and stop the fail-safe timer for the auto-config feature.
- Perform a firmware upgrade via TFTP.

upgrade_firmware *hostname filename*

- Use the **save** command to write the entire configuration to flash.
- Display the unit's MAC address with the command **mac**.
- Perform a ping or extended ping. Syntax is:
ping hostname/address [repeat xx] [size xx] [timeout xx] [source xx] [noNat]

Options:

repeat <repeat count>	Number of pings to send (default 5)
size (datagram size)	Range is 40-1500

timeout (seconds)	Timeout in seconds (range 1-10)
source (address or name)	Source address or interface name to use
noNat	Do not NAT the ping packet

Options may be entered in any order and may be truncated.

Valid interface names are eth0, fdl0, ppp0, fr0, fr1, etc.

Example usage: **ping 10.0.0.5 r si 1500 so eth0 n**

This will ping with a repeat count of 10. The datagram size is 1500 bytes, and the source address used in the ping packet will be the Ethernet IP address. The “noNat” option has been specified, so if NAT is enabled, this packet will NOT be translated.

- Perform a traceroute or extended traceroute. Syntax is:

traceroute hostname/address [hops xx] [timeout xx] [retries xx] [source xx] [noNat]

Options:

hops <hops count>	Max number of hops (default 30)
timeout <seconds>	Timeout in seconds (default 3)
retries <seconds>	Number of retries per hop (default 3)
source <address or name>	Source address or interface name to use
noNat	Do not NAT the trace packets

Options may be entered in any order and may be truncated.

Valid interface names are eth0, fdl0, ppp0, fr0, fr1, etc.

Example usage: **trace 10.0.0.5 h 20 t 1 r 1 so eth0**

This will perform a trace to 10.0.0.5 with a max hop count of 20. The timeout for each hop is 1 second, and the retry count per hop is 1. The Ethernet IP will be used as the source address, and the packet WILL go through NAT if NAT is enabled, meaning that the packet will be translated and the source address will be replaced by the NAT address.

- Use the Telnet client feature to Telnet to a remote host. Syntax is:

Telnet hostname/address [port xx]

Default port is 23 (TELNET).

- To exit terminal mode, type **exit** or **!exit**,

exit - if any configuration have been made, you will be prompted whether or not to save these changes. If no changes were made, the terminal session will exit without the confirm message.

!exit - exit without saving or applying any configuration changes.



Extended ping, extended traceroute, and Telnet client are new features initially available in A.04.02. These functions may be performed simultaneously from multiple user sessions.

INTERFACES

Use the **INTERFACES** menu to view and configure parameters for the **T1**, **ETHERNET**, **V.35**, **FXS**, **FXO**, **DSX-1 MODULE**, and **UBR1TE** interfaces as shown in Figure 6.




Figure 6. Interfaces Menus

INTERFACES (NETWORK T1)

View the network T1 interface status and configure T1 parameters from this menu.

INTERFACES (T1) > CONFIG

Configure the various T1 parameters and enable/disable loopbacks from this menu.

INTERFACES (T1) > CONFIG > TIMING MODE

Choices are **NETWORK** and **INTERNAL**. Select **NETWORK** when the unit will receive timing from the network. Select **INTERNAL** when the unit will generate the timing. Default is **NETWORK**.

INTERFACES (T1) > CONFIG > FORMAT

This sets the frame format for the T1 interface. The setting must match the frame format of the circuit to which the interface is connected. Choices are **ESF** or **SF** (D4). Extended Superframe (**ESF**) provides a non-disruptive means of full-time monitoring on the facility datalink (FDL). Default is **ESF**.

INTERFACES (T1) > CONFIG > LINE CODE

This sets the line code for the T1 interface. The setting must match the line code of the circuit to which the interface is connected. Choices are **B8ZS** (bipolar with 8-zero substitution) and **AMI** (alternate mark inversion). Default is **B8ZS**.

INTERFACES (T1) > CONFIG > EQUALIZATION

Select the line build out for the T1 interface. These are attenuation settings. 0 dB is the strongest signal, and the other settings make the T1 transmit signal weaker. The setting of this field depends on whether the circuit is provisioned for DS1 by the telephone company. The choices are **0 dB**, **-7.5 dB**, **-15 dB**, **-22 dB**. Default is **0 dB**.

INTERFACES (T1) > CONFIG > CSU LPBK

Choices are **ENABLE**, **DISABLE**, and **DISABLE ALL**. Default is **ENABLE**. This allows the unit to either respond or not respond to CSU loop up commands.

INTERFACES (T1) > CONFIG > RX SENSITIVITY

Configures the sensitivity of the T1 receiver for this interface to provide increased sensitivity for long-run T1 applications. Choices are **AUTO**, **-36 dB**, and **-10 dB**.

INTERFACES (T1) > STATUS

Displays the T1 status including performance data and alarm histories.

INTERFACES (T1) > STATUS > PERFORMANCE

Displays the T1 performance data.

INTERFACES (T1) > STATUS > PERFORMANCE > CURRENT AND TOTALS

Provides current (15-minute window) status on key performance measures as specified in ANSI T1.403 and AT&T TR 54016 for each of the T1 ports as well as historical statistical totals.

INTERFACES (T1) > STATUS > PERFORMANCE > CURRENT AND TOTALS > INTERVAL

Identifies the interval (**CURRENT** or **TOTAL**) for the listed performance statistics.

INTERFACES (T1) > STATUS > PERFORMANCE > CURRENT AND TOTALS > ES

ES (Errored Second) - For ESF mode, an errored second is defined as a second with one or more Path Code Violations (PCVs), or one or more Out of Frame (OOF) defects, or one or more Controlled Slip events, or a detected AIS (blue alarm) defect. For D4 (SF) mode, the presence of Bipolar Violations (BPVs) also triggers an errored second.

INTERFACES (T1) > STATUS > PERFORMANCE > CURRENT AND TOTALS > SES

SES (Severely Errored Second) - For ESF mode, an **SES** is a second with 320 or more PCVs, or one or more OOF defects, or a detected AIS defect. For D4 (SF) mode, an **SES** is a second with one or more Framing Error events, or an OOF defect, or at least 1544 Line Code Violations or more.

INTERFACES (T1) > STATUS > PERFORMANCE > CURRENT AND TOTALS > SEF

SEF (Severely Errored Frame) - An **SEF** condition occurs when 2 out of 6 consecutive frame bits are in error.

INTERFACES (T1) > STATUS > PERFORMANCE > CURRENT AND TOTALS > FS

FS (Frame Slip) - A frame slip is defined as one or more frame bit errors in a one-second interval.

INTERFACES (T1) > STATUS > PERFORMANCE > CURRENT AND TOTALS > LCV

LCV (Line Code Violation) - A Line Code Violation is defined as a Bipolar Violation (BPV), not including the B8ZS code word if B8ZS is employed. The number displayed is **LCV** events, which is defined as one or more BPVs in a one-second interval.

INTERFACES (T1) > STATUS > PERFORMANCE > CURRENT AND TOTALS > SLP

SLP (Slip Error Event) - This occurs when a received frame is either repeated or deleted. A **SLP** error indicates a timing problem.

INTERFACES (T1) > STATUS > PERFORMANCE > CURRENT AND TOTALS > UAS

UAS (Unavailable Seconds) - When 10 consecutive **SESs** have been logged, the unit is declared in an unavailable state, the 10 **SESs** are cleared, and the Unavailable Seconds count begins to increment starting with 10. The unavailable state is cleared when 10 consecutive non-SES seconds have occurred.

INTERFACES (T1) > STATUS > PERFORMANCE > EXTENDED

Provides statistics for the last 24 hours (in 15 minute windows) on key performance measures as specified in ANSI T1.403 and AT&T TR 54016 for each of the T1 ports. Refer to the **CURRENT AND TOTALS** performance information for more details on listed statistics.

INTERFACES (T1) > STATUS > PERFORMANCE > CLEAR CURRENT DATA

Clears all statistics collected in the **CURRENT AND TOTALS** statistics table.

INTERFACES (T1) > STATUS > PERFORMANCE > CLEAR ALL DATA

Clears all statistics collected in the **CURRENT AND TOTALS** and the **EXTENDED** 24 hour statistics tables.

INTERFACES (T1) > STATUS > ALARMS

Displays current alarms and alarm history for T1 interface.

INTERFACES (T1) > STATUS > ALARMS > CURRENT ALARMS

Displays the current alarms on the T1 interface. An asterisk in a field indicates that an alarm is active.

LOS	Loss of Signal. No signal detected on port interface.
RED	Not able to frame data received on the port. Alternately referred to as Out of Frame (OOF).
YELLOW	Remote alarm indicator (RAI) being received on port.
BLUE	Receiving unframed all ones from the port alarm indicator signal (AIS).

INTERFACES (T1) > STATUS > ALARMS > ALARM HISTORY

Displays the alarm history for the T1 interface. An asterisk in a field indicates that an alarm has occurred on the T1 interface since the last clear history. Refer to *Interfaces (T1) > Status > Alarms > Current Alarms* on page 96 for more details on listed alarm conditions.

INTERFACES (T1) > STATUS > ALARMS > CLEAR HISTORY

Selecting this activator will clear the Alarm History for the T1 interface.

INTERFACES (T1) > STATUS > RX LEVEL

Displays the level (in dB) of the received T1 signal on the interface.

INTERFACES (T1) > TEST

These options are used to initiate local and remote loopback tests and display the test status.

INTERFACES (T1) > TEST > LOC LB

Loopback of the local unit. Choices are **NONE**, **LINE**, and **PAYLOAD**. **LINE** loopback loops all of the received data back toward the network. The transmitted data is the identical line code that was received, including any bipolar violations. **PAYLOAD** loopback is similar to line loopback except that the framing is extracted from the received data and then regenerated for the transmitted data. **NONE** disables the loopback test. Default is **NONE**.

INTERFACES (T1) > TEST > REM LB

Loopback of remote unit. Choices are **NONE**, **LINE**, and **PAYLOAD**. **LINE** loopback loops all of the received data back toward the network. The transmitted data is the identical line code that was received, including any bipolar violations. **PAYLOAD** loopback is similar to line loopback except that the framing is extracted from the received data and then regenerated for the transmitted data. **NONE** disables the loopback test. Default is **NONE**.

INTERFACES (T1) > TEST > TEST STATUS

Indicates whether a test is in progress.

INTERFACES (DSX)

View the integrated DSX interface status and configure T1 parameters from this menu.

INTERFACES (DSX) > CONFIG

Configure the various DSX parameters and enable/disable loopbacks from this menu.

INTERFACES (DSX) > CONFIG > FORMAT

This sets the frame format for the DSX interface. The setting must match the frame format of the circuit to which the interface is connected. Choices are **ESF**, **SF** (D4). Extended Superframe (**ESF**) provides a non-disruptive means of full-time monitoring on the facility datalink (FDL). Default is **ESF**.

INTERFACES (DSX) > CONFIG > LINE CODE

This sets the line code for the DSX interface. The setting must match the line code of the circuit to which the interface is connected. Choices are **B8ZS** (bipolar with 8-zero substitution) and **AMI** (alternate mark inversion). Default is **B8ZS**.

INTERFACES (DSX) > CONFIG > EQUALIZATION

Select the line build out for the DSX1 interface. The choices are **0 dB**, **266 FT**, **399 FT**, **533 FT**, **655 FT**, or **-7.5 dB**. Default is **0 dB**. The **7.5 dB** setting is provided for terminal equipment that has trouble recovering a full 0dB level signal (typically one with a DS1 long haul line interface).

INTERFACES (DSX) > CONFIG > CSU LPBK

Choices are **ENABLE**, **DISABLE**, and **DISABLE ALL**. Default is **ENABLE**. This allows the unit to either respond or not respond to CSU loop up commands.

INTERFACES (DSX) > CONFIG > RX SENSITIVITY

Configures the sensitivity of the T1 receiver for this interface to provide increased sensitivity for long-run T1 applications. Choices are **AUTO**, **-36 dB**, and **-10 dB**.

INTERFACES (DSX) > STATUS

Displays the T1 status including performance data and alarm histories.

INTERFACES (DSX) > STATUS > PERFORMANCE

Displays the T1 performance data.

INTERFACES (DSX) > STATUS > PERFORMANCE > CURRENT AND TOTALS

Provides current (15-minute window) status on key performance measures as specified in ANSI T1.403 and AT&T TR 54016 as well as historical statistical totals for the integrated DSX port.

INTERFACES (DSX) > STATUS > PERFORMANCE > CURRENT AND TOTALS > INTERVAL

Identifies the interval (**CURRENT** or **TOTAL**) for the listed performance statistics.

INTERFACES (DSX) > STATUS > PERFORMANCE > CURRENT AND TOTALS > ES

ES (Errored Second) - For ESF mode, an errored second is defined as a second with one or more Path Code Violations (PCVs), or one or more Out of Frame (OOF) defects, or one or more Controlled Slip events, or a detected AIS (blue alarm) defect. For D4 (SF) mode, the presence of Bipolar Violations (BPVs) also triggers an errored second.

INTERFACES (DSX) > STATUS > PERFORMANCE > CURRENT AND TOTALS > SES

SES (Severely Errored Second) - For ESF mode, an **SES** is a second with 320 or more PCVs, or one or more OOF defects, or a detected AIS defect. For D4 (SF) mode, an **SES** is a second with one or more Framing Error events, or an OOF defect, or at least 1544 Line Code Violations or more.

INTERFACES (DSX) > STATUS > PERFORMANCE > CURRENT AND TOTALS > SEF

SEF (Severely Errored Frame) - An **SEF** condition occurs when 2 out of 6 consecutive frame bits are in error.

INTERFACES (DSX) > STATUS > PERFORMANCE > CURRENT AND TOTALS > FS

FS (Frame Slip) - A frame slip is defined as one or more frame bit errors in a one-second interval.

INTERFACES (DSX) > STATUS > PERFORMANCE > CURRENT AND TOTALS > LCV

LCV (Line Code Violation) - A Line Code Violation is defined as a Bipolar Violation (BPV), not including the B8ZS code word if B8ZS is employed. The number displayed is **LCV** events, which is defined as one or more BPVs in a one-second interval.

INTERFACES (DSX) > STATUS > PERFORMANCE > CURRENT AND TOTALS > SLP

SLP (Slip Error Event) - This occurs when a received frame is either repeated or deleted. A **SLP** error indicates a timing problem.

INTERFACES (DSX) > STATUS > PERFORMANCE > CURRENT AND TOTALS > UAS

UAS (Unavailable Seconds) - When 10 consecutive **SES**s have been logged, the unit is declared in an unavailable state, the 10 **SES**s are cleared, and the Unavailable Seconds count begins to increment starting with 10. The unavailable state is cleared when 10 consecutive non-SES seconds have occurred.

INTERFACES (DSX) > STATUS > PERFORMANCE > EXTENDED

Provides statistics for the last 24 hours (in 15 minute windows) on key performance measures as specified in ANSI T1.403 and AT&T TR 54016 for each of the T1 ports. Refer to the **CURRENT AND TOTALS** performance information for more details on listed statistics.

INTERFACES (DSX) > STATUS > PERFORMANCE > CLEAR CURRENT DATA

Clears all statistics collected in the **CURRENT AND TOTALS** statistics table.

INTERFACES (DSX) > STATUS > PERFORMANCE > CLEAR ALL DATA

Clears all statistics collected in the **CURRENT AND TOTALS** and the **EXTENDED** 24 hour statistics tables.

INTERFACES (DSX) > STATUS > ALARMS

Displays current alarms and alarm history for the integrated DSX interface.

INTERFACES (DSX) > STATUS > ALARMS > CURRENT ALARMS

Displays the current alarms on the T1 interface. An asterisk in a field indicates that an alarm is active.

LOS	Loss of Signal. No signal detected on port interface.
RED	Not able to frame data received on the port. Alternately referred to as Out of Frame (OOF).
YELLOW	Remote alarm indicator (RAI) being received on port.
BLUE	Receiving unframed all ones from the port alarm indicator signal (AIS).

INTERFACES (DSX) > STATUS > ALARMS > ALARM HISTORY

Displays the alarm history for the T1 interface. An asterisk in a field indicates that an alarm has occurred on the T1 interface since the last clear history. Refer to *Interfaces (DSX) > Status > Alarms > Current Alarms* for more details on listed alarm conditions.

INTERFACES (DSX) > STATUS > ALARMS > CLEAR HISTORY

Selecting this activator will clear the Alarm History for the integrated DSX interface.

INTERFACES (DSX) > STATUS > RX LEVEL

Displays the level (in dB) of the received T1 signal on the interface.

INTERFACES (DSX) > TEST

These options are used to initiate local and remote loopback tests and display the test status.

INTERFACES (DSX) > TEST > LOC LB

Loopback of the local unit. Choices are **NONE**, **LINE**, and **PAYLOAD**. **LINE** loopback loops all of the received data back toward the network. The transmitted data is the identical line code that was received, including any bipolar violations. **PAYLOAD** loopback is similar to line loopback except that the framing is extracted from the received data and then regenerated for the transmitted data. **NONE** disables the loopback test. Default is **NONE**.

INTERFACES (DSX) > TEST > REM LB

Loopback of remote unit. Choices are **NONE**, **LINE**, and **PAYLOAD**. **LINE** loopback loops all of the received data back toward the network. The transmitted data is the identical line code that was received, including any bipolar violations. **PAYLOAD** loopback is similar to line loopback except that the framing is extracted from the received data and then regenerated for the transmitted data. **NONE** disables the loopback test. Default is **NONE**.

INTERFACES (DSX) > TEST > TEST STATUS

Indicates whether a test is in progress.

INTERFACES (ETH)

View the Ethernet interface status and configure the Ethernet parameters from this menu.

INTERFACES (ETH) > CONFIG

Configure the various Ethernet parameters from this menu.

INTERFACES (ETH) > CONFIG > AUTO NEGOTIATION

The Total Access 850 has the capability of auto negotiating the rate and duplex of the connected Ethernet link. Additionally, when this parameter is set to **OFF**, the rate and duplex are set manually. Auto Negotiation is only available when using a 3rd Generation RCU with the Total Access 850 system.

INTERFACES (ETH) > CONFIG > DATA RATE

Defines the Ethernet interface as **100BASET** or **10BASET**. Data Rate configuration is only available when using a 3rd Generation RCU with the Total Access 850 system.

INTERFACES (ETH) > CONFIG > DUPLEX TYPE

Defines operation on the Ethernet interface as **FULL DUPLEX** or **HALF DUPLEX**. Duplex Type configuration is only available when using a 3rd Generation RCU with the Total Access 850 system.

INTERFACES (ETH) > STATUS

Displays the Ethernet status information.

INTERFACES (ETH) > STATUS > MAC ADDRESS

(Read only) Displays the unique MAC address programmed at ADTRAN.

INTERFACES (ETH) > STATUS > DATA LINK

Displays the current status of the Ethernet link as either **UP** or **DOWN**. If there is an active Ethernet link, the status displays **UP**. Data Link status information is only available when using a 3rd Generation RCU with the Total Access 850 system.

INTERFACES (ETH) > STATUS > DATA RATE

Displays the Ethernet interface current rate of operation (as defined by the **DATA RATE** configuration parameter).

INTERFACES (ETH) > STATUS > DUPLEX TYPE

Displays the Ethernet interface current mode of operation (as defined by the **DUPLEX TYPE** configuration parameter). Duplex Type status information is only available when using a 3rd Generation RCU with the Total Access 850 system.

INTERFACES (V35)

View the V.35 interface status and configure the V.35 parameters from this menu.

INTERFACES (V35) > CONFIG

Configure the DTE leads from this menu.

INTERFACES (V35) > CONFIG > CTS

Sets the control characteristic of the clear-to-send lead. Choices are **NORMAL** (follows RTS) or **FORCE ON**. Default is **NORMAL**.

INTERFACES (V35) > CONFIG > DCD

Sets the control characteristic of the carrier detect lead. Choices are **NORMAL** (follows valid signal on the network interface) or **FORCE ON**. Default is **NORMAL**.

INTERFACES (V35) > CONFIG > DSR

Sets the control characteristic of the data set ready lead. Choices are **NORMAL** (follows DTR) or **FORCE ON**. Default is **NORMAL**.

INTERFACES (V35) > STATUS

View the status of the DTE leads from this menu.

INTERFACES (V35) > STATUS > RTS

View the status of Request to Send (RTS) lead. Possibilities are **OFF** or **ON**.

INTERFACES (V35) > STATUS > DTR

View the status of the Data Terminal Read (DTR) lead. Possibilities are **OFF** and **ON**.

INTERFACES (V35) > TEST

These options are used to loopback tests.

INTERFACES (V35) > TEST > LOOPBACK

Enables a local loopback of the V.35 interface. All data received on the V.35 interface is transmitted back out the interface.

INTERFACES (FXS)

View the FXS interface status and configure the FXS parameters from this menu.

INTERFACES (FXS) > CONFIG

Configure the FXS mode, line impedance and Tandem parameters from this menu.

INTERFACES (FXS) > CONFIG > SLOT

Displays the slot number associated with the installed FXS Module.

INTERFACES (FXS) > CONFIG > PORT

Indicates the port on which the FXS is installed.

INTERFACES (FXS) > CONFIG > MODE

Choices are given below. Default is **LOOP START**.



This mode must match the network configuration and/or how each port is being used. Each port on the FXS Module is independent and should be set accordingly.

LOOP START	Sets the port to use FXS loop start signaling on the T-span and loop start supervision on the analog 2-wire interface.
GROUND START	Sets the port to use FXS ground start signaling on the T-span and ground start supervision on the analog 2-wire interface.
TR08 SINGLE	Sets the port to use Single Party Channel Unit signaling on the T-span (as defined by TR-TSY-000008) and loop start supervision on the analog 2-wire interface.
TR08 UVG	Sets the port to use Universal Voice Grade signaling on the T-span (as defined by TR-TSY-000008) and either loop start or ground start supervision on the analog 2-wire interface.
DPO	Sets the port to use Dial Pulse signaling to originate dialed numbers.
TANDEM (E&M)	Sets the port to use E&M signaling on the T-span and either loop start or ground start supervision on the analog 2-wire interface. Both immediate and wink modes of E&M are supported. See the TANDEM submenus for more information.

INTERFACES (FXS) > CONFIG > Tx (dB)

Sets the TX direction level points. This signal will change the volume of the voice. TX (dB) is the signal that is transmitted out the T1, with 0 dB being the strongest. If the volume is too loud across the T1, this number should be increased. A higher number indicates more attenuation which equals lower volume. The value entered must be less than 10 dB. Default is **6.0 dB**.

INTERFACES (FXS) > CONFIG > Rx (dB)

Sets the RX direction level points. This signal will change the volume of the voice. A higher number indicates more attenuation which equals lower volume. The value entered must be less than 10 dB. Default is **3.0 dB**. The maximum signal is **0.0 dB**.

INTERFACES (FXS) > CONFIG > SVC MODE

Indicates whether the module is **IN SERVICE** or **OUT OF SVC**. This does not indicate whether the port has been mapped. For proper operation, the port must be mapped using the **DS0 MAPS** menu. Default is **IN SERVICE**.

INTERFACES (FXS) > CONFIG > LINE Z

Sets the line impedance. Choices are **600 OHMS**, **900 OHMS**, **600 OHMS + 2.16 μ F**, **900 OHMS + 2.16 μ F**, and **AUTO**. The line impedance of each port is based on the size of the network. Default is **600 OHMS**.

INTERFACES (FXS) > CONFIG > MSG IND

This is better referred to as On-Hook Message Waiting. When this is set to **ENABLE**, talk path is always open, even in On-Hook conditions, in order for these FSK message tones to pass through. Default is **DISABLE**. Enabling on-hook message waiting will allow message lamp usage but will cause a lower on-hook voltage. Disabling this feature will allow higher on-hook voltage but will not allow on-hook messaging other than caller ID.

INTERFACES (FXS) > CONFIG > TANDEM

Sets the port to use E&M signaling on the T-Span and either loop start or ground start supervision on the analog 2-wire interface. To access submenus for this item, use the arrow keys to scroll to the **TANDEM** column for the corresponding module, and then press **<ENTER>**.

INTERFACES (FXS) > CONFIG > TANDEM > CONVERSION MODE

Sets the port to either **LOOP START** or **GROUND START** mode. Default is **LOOP START**.

INTERFACES (FXS) > CONFIG > TANDEM > SUPERVISION

Sets the supervision method used to either **IMMEDIATE** or **WINK**. Default is **IMMEDIATE**.

INTERFACES (FXS) > CONFIG > TANDEM > DIAL TONE

Used to enable or disable the on-board dial tone generation. Dial Tone is supplied for 5 sec; then it drops. It cannot be broken when dialing digits. Default is **DISABLE**.

INTERFACES (FXS) > CONFIG > TANDEM > RING BACK

Used to enable or disable the option of generating ring back tone towards the T-span. Default is **DISABLE**.

INTERFACES (FXS) > CONFIG > TANDEM ANSWER SUPERVISION

Causes the polarity of tip and ring to be reversed when the far-end answers. Can be enabled or disabled. Default is **DISABLE**.

INTERFACES (FXS) > CONFIG > TANDEM > DNIS OPTIONS

This parameter is used in conjunction with **DNIS DELAY**. Choices are **DISABLE**, **ENABLE**, and **ENABLE W/ NO ANSWER WINK**. Default is **DISABLE**.

INTERFACES (FXS) > CONFIG > TANDEM > DNIS DELAY

Sets the amount of time the voice module waits after it receives a wink before forwarding a DNIS digit if **DNIS OPTIONS** is set to **ENABLE**. Choices are **0.5 SEC**, **1.0 SEC**, **2.0 SEC**, **2.5 SEC**, **3.0 SEC**, and **5.0 SEC**. Default is **3.0 SEC**.

INTERFACES (FXS) > CONFIG > TANDEM > FWD DISC DELAY

In Tandem mode, **FWD DISC DELAY** defines the time battery is actually removed/reversed once the forward disconnect is received. Choices are **250 MSEC**, **500 MSEC**, **750 MSEC**, **1 SEC**, and **2 SEC**. Default is **1 SEC**.

INTERFACES (FXS) > CONFIG > TANDEM > FWD DISC BATTERY

In Tandem mode, selects whether battery is to be removed or reversed during forward disconnect. Choices are **REMOVE** and **REVERSE**. Default is **REMOVE**.

INTERFACES (FXS) > STATUS

Displays the status of the FXS signal bits.

INTERFACES (FXS) > STATUS > SLOT

Displays the slot number associated with the installed FXS Module.

INTERFACES (FXS) > STATUS > PORT

Displays the port number.

INTERFACES (FXS) > STATUS > TA SIG

This parameter displays the status of the Transmit A signal bit. The high/low status is indicated by a 0 or 1.

INTERFACES (FXS) > STATUS > TB SIG

This parameter displays the status of the Transmit B signal bit. The high/low status is indicated by a 0 or 1.

INTERFACES (FXS) > STATUS > RA SIG

This parameter displays the status of the Receive A signal bit. The high/low status is indicated by a 0 or 1.

INTERFACES (FXS) > STATUS > RB SIG

This parameter displays the status of the Receive B signal bit. The high/low status is indicated by a 0 or 1.

INTERFACES (FXS) > TEST

Activate tests and monitor test status on a per port basis from this menu.

INTERFACES (FXS) > TEST > SLOT

Displays the slot number for the installed FXS Module.

INTERFACES (FXS) > TEST > PORT

Displays the port number.

INTERFACES (FXS) > TEST > TEST

Choices are given below. Default is **NONE**.

NONE	Indicates that no test is currently active.
DIGITAL NETWORK LPBK	Used to loop back DS0 data coming from the network for each channel. Received data is latched in on the appropriate receive time slot on the receive bus. This data is then placed on the transmit bus in the unit's transmit time slot.
NETWORK ON HOOK TEST	Used to test signaling sent to the network by the unit. On-hook signaling is sent to the network. The customer loop is forced on-hook while this test is active.
NETWORK OFF HOOK TEST	Used to test signaling sent to the network by the unit. Off-hook signaling is sent to the network. The customer loop is forced off-hook while this test is active.
1 KHZ TONE-NEAR END	For Near End, the 2-wire side sends out a 1 kHz tone to verify talk path.
1 KHZ TONE-FAR END	For Far End, the tone side is sent out across the Network and can be heard if monitoring on the T1 as well as off of the Far End 2-wire side. This verifies talk path.
CUSTOMER RING TEST	The customer ring test will activate the unit's ring relay in a 2-on /4-off cadence, providing ringing to the customer loop.

INTERFACES (FXS) > TEST > TEST STATUS

This option indicates whether a test is in progress.

INTERFACES (FXO)

View the FXO interface status and configure the FXO parameters from this menu.

INTERFACES (FXO) > CONFIG

Configure the FXO mode, line impedance, and Tandem parameters from this menu.

INTERFACES (FXO) > CONFIG > SLOT

Displays the slot number of the installed FXO Module.

INTERFACES (FXO) > CONFIG > PORT

Indicates the port on which the FXO is installed.

INTERFACES (FXO) > CONFIG > MODE

Choices are given below. Default is **LOOP START**.



This mode must match the network configuration and/or how each port is being used. Each port on the FXO Module is independent and should be set accordingly.

LOOP START	Sets the port to use FXO loop start signaling on the T-span and loop start supervision on the analog 2-wire interface.
GROUND START	Sets the port to use FXO ground start signaling on the T-span and ground start supervision on the analog 2-wire interface.
DPT	Sets the port to use Dial Pulse Terminate signaling for outbound calls.
MODIFIED DPT	Sets the port to use DPT signaling on the interface. In DPT mode, digits are transmitted out the FXO interface to the user equipment. DPT mode is one-way operation only (outbound calls only).

INTERFACES (FXO) > CONFIG > Tx (dB)

Sets the TX direction level points. This signal will change the volume of the voice. TX (dB) is the signal that is transmitted out the T1, with 0 dB being the strongest. If the volume is too loud across the T1, this number should be increased. A higher number indicates more attenuation which equals lower volume. The value entered must be less than 10 dB. Default is **0.0 dB**.

INTERFACES (FXO) > CONFIG > Rx (dB)

Sets the RX direction level points. This signal will change the volume of the voice. A higher number indicates more attenuation which equals lower volume. The value entered must be less than 10 dB. Default is **0.0 dB**.

INTERFACES (FXO) > CONFIG > SVC MODE

Indicates whether the module is **IN SERVICE** or **OUT OF SVC**. This does not indicate whether the port has been mapped. For proper operation, the port must be mapped using the **DS0 MAPS** menu. Default is **IN SERVICE**.

INTERFACES (FXO) > STATUS

Displays the status of the FXO signal bits.

INTERFACES (FXO) > STATUS > SLOT

Displays the slot number for the installed FXO Module.

INTERFACES (FXO) > STATUS > PORT

Displays the port number.

INTERFACES (FXO) > STATUS > TA SIG

This parameter displays the status of the Transmit A signal bit. The high/low status is indicated by a 0 or 1.

INTERFACES (FXO) > STATUS > TB SIG

This parameter displays the status of the Transmit B signal bit. The high/low status is indicated by a 0 or 1.

INTERFACES (FXO) > STATUS > RA SIG

This parameter displays the status of the Receive A signal bit. The high/low status is indicated by a 0 or 1.

INTERFACES (FXO) > STATUS > RB SIG

This parameter displays the status of the Receive B signal bit. The high/low status is indicated by a 0 or 1.

INTERFACES (FXO) > TEST

Activate tests and monitor test status on a per port basis from this menu.

INTERFACES (FXO) > TEST > SLOT

Displays the slot number for the installed FXO Module.

INTERFACES (FXO) > TEST > PORT

Displays the port number.

INTERFACES (FXO) > TEST > TEST

Choices are given below. Default is **NONE**.

NONE	Indicates that no test is currently active.
DIGITAL NETWORK LPBK	Used to loop back DS0 data coming from the network for each channel. Received data is latched in on the appropriate receive time slot on the receive bus. This data is then placed on the transmit bus in the unit's transmit time slot.
NETWORK ON HOOK TEST	Used to test signaling sent to the network by the unit. On-hook signaling is sent to the network. The customer loop is forced on-hook while this test is active.
NETWORK OFF HOOK TEST	Used to test signaling sent to the network by the unit. Off-hook signaling is sent to the network. The customer loop is forced off-hook while this test is active.
1004 HZ - 0DCBM0 TONE GEN	Used to verify talk path by sending out 1004 Hz tone to test across the network. Monitoring of the T1 as well as the Far-End 2-wire side verifies the talk path if the tone is heard.

INTERFACES (FXO) > TEST > TEST STATUS

This option indicates whether a test is in progress.

INTERFACES (DSX-1 MODULE)

View the DSX-1 Module interface status and configure the DSX-1 Module parameters from this menu.

INTERFACES (DSX-1) > CONFIG

Configures the DSX-1 interface format and code from this menu.

INTERFACE (DSX-1) > CONFIG > SLOT

Indicates the slot in which the DSX-1 Module is installed.

INTERFACE (DSX-1) > CONFIG > PORT

Indicates the port on which the DXS is installed.

INTERFACE (DSX-1) > CONFIG > FORMAT

This setting must match the frame format of the circuit to which the interface is connected. Choices are **ESF** and **SF** (D4). Extended Superframe (ESF) provides a non-disruptive means of full-time monitoring on the facility data link (FDL). The default is **ESF**.

INTERFACE (DSX-1) > CONFIG > LINE CODE

This setting must match the line code of the circuit to which the interface is connected. Choices are **B8ZS** (bipolar with 8-zero substitution) and **AMI** (alternate mark inversion). The default is **B8ZS**.

INTERFACES (DSX-1) > STATUS

Displays the DSX-1 interface status including performance data and alarm histories.

INTERFACES (DSX-1) > STATUS > ALARMS

Displays current alarms and alarm history for the DSX-1 interface.

INTERFACES (DSX-1) > STATUS > ALARMS > CURRENT ALARMS

Displays the current alarms on the DSX-1 interface. An asterisk in a field indicates that an alarm is active.

LOS	Loss of Signal. No signal detected on port interface.
RED	Not able to frame data received on the port. Alternately referred to as Out of Frame (OOF).
YELLOW	Remote alarm indicator (RAI) being received on port.
BLUE	Receiving unframed all ones from the port alarm indicator signal (AIS).

INTERFACES (DSX-1) > STATUS > ALARMS > ALARM HISTORY

Displays the alarm history for the T1 interface. An asterisk in a field indicates that an alarm has occurred on the T1 interface since the last clear history. Refer to *Interfaces (DSX-1) > Status > Alarms > Current Alarms* for more details on listed alarm conditions.

INTERFACES (DSX-1) > STATUS > ALARMS > CLEAR HISTORY

Selecting this activator will clear the Alarm History for the T1 interface.

INTERFACES (DSX-1) > TEST

These options are used to initiate local and remote loopback tests and display the test status.

INTERFACES (DSX-1) > TEST > SLOT

Displays the slot number of the installed DSX-1 Module.

INTERFACES (DSX-1) > TEST > LOC LB

Loopback of the local unit. Choices are **NONE**, **LINE**, and **PAYLOAD**. **LINE** loopback loops all of the received data back toward the network. The transmitted data is the identical line code that was received, including any bipolar violations. **PAYLOAD** loopback is similar to line loopback except that the framing is extracted from the received data and then regenerated for the transmitted data. **NONE** disables the loopback test. Default is **NONE**.

INTERFACES (DSX CARD) > TEST > TEST STATUS

Indicates whether a test is in progress.

INTERFACES (UBR1TE MODULE)

View the UBR1TE Module interface status and configure the UBR1TE Module parameters from this menu.

INTERFACES (UBR1TE) > CONFIG

Configures the UBR1TE interface format and code from this menu.

INTERFACE (UBR1TE) > CONFIG > SLOT

Indicates the slot in which the UBR1TE Module is installed.

INTERFACE (UBR1TE) > CONFIG > MODE

Choices are **LUNT**, **LUNT w/WAKEUP**, and **LULT**. The U-BR1TE port should be configured to operate in the **LULT** mode if being operated in the Adjacent to Customer or Tandem Office Source positions (see Figure 7). The **MODE** should be set to **LUNT** if the port is operated in the Adjacent to Switch or Tandem Office Sink positions. Default is **LULT**.




Figure 7. UBR1TE Network Configurations

INTERFACE (UBR1TE) > CONFIG > SERVICE

Allows the user to select the ISDN channels transmitted over the T1 facility. Each channel requires one DS0 of the T1 in which to transmit and receive data. All switched applications will require the D channel. Choices are **2B+D**, **B1+D**, **B2+D**, **B1+B2**, **B1**, **B2**, and **D**. Default is **2B+D**.



The user must provision the proper number of consecutive DS0s of the T1 facility for proper operation.

INTERFACE (UBR1TE) > CONFIG > ZERO BYTE SUB

For proper operation, the **ZBS** (zero byte substitution) for two U-BR1TE ports connected by a T1 facility must be the same value. The **ENABLE** parameter for **ZBS** must be selected if the T1 is using AMI line coding. If the T1 facility is using B8ZS line coding, the **DISABLE** parameter may be chosen. Default is **ENABLED**.

INTERFACE (UBR1TE) > CONFIG > SEALING CURRENT

DC sealing current is only applicable if the mode is **LULT**. Sealing current should be present for Adjacent-to-Customer applications. Default is **ENABLED**.

INTERFACE (UBR1TE) > STATUS

View the interface status information for the UBR1TE Module.

INTERFACE (UBR1TE) > STATUS > SLOT

Displays the slot number for the installed UBR1TE Module.

INTERFACE (UBR1TE) > STATUS > ACT BIT

This status field indicates whether an NT1 is communicating with the ISDN switch.

INTERFACE (UBR1TE) > STATUS > LOOP

Displays synchronization between the UBR1TE card and the NT1 on the loop side of the card. Sync displays **YES** or **NO**.

INTERFACE (UBR1TE) > STATUS > CARRIER

Displays synchronization between the ISDN switch and the UBR1TE card on the T1 network side. Sync displays **YES** or **NO**.

INTERFACE (UBR1TE) > STATUS > RX LOOP CRC ERROR

Indicates a CRC error has been received on the loop side of the card (indicating it came from the NT1).

INTERFACE (UBR1TE) > STATUS > RX CARRIER CRC ERROR

Indicates a CRC error has been received on the carrier side of the card (indicating it came from the ISDN switch).

INTERFACE (UBR1TE) > STATUS > TEST STATUS

Indicates whether a test is in progress.

INTERFACE (UBR1TE) > TEST

These options are used to initiate tests.

INTERFACE (UBR1TE) > TEST > SLOT

Displays the slot number for the installed UBR1TE Module.

INTERFACE (UBR1TE) > TEST > B1 TEST

Initiates a test on the first B channel (B1) of the ISDN circuit. The following tests are available:

NONE

No active test.

ADDR1 (LOCAL LPBK)	Loopbacks in the Network-to-Customer direction initiate from either the ISDN switch or the test menus. If a DS0 digital test set is connected to the bantam connector on the front of the module, data from the test set provides the 64 kbps test pattern used in testing B1 or B2. If no test set is connected, an internally generated 2074 test pattern is used. When initiating loopbacks from the UBR1TE Module, the downstream direction is automatically selected based on the card position in the network. These tests are only valid for the Adjacent-to-Customer circuit position. Use ADDR2 to test an ADTRAN U-Repeater deployed from the UBR1TE.
ADDR2	
ADDR3	
ADDR4	
NT1	
TX INTO CARRIER	A point-to-point (straight-away) test initiated toward the T1 carrier interface. The internal 2047 test pattern generator is used to verify the performance of the bearer channel. This test is valid for all network configurations.
TX INTO LOOP	A point-to-point (straight-away) test initiated toward the U-interface. The internal 2047 test pattern generator is used to verify the performance of the bearer channel. This test is valid for all network configurations.
BILATERAL LPBK	Loops toward both the U-interface and the T1 carrier network.

LEASED MODE TESTING (INITIATED BY THE NETWORK; NOT A MENU OPTION)

For leased mode applications, the D channel is typically disabled on the UBR1TE. Without the D channel, standard ISDN loopbacks by way of the EOC are not available across the T1 carrier system. For this situation, the UBR1TE responds to independent network-issued OCU and CSU latching loopback sequences for B1 and B2, when configured as Adjacent-to-Customer. Upon receipt of an OCU latching loopback sequence, the UBR1TE initiates a bilateral loopback for the B channel under test. Upon receipt of a CSU latching loopback sequence, and provided the U-interface is terminated by an NT1/TA, the UBR1TE issues an EOC NT1 loopback for the appropriate B channel. In both tests of the OCU and the CSU loopbacks, the other B channel is not affected. The UBR1TE supports simultaneously testing both B channels. The OCU and CSU latching loopbacks are enabled by the following:

1. Minimum of 35 transition in progress (TIP) bytes (*0111010).
2. Minimum of 35 LSC bytes: OCU (*1010101), CSU (*0110001).
3. Minimum of 100 loopback enable (LBE) bytes (*1010110).
4. Minimum of 32 far-end voice (FEV) bytes (*1011010).
* denotes don't care bit (either a 1 or a 0)

Upon receipt of an OCU latching loopback, the UBR1TE provides a bilateral loopback on the bearer channel that received the loopback sequence. The other bearer channel is not affected during this loopback.

Upon receipt of a CSU latching loopback sequence in either B1 or B2 channels and the U-interface is in sync, the UBR1TE issues an EOC loopback request to the NT1 for the appropriate channel. If the U-interface is not in sync, the UBR1TE sends abnormal station (*0011110) in both B1 and B2 channels.

For a UBR1TE in a CSU latching loopback, receipt of the 35 TIPs will release the test in progress, following the release code to a UBR1TE in a CSU test, the UBR1TE issues a Return-To-Normal EOC message to the NT1/TA.

INTERFACE (UBR1TE) > TEST > B2 TEST

Initiates a test on the first B channel (B1) of the ISDN circuit. Refer to *Interface (UBR1TE) > Test > B1 Test* on page 113 for more details on available tests.

L2 PROTOCOL (T1 TDM FIRMWARE) – T1 INTERFACE

Configure the L2 Protocol parameters and view the status of the T1 interface using items from this menu.

L2 PROTOCOL (T1 TDM – T1) > PROTOCOL

Configure the L2 protocol mode. Choices are **PPP**, **FRE**, **HDLC**, and **AUTO** (def). Selecting **PPP** configures the interface for Point-to-Point Protocol signaling on Layer 2. Selecting **FRE** configures the interface for frame relay signaling on Layer 2. Selecting **HDLC** configures the interface for generic High-Level Data Link Control signaling on Layer 2. Selecting **AUTO** enables the Auto-config feature.

L2 PROTOCOL (T1 TDM – T1) > PROTOCOL > PPP

Point-to-Point Protocol (PPP) is an 8-bit serial protocol which allows a PC to connect as a TCP/IP host to a network through an asynchronous port. PPP is used for connection from a PC to an Internet Service Provider (ISP) for Internet access. PPP works over synchronous and asynchronous circuits.

Router-to-router and host-to-network connections can be made via PPP. PPP includes error detections which Serial Line Internet Protocol (SLIP) and other protocols do not.

L2 PROTOCOL (T1 TDM – T1) > PROTOCOL > FRE

Frame Relay is a switched data link layer protocol that handles multiple virtual circuits using High-Level Data Link Control (HDLC) encapsulation. Frame Relay uses statistical multiplexing as opposed to time-division-multiplexing to multiplex many logical connections over a single physical link. It contains a cyclical redundancy check (CRC) for detecting bad data, but leaves the error correction algorithms to be performed by higher protocol layers. Similarly, Frame Relay uses simple congestion notification. This notification in turn can alert higher-layer protocols to exercise flow control. These characteristics allow Frame Relay to provide a more flexible and efficient use of bandwidth.

L2 PROTOCOL (T1 TDM – T1) > PROTOCOL > HDLC

HDLC (High-level Data Link Control) is a group of protocols or rules for transmitting data between two network points (point-to-point transmission). HDLC provides a low overhead system for transmitting data over Layer 2. IP packets are encapsulated into frames with an HDLC start and end flag. Generic HDLC protocol should be used when connecting with remote equipment using proprietary HDLC encapsulation methods.

L2 PROTOCOL (T1 TDM – T1) > PROTOCOL > AUTO

Setting the **L2 PROTOCOL** to **AUTO** allows the unit to automatically detect the **L2 PROTOCOL** from the network.



*The **L2 PROTOCOL** must be set to **AUTO** in order to use the Auto-config feature.*

L2 PROTOCOL (T1 TDM FIRMWARE) – T1 INTERFACE > PPP

Configure the **L2 PROTOCOL** parameters and view the status of the T1 interface using PPP protocol from this menu.

L2 PROTOCOL (T1 TDM–T1–PPP) > CONFIG

Configure the **L2 PROTOCOL** parameters for the T1 interface using PPP protocol.

L2 PROTOCOL (T1 TDM–T1–PPP) > CONFIG > MODE

Select the **L2 PROTOCOL** mode. Choices are **ROUTE IP**, **BRIDGE ALL**, and **ROUTE IP/BRIDGE OTHER**. The default is **ROUTE IP**.

L2 PROTOCOL (T1 TDM–T1–PPP) > CONFIG > AUTHENTICATION

The **AUTHENTICATION** menu contains the required parameters for the authentication of the PPP peer and for being authenticated by the PPP peer. Authentication is applied between the unit and the PPP peer as described in the Authentication submenus.

L2 PROTOCOL (T1 TDM–T1–PPP) > CONFIG > AUTHENTICATION > TX METHOD

This parameter specifies how the unit is to be authenticated by the PPP peer. There are four possible selections. Default is **NONE**.

NONE	The connection will not allow the PPP peer to authenticate it
PAP, CHAP, OR EAP	The unit will ask for EAP during the first PPP LCP negotiation and allow the PPP peer to negotiate down to CHAP or PAP .
CHAP OR EAP	The unit will ask for EAP during the first PPP LCP negotiation and allow the PPP peer to negotiate down to CHAP but not PAP .
EAP ONLY	The unit will only allow EAP to be negotiated. If the PPP peer is not capable of doing EAP, then the connection will not succeed.
PAP ONLY	The unit will only allow PAP to be negotiated. If the PPP peer is not capable of doing PAP , then the connection will not succeed.

L2 PROTOCOL (T1 TDM–T1–PPP) > CONFIG > PPP

Configure the PPP specific parameters such as **MAX CONFIG**, **MAX TIMER**, **MAX FAILURE**, and **FORCE PEER IP ADDRESS** from this menu.

L2 PROTOCOL (T1 TDM–T1–PPP) > CONFIG > PPP > MAX CONFIG

This value is the number of unanswered configuration-requests that should be transmitted before resetting PPP negotiations. The possible values are **5**, **10**, **15** and **20** (def).

L2 PROTOCOL (T1 TDM-T1-PPP) > CONFIG > PPP > MAX TIMER (SEC)

This value is the numbers of seconds to wait between unanswered configuration-requests. The possible values are **1 SEC**, **2 SECS**, **3 SECS** (def), **5 SECS** and **10 SECS**.

L2 PROTOCOL (T1 TDM-T1-PPP) > CONFIG > PPP > MAX FAILURE

Due to the nature of PPP, configuration options may not be agreed upon between two PPP peers. This value is the number of configuration-naks that should occur before an option is configuration-rejected. The possible values are **5** (def), **10**, **15**, and **20**.

L2 PROTOCOL (T1 TDM-T1-PPP) > CONFIG > PPP > KEEPALIVE PERIOD

This option allow the user to generate PPP keepalive packets that can be sent one every 1 minute, 2 minutes or every 5 minutes. A value of 0 (def) disables the PPP keepalive packet generating feature.

L2 PROTOCOL (T1 TDM-T1-PPP) > CONFIG > PPP > FORCE PEER IP ADDRESS

This option forces the PPP to negotiate the IP address entered instead of allowing the IP address to be assigned by the remote end.

L2 PROTOCOL (T1 TDM-T1-PPP) > CONFIG > PPP > SEND IDENTIFICATION

When enabled, this option enables the Total Access 850 to send the system identification code in response to a configure acknowledgement from the peer equipment. For most peer routers this option should be configured as **YES**. If set to **No**, the Total Access 850 will accommodate peer routers that do not correctly respond to the identification code.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS

View the **L2 PROTOCOL** status for the T1 interface using the PPP protocol.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > LCP

Link Control Protocol. Reflects the LCP layer active.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > BCP

Shows **UP** if PPP Bridge Control Protocol has negotiated successfully.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > IPCP

Shows **UP** if PPP IP Control Protocol has negotiated successfully.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > UP TIME

Displays how long the PPP session has been connected.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > TX PKTS

Number of packets transmitted on the T1 interface.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > RX PKTS

Number of packets received on the T1 interface.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > TX BYTES

Number of bytes transmitted on the T1 interface.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > RX BYTES

Number of bytes received on the T1 interface.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > CURRENT UTIL (b/s)

Current utilization of the T1 interface bandwidth presented in bits per second.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > CURRENT UTIL (%)

Current utilization of the T1 interface bandwidth presented in percentage format.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > AVERAGE UTIL (b/s)

Average utilization of the T1 interface bandwidth (since the last stats reset) presented in bits per second.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > AVERAGE UTIL (%)

Average utilization of the T1 interface bandwidth (since the last stats reset) presented in percentage format.

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > TX PKTS

Number of packets transmitted on the T1 interface

L2 PROTOCOL (T1 TDM-T1-PPP) > STATUS > CLEAR STATS

Clears the PPP stats (returning the counters to 0) for the T1 interface.

L2 PROTOCOL (T1 TDM FIRMWARE) – T1 INTERFACE > FRE PROTOCOL

Configure the **L2 PROTOCOL** parameters and view the status of the T1 interface using Frame Relay protocol from this menu.

L2 PROTOCOL (T1 TDM–T1–FRE) > CONFIG

Configure the **L2 PROTOCOL** parameters for the T1 interface using the Frame Relay protocol.

L2 PROTOCOL (T1 TDM–T1–FRE) > CONFIG > MAINTENANCE PROTOCOL

The Frame Relay maintenance protocol is used on the WAN port. The maintenance protocol is used to send link status and virtual circuit information between Frame Relay switches and other devices (such as routers that communicate with them. Possible choices are as follows:

ANNEX D (ANSI)	This ANSI standard ANSI T1.617-D and is the most commonly used in the United States.
ANNEX A (Q933A)	This is the CCITT European standard, ITU-T Q.933-A.
LMI	This was developed by a vendor consortium and is also known as the “Consortium” management interface specification. It is still used by some carriers in the United States.
STATIC (No SIG)	This should be selected when there is no Frame Relay switch in the circuit. The DLCIs are assigned in the DLCI Mapping and must be the same for the device it will communicate with.

The default value is **ANNEX D (ANSI)**.

L2 PROTOCOL (T1 TDM–T1–FRE) > CONFIG > POLLING FREQUENCY (5-30)

This parameter is the interval that the unit polls the Frame Relay switch using the maintenance protocol selected. The unit is required to poll the Frame Relay switch periodically to determine whether the link is active. The value is in seconds and ranges from **5** to **30** seconds with a default of **10 SECONDS**.

L2 PROTOCOL (T1 TDM–T1–FRE) > CONFIG > DLCI MAPPING

This menu allows each DLCI to be mapped to a particular Frame Relay maintenance protocol. Each protocol parameter can be individually configured for each DLCI. By factory default, the DLCI map is empty.

When empty and a maintenance protocol other than the static is used, the unit will poll the switch to determine which DLCIs are active. These active DLCIs will attempt to determine the IP addresses on the other end of the virtual circuit using Inverse ARP (IARP). If there is a response, the network learned will be added to the router tables and the virtual circuit will be treated as an unnumbered interface. Bridge connections are made using bridge group 1. When more than one DLCI mapping is listed, the unit will try to match the DLCIs learned from the Frame Relay switch with the DLCI values in the map. If there is a match, the protocols specified in the map are used. However, if an active DLCI is not in the list, the unit looks for an entry that has 0 in the DLCI field. This entry is considered the default entry to use when no

match occurs. If this default entry is not present, the unit falls back to using IARP to determine the protocols to use with that particular virtual circuit. If a static maintenance protocol is used, at least one DLCI mapping must be specified.



*To insert a new profile, press the **I** key when over the **Num** column. A new inserted profile will always be set up with the default parameters. To copy parameters from an old profile to this newly inserted profile, use the copy (**C**) and paste (**P**) keys. Entire configuration trees can be copied with this method.*



*To delete an unused profile, use the **D** key when the cursor is over the number in the **Num** column. Once deleted, the profile is gone permanently.*

L2 PROTOCOL (T1 TDM–T1–FRE) > CONFIG > DLCI MAPPING > NUM

Displays the index number in the DLCI mapping table.

L2 PROTOCOL (T1 TDM–T1–FRE) > CONFIG > DLCI MAPPING > ACTIVE

When this parameter is set to **Yes** (def), the mapping is used to determine the protocols used. If set to **No**, the unit will ignore the virtual circuit with this DLCI.

L2 PROTOCOL (T1 TDM–T1–FRE) > CONFIG > DLCI MAPPING INTERFACE

Shows the user the physical and logical port associated with each DLCI. This is a read-only field.

L2 PROTOCOL (T1 TDM–T1–FRE) > CONFIG > DLCI MAPPING > DLCI

This DLCI (Data Link Connection Identifier) number identifies the virtual circuit being configured.

L2 PROTOCOL (T1 TDM–T1–FRE) > CONFIG > DLCI MAPPING > MODE

The mode identifies how the data will be forwarded. The choices are:

- | | |
|-------------------------------|---|
| ROUTE IP (def) | All IP data for this DLCI will be routed. |
| BRIDGE ALL | All data for this DLCI will be bridged. |
| ROUTE UIP/BRIDGE OTHER | All IP data will be routed. All other data will be bridged. |

L2 PROTOCOL (T1 TDM–T1–FRE) > CONFIG > DLCI MAPPING > BECN TIMEOUT (MSEC)

This value is expressed in milliseconds and represents the amount of time the unit will stop transmitting over a PVC which received a packet with the BECN bit set. Range is **50-5000** msec; the default is

50 MILLISECONDS.

L2 PROTOCOL (T1 TDM–T1–FRE) > STATUS

View the L2 protocol status for the T1 interface using the Frame Relay protocol.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT

View the Frame Relay statistics on the WAN port.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > PORT INDEX

Integer used for identifying DLCIs on an interface. A single DLCI will always be port index 0. Subsequent DLCIs will have incrementing port indices.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > SIGNAL STATE

Displays “up” when the unit is communicating with the Frame Relay switch; otherwise displays “down”.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > TX FRAMES

Total frames transmitted out the WAN port.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > RX FRAMES

Total frames received from the WAN port.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > TX BYTES

Total bytes transmitted out the WAN port.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > RX BYTES

Total bytes received on the WAN port.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > CURRENT UTIL (b/s)

Current utilization of the T1 interface bandwidth presented in bits per second.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > CURRENT UTIL (%)

Current utilization of the T1 interface bandwidth presented in percentage format.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > AVERAGE UTIL (b/s)

Average utilization of the T1 interface bandwidth (since the last stats reset) presented in bits per second.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > AVERAGE UTIL (%)

Average utilization of the T1 interface bandwidth (since the last stats reset) presented in percentage format.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > FULL STATUS TX FRAMES

Number of full status frames transmitted out the WAN port.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > FULL STATUS RX FRAMES

Number of full status frames received on the WAN port

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > LINK INTEGRITY STATUS TX FRAMES

Number of Link-Integrity (LI) only frames transmitted out the WAN port.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > LINK INTEGRITY STATUS RX FRAMES

Number of LI only frames received on the WAN port.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > DROP UNKNOWN DLCI

Number of frames received that were not associated with any known PVC.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > DROP INVALID DLCI

Number of frames received that had illegal DLCIs.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PORT > CLEAR STATS

Selecting this activator will clear the port Frame Relay Statistics.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s)

View the Frame Relay status on a per PVC basis.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s) > DLCI

The DLCI number identifies the virtual circuit being monitored.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s) > STATE

The state of the virtual circuit:

INACTIVE	The circuit exists but has been deactivated by the Frame Relay switch.
EXISTS	The circuit exists at this point and should be activated soon.
ACTIVE	The circuit is fully active.
OFF	The circuit has been turned off by the DLCI mapping active selection.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s) > TX FRAMES

Number of Frame Relay packets that have been transmitted via this DLCI.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s) > RX FRAMES

Number of Frame Relay packets that have been received via this DLCI.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s) > TX BYTES

Number of Frame Relay bytes that have been transmitted via this DLCI.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s) > RX BYTES

Number of Frame Relay bytes that have been received via this DLCI.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s) > DE COUNT

Number of packets received on this DLCI with the Discharge Eligible (DE) bit set.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s) > CR COUNT

Number of packets received on this DLCI with the Command Response (CR) bit set.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s) > BECN COUNT

Number of packets received on this DLCI with the Backward Explicit Congestion Notification (BECN) bit set.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s) > FECN COUNT

Number of packets received on this DLCI with the Forward Explicit Congestion Notification (FECN) bit set.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s) > UNKNOWN FRAME RX

Number of frames that have been received that the unit does not know where to route.

L2 PROTOCOL (T1 TDM-T1-FRE) > STATUS > PVC(s) > CLEAR STATS

Clears all gathered statistics for this interface and returns counters to 0.

L2 PROTOCOL (T1 TDM FIRMWARE) – T1 INTERFACE > HDLC PROTOCOL

View the status of the T1 interface with the **L2 PROTOCOL** set to **HDLC**.

L2 PROTOCOL (T1 TDM-T1-HDLC) > STATUS

View the status of traffic flow and utilization for the T1 interface with an **L2 PROTOCOL** set to **HDLC**.

L2 PROTOCOL (T1 TDM-T1-HDLC) > STATUS > Tx PKTS

Number of packets transmitted on the T1 interface.

L2 PROTOCOL (T1 TDM-T1-HDLC) > STATUS > RX PKTS

Number of packets received on the T1 interface.

L2 PROTOCOL (T1 TDM-T1-HDLC) > STATUS > TX BYTES

Number of bytes transmitted on the T1 interface.

L2 PROTOCOL (T1 TDM-T1-HDLC) > STATUS > RX BYTES

Number of bytes received on the T1 interface.

L2 PROTOCOL (T1 TDM-T1-HDLC) > STATUS > CURRENT UTIL (b/s)

Current utilization of the T1 interface bandwidth presented in bits per second.

L2 PROTOCOL (T1 TDM-T1-HDLC) > STATUS > CURRENT UTIL (%)

Current utilization of the T1 interface bandwidth presented in percentage format.

L2 PROTOCOL (T1 TDM-T1-HDLC) > STATUS > AVERAGE UTIL (b/s)

Average utilization of the T1 interface bandwidth (since the last stats reset) presented in bits per second.

L2 PROTOCOL (T1 TDM-T1-HDLC) > STATUS > AVERAGE UTIL (%)

Average utilization of the T1 interface bandwidth (since the last stats reset) presented in percentage format.

L2 PROTOCOL (T1 TDM-T1-HDLC) > STATUS > TX PKTS

Number of packets transmitted on the T1 interface

L2 PROTOCOL (T1 TDM-T1-HDLC) > STATUS > CLEAR STATS

Clears all the gathered statistics for this interface and returns the counters to 0.

L2 PROTOCOL (T1 TDM FIRMWARE) – T1 INTERFACE > AUTO PROTOCOL

View the status of the T1 interface with the **L2 PROTOCOL** set to **AUTO** (using Auto-config feature).

L2 PROTOCOL (T1 TDM-T1-AUTO) > STATUS

View the status of the auto detect function and traffic flow for the T1 interface with an **L2 PROTOCOL** set to **AUTO**.

L2 PROTOCOL (T1 TDM-T1-AUTO) > STATUS > STATE

This field represents the state of the auto detect/configuration function. The possible state are:

OFF	The T1 interface is down, so the auto-detect/configuration process is currently idle.
DETECTING L2 PROTOCOL	The T1 interface is up and waiting for the first control/signaling packet.
CONFIRMING FR	The T1 interface is up and one FR signaling packet has been received
CONFIRMED FR	The T1 interface is up and two FR signaling packets have been received. It takes two consecutive control/signaling packets of the same type to confirm the detected protocol.
CONFIRMING PPP	The T1 interface is up and one PPP control packet has been received.
CONFIRMED PPP	The T1 interface is up and two PPP control packets have been received. It takes two consecutive control/signaling packets of the same type to confirm the detected protocol.

L2 PROTOCOL (T1 TDM-T1-AUTO) > STATUS > TX PKTS

Number of packets transmitted out of the WAN port.

L2 PROTOCOL (T1 TDM-T1-AUTO) > STATUS > RX PKTS

Number of packets received on WAN port.

L2 PROTOCOL (T1 TDM-T1-AUTO) > STATUS > TX BYTES

Number of bytes transmitted out of the WAN port.

L2 PROTOCOL (T1 TDM-T1-AUTO) > STATUS > RX BYTES

Number of bytes received out of the WAN port.

L2 PROTOCOL (T1 TDM-T1-AUTO) > STATUS > CLEAR STATS

Clears all the gathered statistics for this interface and returns the counters to 0.

L2 PROTOCOL (T1 ATM FIRMWARE)

Use the **L2 PROTOCOL** menu to select the **L2 PROTOCOL**, configure the protocol specific parameters, and view the status as shown in Figure 8. The following menus are for Total Access 850 systems using T1 ATM firmware.





Figure 9. L2 Protocol (T1 TDM) Menu

For convenience, the following heading notations identify the type of firmware and L2 protocol configured in the Total Access 850 system:



L2 PROTOCOL (T1 ATM FIRMWARE) – T1 INTERFACE

Configure the **L2 PROTOCOL** parameters and view the status of the T1 interface using items from this menu.

L2 PROTOCOL (T1 ATM – T1) > PROTOCOL

Configure the **L2 PROTOCOL** mode. Choices are **ATM** and **CUMTN** (def). Selecting **ATM** configures the interface for Asynchronous Transfer Mode signaling on Layer 2. Selecting **CUMTN** configures the interface for Copper Mountain frame relay signaling on Layer 2.

L2 PROTOCOL (T1 ATM – T1) > PROTOCOL > ATM

Asynchronous Transfer Mode allocates bandwidth on demand, automatically adjusting the network capacity to meet the system needs. Fixed-length cells (53 octet) require lower processing overhead and allow higher transmission speeds than traditional packet switching methods. ATM uses five octet headers in each fifty-three octet cell to match cells with specific virtual channels to which they belong.

L2 PROTOCOL (T1 ATM – T1) > PROTOCOL > CUMTN

Copper Mountain Frame Relay is a data link layer protocol that uses Frame Relay instead of ATM on the subscriber loop. Frame relay is a switched layer protocol that handles virtual circuits using High-Level Data Link Control (HDLC) encapsulation. Frame Relay uses statistical multiplexing as opposed to time-division-multiplexing many logical connections over a single physical link.

L2 PROTOCOL (T1 ATM FIRMWARE) – T1 INTERFACE > ATM

Configure the **L2 PROTOCOL** parameters and view the status of the T1 interface using ATM protocol from this menu.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG

Configure the **L2 PROTOCOL** parameters for the T1 interface using ATM protocol.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > ATM CONFIG

Use the **ATM CONFIG** menu to set the parameters listed below.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > ATM CONFIG > IDLE CELLS

The **IDLE CELLS** format must be configured for either **ATM FORUM (UNASSIGNED)** or **ITU (IDLE)**. Configuring this setting incorrectly for a particular circuit will cause poor performance at the ATM Layer. The default is **ATM FORUM (UNASSIGNED)**.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > ATM CONFIG > DATA SCRAMBLING

DATA SCRAMBLING can be **ENABLED** or **DISABLED** for cell traffic. Configuring this setting incorrectly for a particular circuit will cause poor performance at the ATM Layer.



The setting must match the configuration setting of the ATM switch or DSLAM at the other end of the circuit.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > ATM CONFIG > HEC COSET

Header Error Control is located in the last (5th) byte of the ATM cell header that checks for cell integrity only. The Coset polynomial is applied to the received HEC for comparison with the HEC generated internally. HEC errors may be detected after synchronization, and any detected bit errors prompt that the cell be dropped. The choice are **ENABLED** (def) or **DISABLED**.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > PVC CONFIG

Configure up to six ATM PVCs from this menu (five data and one voice PVC).



*To insert a new PVC, press the **I** key when over the **NUM** column. A new inserted PVC will always be set up with the default parameters. To copy parameters from an old PVC to the new PVC, use the copy (**C**) and paste (**P**) keys. Entire configuration trees can be copied with this method.*



*To delete an unused PVC, use the **D** key when the cursor is over the number in the **NUM** column. Once deleted, the PVC is gone permanently.*

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > PVC CONFIG > NUM

Displays the index number for the PVC entry.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > PVC CONFIG > ACTIVE

Activates the ATM PVC. The choices are **Yes** or **No**. Default is **No**.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > PVC CONFIG > SUB-INTERFACE

The T1 Sub-Interface is **ATM [0.0]** that represents the T1 physical and logical ports respectively. This is a read-only field.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > PVC CONFIG > VPI

ATM Virtual Path Identifier located in the ATM cell header identifies the virtual path over which this port is running. The range is **0-256**. The default is **0**.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > PVC CONFIG > VCI

This is the ATM Virtual Channel Identifier that serves as an address for the virtual channel cell transmissions between two devices. The range is **0-65355**. The default setting is **38**.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > PVC CONFIG > CONNECTION

Select the physical and logical method of data transfer over the virtual path. There are three valid connection entries: **ROUTER**, **V35**, and **VOICE**. Select **ROUTER** to connect traffic from this PVC to the Total Access 850 integral IP router. Select **V35** to connect traffic from this PVC to a V.35 interface on the system. Select **VOICE** to connect traffic from this PVC to a voice connection (on a DSX-1 or FXS interface).

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > PVC CONFIG > SETUP (ROUTER)

Use these menus to configure the router parameters for this logical connection from the router to the T1 interface. These menus are only applicable when the **CONNECTION** parameter is set to **ROUTER**.

CONNECTION (ROUTER) > SETUP > PROTOCOL

Selects the data-link protocol for the PVC connection between the T1 interface and the router. The choices are: **IP** (def) and **PPP**.

CONNECTION (ROUTER) > SETUP > MODE

Identifies how the data will be transferred through the Total Access 850 system. The following choices are available:

ROUTE IP (def) – All IP data for this PVC is routed through the Total Access 850 integral router.

BRIDGE ALL – All data for this PVC is bridged through the Total Access 850 system.

ROUTE IP/BRIDGE OTHER – All IP data for this PVC is routed through the Total Access 850 integral router and all other data is bridged through the system.

CONNECTION (ROUTER) > SETUP > PPP SETUP

Provides PPP configuration parameters for the PVC. These menus are only visible when the **MODE** is set to **PPP**.

AUTHENTICATION

Contains the required parameters for PPP peer authentication and for being authenticated by the PPP peer. Authentication is applied between the unit and the PPP peer as described in the submenus.

TX METHOD

Specifies the method the Total Access 850 uses to obtain PPP authentication from the peer. There are four possible selections:

NONE	The connection will not allow the PPP peer to authenticate it.
PAP, CHAP, OR EAP	The unit will ask for EAP during the first PPP LCP negotiation and allow the PPP peer to negotiate down to CHAP or PAP .
CHAP OR EAP	The unit will ask for EAP during the first PPP LCP negotiation and allow the PPP peer to negotiate down to CHAP but not PAP .
EAP ONLY	The unit will only allow EAP to be negotiated. If the PPP peer is not capable of doing EAP , then the connection will not succeed.
PAP ONLY	The unit will only allow PAP to be negotiated. If the PPP peer is not capable of doing PAP , then the connection will not succeed.

RX METHOD

Specifies the method the Total Access 850 uses to authenticate the PPP peer. There are four possible selections:

NONE	The connection will not allow the PPP peer to authenticate it.
PAP, CHAP, OR EAP	The unit will ask for EAP during the first PPP LCP negotiation and allow the PPP peer to negotiate down to CHAP or PAP .
CHAP OR EAP	The unit will ask for EAP during the first PPP LCP negotiation and allow the PPP peer to negotiate down to CHAP but not PAP .
EAP ONLY	The unit will only allow EAP to be negotiated. If the PPP peer is not capable of doing EAP , then the connection will not succeed.
PAP ONLY	The unit will only allow PAP to be negotiated. If the PPP peer is not capable of doing PAP , then the connection will not succeed.

PPP

Configure the PPP specific parameters such as **MAX CONFIG**, **MAX TIMER**, **MAX FAILURE**, and **FORCE PEER IP ADDRESS** from this menu.

MAX CONFIG

This value is the number of unanswered configuration-requests that should be transmitted before resetting PPP negotiations. The possible values are **5**, **10**, **15**, and **20** (def).

MAX TIMER (SEC)

This value is the number of seconds to wait between unanswered configuration-requests. The possible values are **1 SEC**, **2 SECS**, **3 SECS (DEF)**, **5 SECS**, and **10 SECS**.

MAX FAILURE

Due to the nature of PPP, configuration option may not be agreed upon between two PPP peers. This value is the number of configuration-naks that should occur before an option is configuration-rejected. The possible values are **5 (DEF)**, **10**, **15**, and **20**.

FORCE PEER IP ADDRESS

This option forces the PPP to negotiate the IP address entered instead of allowing another address to be assigned by the remote end. The default is **No**.

KEEPALIVE PERIOD

This option allows the user to generate PPP keepalive packets that can be sent every **1** minute, **2** minutes, or every **5** minutes. A value of **0 (OFF)** disables the PPP keepalive packet generating feature. The default is **0 (OFF)**.

PPP ENCAPSULATION

This option allows the user to set the encapsulation modes for PPP over ATM. LLC has an encapsulation header in the AAL5 frame indicating it is encapsulating PPP. VC-Mux does not have a header, and is therefore dedicated to using PPP. The choices are **LLC** or **VC-MUX**. The default is **VC-MUX**.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > PVC CONFIG > SETUP (V35)

Use these menus to configure the V35 parameters for this logical connection from the T1 interface to the V.35 port. These menus are only applicable when the **CONNECTION** parameter is set to **V35**.

CONNECTION (V35) > SETUP > SETUP

Use these menus to configure the Protocol mapping, DE map, and FECN map for the V.35 PVC connections.

CONNECTION (V35) > SETUP > SETUP > PROTOCOL MAPPING

Network providers have the ability to provision each PVC pair with an encapsulation mode to ensure interoperability between terminal equipment. The choices are **TRANSPARENT** or **TRANSLATION** (def). **TRANSLATION** mode is most common and carries multiple upper layer protocols over Frame Relay and ATM PVCs.

CONNECTION (V35) > SETUP > SETUP > DE MAP

Maps Frame Relay Discard Eligible (DE) bit to the ATM Cell Loss Priority (CLP) bit. The choices are **DE = 0**, **DE = 1**, and **CONVERT** (map DE TO CLP). The factory default setting is **DE = 0**.

CONNECTION (V35) > SETUP > SETUP > FECN MAP

Allows mapping of Frame Relay FECN (Forward Explicit Congestion Notification) bit to ATM EFCI (Explicit Forward Congestion Indicator) bit. The choices are **NO MAP FECN** and **MAP FECN**. The factory default setting is **NO MAP FECN**.

CONNECTION (V35) > SETUP > DLCI MAPPING

Use these menus to configure the DLCI mapping for the PVC from the T1 network interface to the V.35 interface.

CONNECTION (V35) > SETUP > DLCI MAPPING > MAP

Displays the DLCI Map number and is used as an index for multiple listings. The first map entry listed is 1, the next is 2, etc. All map numbers assigned will be sequential.

CONNECTION (V35) > SETUP > DLCI MAPPING > ACTIVE

Enables FR/ATM mapping and data passing between the V.35 FRFx connection and the ATM PVC on the network interface. If set to **NO**, data will not pass from the network to the configured V.35 endpoint. By default, this field is set to **YES** to allow data to pass as soon as the connection is configured.

CONNECTION (V35) > SETUP > SETUP > INTERFACE

The T1 interface is **ATM[0.0]** which represents the T1 physical and logical ports respectively. This is an identifier for the system to document the T1 network end of the logical link between the network port and the V.35 interface.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > PVC CONFIG > SETUP (VOICE)

Use these menus to configure the voice parameters for this logical connection from the T1 interface to the DSX-1 or FXS port being used as a voice interface. These menus are only applicable when the **CONNECTION** parameter is set to **VOICE**.

CONNECTION (VOICE) > SETUP > CALL CONTROL

The Call Control setting is used to configure the correct Voice Gateway protocol for voice signaling control between the Total Access 850 and the configured Gateway. The **CALL CONTROL** setting must be configured correctly before the voice circuits will work correctly. The Total Access 850 supports Jetstream, Coppercom, Tollbridge, and LES-CAS. The default is LES-CAS.

CONNECTION (VOICE) > SETUP > LES PROFILE

This options applies when **CALL CONTROL** is set to **LES-CAS**. The choices are **ITU PROFILE 1**, **ATM FORUM PROFILE 9**, and **ATM FORUM PROFILE 10**. The default is **ATM FORUM PROFILE 10**.

***ATM FORUM PROFILE 9** provides ability to support 64 kbps PCM calls. **ATM FORUM PROFILE 10** enables support of 64 Kbps PCM calls as well as 32 kbps ADPCM calls.*

CONNECTION (VOICE) > SETUP > LES-CAS GW SIM

Configures the interface to simulate a LES-CAS gateway. Enable this parameter only when back-to-back IAD testing.

L2 PROTOCOL (T1 ATM–T1–ATM) > CONFIG > PVC CONFIG > QOS

Use these menus to configure the Quality of Service parameters for the connection. This menu does not apply to logical connections involving a **VOICE** port.

QOS > QUALITY OF SERVICE

Quality of Service for ATM Undefined Bit Rate (UBR) and non-real time Variable Bit Rate (VBR) for the data PVC DLCI. This setting depends on the type of network ATM service being provided.

QOS > PEAK CELL RATE

Defines the peak cell rate for the data PVC. This setting is normally used for Undefined Bit Rate (UBR) connections and is calculated using the following equation:

$$\text{Peak Cell Rate} = \text{Bit Rate} / 424$$

The total of all peak cell rates for the ATM network connection must not exceed the line rate. The range for this parameter is **0** to **3623**.

L2 PROTOCOL (T1 ATM–T1–ATM) > STATUS

Displays all available ATM statistics (both overall and PVC-specific).

L2 PROTOCOL (T1 ATM-T1-ATM) > STATUS > ATM STATUS

Displays overall ATM link performance statistics. The following statistics are available:

AP: TX CELLS	Number of cells transmitted over the ATM link.
AP: RX CELLS	Number of cells received over the ATM link.
AP: RX OAM CELLS	Number of Operation, Administration, and Maintenance cells received on the ATM link. OAM cells provide network fault indications, performance information, and data and diagnostic functions.
AP: RECEIVE CELL DISCARDED	Number of cells received that are received and discarded. An incrementing count in this field could indicate a configuration problem with the ATM layer.
AP: RECEIVE CELL ERRORS	Number of cells received that contain a Header Error Control (HEC) error. The HEC is a CRC code located in the last byte of the ATM cell header that's used for checking integrity.
AP: SYNC	Indicates cell delineation at the ATM layer.
AP: OUT OF CELL	Indicates loss of cell delineation at the ATM layer.
AAL5: TRANSMIT FRAMES	Number of ATM Adaptation Layer Type 5 frames transmitted on the ATM link.
AAL5: RECEIVE FRAMES	Number of ATM Adaptation Layer Type 5 frames received on the ATM link.
AAL5: TRANSMIT DISCARDED FRAMES	Number of ATM Adaptation Layer Type 5 transmitted frames that were discarded before transmission.
AAL5: RECEIVE ERRORS	Number of ATM Adaptation Layer Type 5 frames that were received and contained errors.
AAL5: RECEIVE DISCARDED FRAMES	Number of ATM Adaptation Layer Type 5 frames that were received but then discarded.
AAL5: NO ATM FRAMES	Internal ADTRAN use only.
AAL5: NO DATA PACKETS	Internal ADTRAN use only.

L2 PROTOCOL (T1 ATM-T1-ATM) > STATUS > ATM STATUS > CLEAR STATS

Clears all ATM statistics contained in the ATM status field and returns all counters to 0.

L2 PROTOCOL (T1 ATM-T1-ATM) > STATUS > PVC STATUS

View the ATM PVC statistics from this menu.

L2 PROTOCOL (T1 ATM-T1-ATM) > STATUS > PVC STATUS > NUM

Displays the index number in the PVC Status menu.

L2 PROTOCOL (T1 ATM–T1–ATM) > STATUS > PVC STATUS > SUB-INTERFACE

The T1 **SUB-INTERFACE** is **ATM[0.0]**, representing the T1 physical and logical ports, respectively. This is a read-only field.

L2 PROTOCOL (T1 ATM–T1–ATM) > STATUS > PVC STATUS > AAL STATS

Shows the statistics of ATM Adaptation Layer frames.

MAX PDU SIZE	Maximum Protocol Data Unit size for the ATM AAL5 frame. All data information larger than the PDU must be transmitted in multiple frames.
TX DATA BYTES	Number of AAL5 data bytes transmitted.
TX FRAMES	Number of AAL5 frames transmitted.
TX CELLS (ALL TYPES)	Total number of AAL5 cells transmitted (all types).
TX OAM CELLS	Number of AAL5 Operations, Administration, and Maintenance cells transmitted.
TX RM CELLS	Number of AAL5 Resource Management cells transmitted.
TX EFCI=1 CELLS	Number of AAL5 EFCI=1 cells transmitted.
TX CLPI=1 CELLS	Number of AAL5 CLPI=1 transmitted.
RX DATA BYTES	Number of AAL5 data bytes received.
RX FRAMES	Number of AAL5 frames received
RX USER CELLS	Number of AAL5 user cells received
RX OAM CELLS	Number of AAL5 OAM cells received
RX BAD OAM CELLS	Number of AAL5 Bad OAM cells received
RX RM CELLS	Number of AAL5 RM cells received
RX BAD RM CELLS	Number of AAL5 Bad RM cells received
RX EFCI=1 CELLS	Number of AAL5 EFCI=1 cells received.
RX CLPI=1 CELLS	Number of AAL5 CLPI=1 cells received.
DISCARD RX CELLS	Number of AAL5 RX cells which were discarded.
DISCARD RX FRAMES	Number of AAL5 RX frames which were discarded.
DISCARD TX FRAMES	Number of AAL5 TX frames which were discarded.
TX QUEUE OVERFLOW	Number of cells discarded due to queue overflow.
TX OUT OF CELLS	Number of AAL5 TX Out of Cells.
TX INACTIVE	Number of TX frames discarded while PVC is inactive.
RX INACTIVE	Number of RX frames discarded while PVC is inactive.
CRC ERRORS	Number of AAL5 CRC Errors.
REASSEMBLY TIMEOUTS	Number of AAL5 Reassembly Timeouts.
TOO LONG FRAMES	Number of AAL5 Too Long Frames.
CLEAR COUNTS	Clears all recorded statistics and returns all counters to 0.

L2 PROTOCOL (T1 ATM–T1–ATM) > STATUS > PVC STATUS > PROTOCOL STATUS

Use these menus to view the **AAL2 STATS**, **POTS STATS**, and to **CLEAR STATS** for the PVC Protocol.

AAL2 STATS

ATM Adaptation Layer 2 statistics is used to provide error information on voice traffic. This menu displays **Rx AAL2 HEC ERRORS**, **Rx AAL2 SEQK ERRORS**, **Rx VOICE SEQ ERRORS**, **Rx VOICE BAD CID**, **Rx VOICE BAD UUI**, **Rx VOICE EOC CELLS**, and **PEAK CELL RATE**.

Rx AAL2 HEC ERRORS

A CRC code (used for data integrity checks) is contained in the last byte of an AAL2 header. A received HEC error could result in dropped packets and poor voice quality.

Rx AAL2 SEQK ERRORS

A single bit of the AAL2 header is used as a sequence bit and toggles from 1 to 0 with each successive transmitted cell. If two cells are received back to back with the same sequence bit, a sequence error is denoted.

Rx VOICE SEQ ERRORS

Indicates that the Total Access 850 received voice packets that were out of sequence according to the voice sequencing bits. The Total Access 850 does not drop these packets, but the error is logged because invalid sequence numbers were received.

Rx VOICE BAD CID

Indicates that the channel identifier (used for identifying voice calls in the ATM cell) was not valid.

Rx VOICE BAD UUI

The User Indication designates the signaling bit pattern for PCM/ADPCM and identifies the packet as Type 1 (voice) or Type 3 (signaling). This error indicates the Total Access 850 received an incorrectly formatted UUI.

Rx VOICE EOC CELLS

Indicates an EOC cell was received with a voice designation.

PEAK CELL RATE

Indicates the number of times (since the last statistics reset) that the PVC has reached the peak cell rate.

POTS STATS

Selecting this menu options will show real-time indication status of each voice port on the Total Access 850. On a per port basis, the user can determine which ports are active/inactive as well as view other statistics like **TxQ**, **INSERTS** and **DROPS INDICATORS**.



*The Echo Canceller module ADPCM functionality automatically shifts ON/OFF when fax or modem calls are placed. To find out the current status of the Echo Canceller functionality, check the current status of each FXS port. The path of the current status can be found at the following path: **L2 PROTOCOL > STATUS > PVC STATUS > PROTOCOL STATUS > POTS STATS > CODING TYPE** (this will display either PCM of ADPCM).*

TxQ

Displays the numbers of cells waiting in the buffer to transmit out the POTS port. Buffering voice cells is used to minimize jitter.

INSERTS

Displays the number of cells the Total Access 850 inserted on the analog interface to keep the current voice call connected when the network is idle.

DROPS

Displays the number of voice cells the Total Access 850 dropped due to a full buffer. This indicates that the network is sending traffic faster than the Total Access 850 is anticipating receiving cells; thus overrunning the jitter buffer. Excess drops could result in a timing mismatch.

CLEAR STATS

Clears all recorded statistics and returns all counters to 0.

L2 PROTOCOL (T1 ATM FIRMWARE) – T1 INTERFACE > CUMTN

Configure the **L2 PROTOCOL** parameters and view the status of the T1 interface using Copper Mountain Frame Relay protocol from this menu.

L2 PROTOCOL (T1 ATM-T1-CuMTN) > CONFIG

Configure the **L2 PROTOCOL** parameters for the T1 interface using Copper Mountain Frame Relay protocol.



*To insert a new profile, press the **I** key when over the **NUM** column. A new inserted profile will always be set up with the default parameters. To copy parameters from an old profile to this newly inserted profile, use the copy (**C**) and paste (**P**) keys. Entire configuration trees can be copied with this method.*



*To delete an unused profile, use the **D** key when the cursor is over the number in the **NUM** column. Once deleted, the profile is gone permanently.*

L2 PROTOCOL (T1 ATM-T1-CuMTN) > CONFIG > NUM

Displays the index number in the DLCI config table. The number range is **0-9**.

L2 PROTOCOL (T1 ATM-T1-CuMTN) > CONFIG > ACTIVE

When this parameter is set to **YES** (def), the mapping is used to determine the protocols used. If set to **No**, the unit will ignore the virtual circuit with this DLCI.

L2 PROTOCOL (T1 ATM-T1-CuMTN) > CONFIG > INTERFACE

Shows the user the physical and logical port associated with each DLCI. This is a read-only field.

L2 PROTOCOL (T1 ATM-T1-CuMTN) > CONFIG > DLCI

The DLCI (Data Link Connection Identifier) number identifies the virtual circuit being configured. The DLCI range is **16-1023**. The default is **16-25** corresponding to the index numbers **0-9** respectfully.

L2 PROTOCOL (T1 ATM-T1-CuMTN) > CONFIG > CONNECTION

Select the physical and logical method of data transfer over the virtual path. There are two valid connection entries: **ROUTER** and **VOICE**. Select **ROUTER** to connect traffic from this PVC to the Total Access 850 integral IP router. Select **VOICE** to connect traffic from this PVC to a voice connection (normally an FXS interface).

L2 PROTOCOL (T1 ATM-T1-CuMTN) > CONFIG > SETUP

This submenu only appears for **VOICE** connections. Configure the **CALL CONTROL** for voice gateway using this menu.

L2 PROTOCOL (T1 ATM-T1-CuMTN) > CONFIG > SETUP > CALL CONTROL

The **CALL CONTROL** setting is used to configure the correct Voice Gateway protocol for voice signaling control between the Total Access 850 and the configured Gateway. The Call Control setting must be configured correctly before the voice circuits will work correctly. The Total Access 850 supports **JETSTREAM**, **COPPERCOM**, **TOLLBRIDGE** and **LES-CAS** (def).

L2 PROTOCOL (T1 ATM–T1–CuMTN) > STATUS

View the status of the Copper Mountain DLCI connections.

L2 PROTOCOL (T1 ATM–T1–CuMTN) > STATUS > NUM

Displays the index number for the Status menu entries.

L2 PROTOCOL (T1 ATM–T1–CuMTN) > STATUS > SUB-INTERFACE

The T1 **SUB-INTERFACE** is CuMtn[0.0] when the **L2 PROTOCOL** is set for **CuMTN FRE**. The [0.0] represents the T1 physical and logical ports respectively. This is a read-only field.

L2 PROTOCOL (T1 ATM–T1–CuMTN) > STATUS > DLCI STATE

This is a read-only field that displays the live DLCI state.

L2 PROTOCOL (T1 ATM–T1–CuMTN) > STATUS > PROTOCOL STATUS

This is a read-only field that displays the live protocol status. Menu visible for physical and logical **VOICE** ports only.

L2 PROTOCOL (T1 ATM–T1–CuMTN) > STATUS > PROTOCOL STATUS > POTS STATS

View the voice port activity and coding type.

L2 PROTOCOL (T1 ATM–T1–CuMTN) > STATUS > PROTOCOL STATUS > CLEAR STATS

Clears all recorded statistics for the interface and returns all counters to 0.

L2 PROTOCOL (T1 ATM FIRMWARE) – V.35 INTERFACE

Configure the **L2 PROTOCOL** parameters and view the status of the V.35 interface using items from this menu. The V.35 interface is only available when the configured T1 network protocol is ATM. Refer to *L2 Protocol (T1 ATM Firmware) – T1 Interface > ATM* on page 129.

L2 PROTOCOL (T1 ATM – V35) > PROTOCOL

Configure the **L2 PROTOCOL** mode. Choices are **FRF5** (def) and **FRF8**. Selecting **FRF5** configures the interface for network interworking and should be used for Frame Relay over ATM applications. Selecting **FRF8** configures the interface for service interworking allowing the Total Access 850 to make the translation between Frame Relay signaling on the V35 interface and ATM protocols on the network interface.

L2 PROTOCOL (T1 ATM – V35) > CONFIG

Configures the **L2 PROTOCOL** parameters for either FRF5 or FRF8 signaling.

L2 PROTOCOL (T1 ATM – V35) > CONFIG > UNI MAINT PROTOCOL

Specifies the maintenance protocol or signaling protocol between the local V.35 port and the attached DTE port. The choices are **ANNEX D** (def), **ANNEX A**, **LMI**, and **STATIC**.

L2 PROTOCOL (T1 ATM – V35) > CONFIG > UNI POLL TIMEOUT T392 (5-30)

T392 for signaling protocol. This parameter has no meaning if the **UNI MAINT PROTOCOL** is set to **STATIC** (no signaling). The default setting is **10**.

L2 PROTOCOL (T1 ATM – V35)> STATUS

Displays the L2 statistics for FRF5 or FRF8 operation.

L2 PROTOCOL (T1 ATM – V35)> STATUS> PORT

Displays statistics for all the PVCs configured on this port. The following statistics are available:

PORT INDEX	Port number
SIGNAL STATE	Frame relay state
TX FRAMES	Number of frames transmitted
RX FRAMES	Number of frames received
TX BYTES	Number of bytes transmitted
RX BYTES	Number of bytes received
FULL STATUS TX FRAMES	Number of Frame Relay signaling packets transmitted out the port
FULL STATUS RX FRAMES	Number of Frame Relay signaling packets received by the port
LINK INTEGRITY STATUS TX FRAMES	Number of Link Integrity signaling packets transmitted out the port
LINK INTEGRITY STATUS RX FRAMES	Number of Link Integrity signaling received by the port
DROP UNKNOWN DLCI	Number of frames received that were not associated with any known PVC
DROP INVALID DLCI	Number of frames received that had illegal DLCIs
CLEAR STATS	When activated, this field will clear all frame relay port stats

L2 PROTOCOL (V35[2]-ATM)> STATUS> PVC(s)

Displays statistics for all the PVCs configured on this port on a PVC basis. The following statistics are available:

DLCI	DLCI number
STATE	Frame relay state
TX FRAMES	Number of frames transmitted
RX FRAMES	Number of frames received
RX BYTES	Number of bytes received
DE COUNT	Number of packets received on an individual DLCI with the DE bit set

CR COUNT	Number of packets received on an individual DLCI with the CR bit set
BECN COUNT	Number of packets received on an individual DLCI with the BECN bit set
FECN COUNT	Number of packets received on an individual DLCI with the FECN bit set
UNKNOWN FRAME	RX Frames received that were not associated with any PVC entries

L2 PROTOCOL (T1 ATM FIRMWARE) – DSX INTERFACE

Configure the **L2 PROTOCOL** parameters and view the status of the integrated DSX interface using items from this menu.

L2 PROTOCOL (T1 ATM – DSX) > CONFIG

Configures the voice parameters for the interface.

INTERFACES (T1 ATM – DSX) > CONFIG > SIGNALING

Configures the voice signaling implemented on the interface. The signaling must match the network application. The choices are:

E&M (TANDEM)	Sets the DSX interface to use E&M signaling.
LOOP START	Sets the DSX interface to use loop start signaling.
GROUND START	Sets the DSX interface to use ground start signaling.
ISDN PRI	Sets the DSX interface to use common channel signaling for ISDN.

INTERFACES (T1 ATM – DSX) > CONFIG > Tx OAM

Configures the Total Access 850 to transmit an Operation, Administration, and Maintenance (OAM) cell to the network (voice gateway) when the DSX interface is down.

INTERFACES (T1 ATM – DSX) > CONFIG > Rx OAM

Configures the Total Access 850 to transmit an alarm condition to the DSX interface when the network (voice gateway) is down.

INTERFACES (T1 ATM – DSX) > CONFIG > LEGACY CONFIG

Digital trunk channel ID's are bits used to identify voice calls being carried within ATM cells. Some gateways do not support higher channel IDs, therefore the Total Access 850 supports CIDs from 16 or 65. The default is **DSX CID FROM 65**.

L2 PROTOCOL (ALL FIRMWARE) – ETH INTERFACE > 802.3 PROTOCOL

Configure the **L2 PROTOCOL** parameters and view the status of the Ethernet interface from this menu.

L2 PROTOCOL (ALL-ETH-802.3) > PROTOCOL

Displays the **L2 PROTOCOL** for the 10/100BaseT Ethernet port. Currently only **802.3** is supported.

L2 PROTOCOL (ALL-ETH-802.3) > CONFIG

Configure the mode for this **10/100BASET** Ethernet port from this menu.

L2 PROTOCOL (ALL-ETH-802.3) > CONFIG > MODE

The mode identifies how the data will be forwarded. The choices are:

ROUTE IP (def)	All IP data will be routed
BRIDGE ALL	All data will be bridged
ROUTE IP/BRIDGE OTHER	All IP data will be routed. All other data will be bridged.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS

View the **L2 PROTOCOL** statistics for the **10/100BASET** Ethernet port from this menu.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > TX PACKETS

Total number of packets transmitted out the Ethernet port.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > RX PACKETS

Total number of packets received from the Ethernet port.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > TX ERRORS

Total number of transmit errors encountered on Ethernet port.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > SINGLE COLLISIONS

Total number of single collisions before successful transmission.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > MULTIPLE COLLISIONS

Total number of multiple collisions before successful transmission.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > EXCESSIVE COLLISIONS

Total number of collisions that resulted in packet being dropped.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > DEFERRED TRANSMISSIONS

Total number of packets deferred due to collisions.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > CARRIER SENSE ERRORS

Total number of carrier sense errors encountered (no link integrity).

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > RX ERRORS

Number of packets received in error and dropped.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > CRCs

Number of packets detected with CRC errors.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > RX COLLISIONS

Number of collisions which occurred during reception.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > NON-ALIGNED

The **NON-ALIGNED** parameter is set when the number of bits received is not divisible by 8.

L2 PROTOCOL (ALL-ETH-802.3) > STATUS > CLEAR COUNTS

Selecting this activator clears all the Ethernet stats.

BRIDGE

Configure the bridge parameters and view bridging statistics from this menu as shown in Figure 7.




Figure 10. Bridge Menu

BRIDGE > CONFIG

Configure the interfaces and bridge table parameters from this menu.

BRIDGE > CONFIG > INTERFACES (T1)

Configure the T1 interface bridging parameters from this menu.

BRIDGE > CONFIG > INTERFACES (T1) > SUB-INTERFACE

The T1 sub-interface is PPP [0.0] if the **L2 PROTOCOL** is set for **PPP**. The [0.0] represents the T1 physical and logical ports respectively. This is a read-only field. The T1 sub-interface is **FRE [0.X]** if the **L2 PROTOCOL** is set for **FRAME RELAY**. The [0.X] represents the T1 physical and logical ports respectively. The T1 physical port is always 0. The X represents the Frame Relay logical port and will be a number between 0-6 corresponding to the interface number under **L2 PROTOCOL > CONFIG > DLCI MAPPING**. This is a read-only field.

BRIDGE > CONFIG > INTERFACES (ETH)

Configure the Ethernet Bridging parameters from this menu.



The ETH interface will not appear as a bridge interface entry if the mode is set to route IP.

BRIDGE > CONFIG > INTERFACES (ETH) > SUB-INTERFACE

The Ethernet sub-interface is 802.3[1.0] represents the Ethernet physical and logical ports, where 1 is the physical port and 0 is the logical port assigned to the Ethernet interface. This is a read-only field.

BRIDGE > CONFIG > BRIDGE TABLE

Configure the bridge table parameters from this menu.

BRIDGE > CONFIG > BRIDGE TABLE > BRIDGE TABLE AGING (0-65535)

BRIDGE TABLE AGING is how soon an entry ages out of the Bridge table (in minutes). Default is **5**.

BRIDGE > STATUS

View the bridging statistics from this menu.

BRIDGE > STATUS > BRIDGE TABLE

View the bridge table status from this menu.

BRIDGE > STATUS > BRIDGE TABLE > MAC ADDRESS

Ethernet address for device learned. This is a read-only field.

BRIDGE > STATUS > BRIDGE TABLE > LOCATION

Location indicates if it is LAN or WAN. This is a read-only field.

BRIDGE > STATUS > BRIDGE TABLE > TTL

Time to Live (TTL) is the number of seconds until the address is removed from the table. This is a read only field.

ROUTER

Configure the router parameters and view routing statistics from this menu as shown in Figure 8.




Figure 11. Router Menu

ROUTER > CONFIG

Configure the interfaces, routes, DHCP Server, and UDP Relay options from this menu.

ROUTER > CONFIG > INTERFACES

Configure the layer 3 options for the Ethernet and T1 interfaces from this menu.

ROUTER > CONFIG > INTERFACES (ETH)

Configure the layer 3 options for the Ethernet parameters from this menu.



*The Ethernet port will always appear in the **ROUTER > CONFIG > INTERFACES** table regardless of the L2 protocol mode setting.*

ROUTER > CONFIG > INTERFACES (ETH) > SUB-INTERFACE

The Ethernet sub-interface is 802.3[1.0]. The [1.0] represents the Ethernet physical and logical ports, where 1 is the physical port and 0 is the logical port assigned to the Ethernet interface. This is a read-only field.

ROUTER > CONFIG > INTERFACES (ETH)> SETUP

Configure the Ethernet addressing, RIP, and Proxy ARP from this menu.

PRIMARY IP

This is used to setup the IP addresses for the LAN on the unit.

IP ADDRESS

The IP address assigned to the unit's Ethernet port is set here. This address must be unique within the network. Default is **10.0.0.1**.

SUBNET MASK

This is the IP network mask that is to be applied to the unit's Ethernet port. Default is **255.255.255.0**.

RIP

Use this menu to enable RIP on the LAN interface.

VERSION

Enables or disables RIP and specifies the RIP protocol. Choices are; **OFF** (which disables RIP), **V1** (RIP Version 1) or **V2** (RIP Version 2). The default is **OFF**.

METHOD

Specifies the way the RIP protocol sends out its advertisements. The following options are available:

- | | |
|----------------------------|--|
| SPLIT HORIZON (DEF) | Only routes not learned from this circuit are advertised. |
| POISON REVERSE | All routes are advertised, but the routes learned from this port are "poisoned" with an infinite metric. The default is Split Horizon. |

DIRECTION

Allows the direction at which RIP advertisements are sent and received to be specified.

- | | |
|------------------------|--|
| TX AND RX (DEF) | RIP advertisements are periodically transmitted and are listened to on this port. |
| TX ONLY | RIP advertisements are periodically transmitted but are not listened to on this port. |
| RX ONLY | RIP advertisements are listened to on this port, but are not transmitted on this port. |

V2 SECRET

Enter the secret used by RIP version 2 here.

PROXY ARP

This feature allows the network portion of a group of addresses to be shared among several physical network segments. The ARP protocol provides a way for devices to create a mapping between physical addresses and logical IP addresses. Proxy ARP makes use of this mapping feature by instructing a router to answer ARP requests as a "proxy" for the IP addresses behind one of its ports. The device which sent the ARP request will then correctly assume that it can reach the requested IP address by sending packets to the physical address that was returned. This technique effectively hides the fact that a network has been (further) subnetted. If this option is set to **YES**, when an ARP request is received on the Ethernet port the address is looked up in the IP routing table. If the forwarding port is not on the Ethernet port and the route is not the default route, the unit will answer the request with its own hardware address. Default is **No**.

SECONDARY IPs

This allows the unit to specify additional IP addresses and networks on its Ethernet. The maximum number of entries is 5.

NUM

Displays the index number in the secondary IP list.

IP ADDRESS

This is the second IP address the unit will respond to on the Ethernet. Default is **0.0.0.0**.

SUBNET MASK

This is the mask for the network. Default is **255.255.255.255**.

NAT MODE

This mode specifies whether Network Address Translation (NAT) should be used on this interface. When this mode is set to **PRIVATE** (def) NAT is automatically specified on this interface. The other choice is **PUBLIC** which specifies **not** going through NAT.

ROUTER > CONFIG > INTERFACES (NET)

Configure the layer 3 options for the network interface from this menu.



*The network interface will display in the **ROUTER > CONFIG > INTERFACES** table showing the name of the network technology (i.e. T1 or SDSL), but only once a PVC to the router (ATM) or DS0s to the router (TDM) have been configured.*

ROUTER > CONFIG > INTERFACES (NET) > SUB-INTERFACE

This is a read-only field which displays the physical and logical port of the interface using the following nomenclature: [A.B], where A represents the physical port (network interface is 0, Ethernet is 1) and B represents the logical port for the Layer 2 protocol (i.e. PVC for Frame Relay, PPP link, etc.) Each configured logical port is assigned a number corresponding to the order in which they are listed in the L2 Protocol configuration fields.

ROUTER > CONFIG > INTERFACES (NET)> SETUP

Configure the IP parameters for this interface and sub-interface from this menu.

ACTIVE

This Selection enables IP on this PVC.

VPI

ATM virtual port identifier assigned to this sub-interface in the **L2 PROTOCOL** menus. This field is only applicable when L2 protocol for this sub-interface is ATM.

VCI

ATM virtual channel identifier assigned to this sub-interface in the **L2 PROTOCOL** menus. This field is only applicable when L2 protocol for this sub-interface is ATM.

DLCI

Data Link Connection Identifier assigned to this PVC in the **L2 PROTOCOL** menus. This field is only applicable when L2 protocol for this sub-interface is **FRE**.

ADDRESS MODE

Specifies the method the unit uses to determine the local and far-end IP addresses. The choices are **USER SPECIFIED** (default), **DHCP CLIENT**, or **IARP**. **USER SPECIFIED** allows the user configuration for Local IP and Far-End IP addresses, **DHCP CLIENT** is used for the Total Access 850 to learn his IP address from a DHCP server. **IARP** allows the unit to determine the far-end IP address using inverse ARP.

LOCAL IP ADDRESS

This is the IP address for this PCV. This field is not visible when **ADDRESS MODE** is set to **DHCP CLIENT**.

IP NETMASK

This is the network mask used for this interface. This field is not visible when **ADDRESS MODE** is set to **DHCP CLIENT**.

FAR-END IP ADDRESS

This is the address of the NEXT hop router on this interface. This field is only visible when **ADDRESS MODE** is set to **USER SPECIFIED**.

MTU

Specifies the maximum size for a packet transmitted on this PVC. Default is **1500**. This field is only valid when L2 protocol for this sub-interface is **FRE**.

NAT

Use this menu to set up and use Network Address Translation on this interface.

PORT TRANSLATION

By enabling port translation, IP packets are modified as they pass through this interface. During transmission, private addresses are translated into a single public (NAPT) IP address. Incoming packets are translated from the public to private address based on the protocol port numbers. Once enabled, additional menus appear and can be used to further customize the NAT configuration. The default is **DISABLED**.

PUBLIC IP ADDRESS MODE

Sets the public NAPT address used for translating. Choices are **INTERFACE** (default) and **SPECIFIED**. Selecting **INTERFACE** configures NAT to use the IP address already specified on the interface; the NAPT address and the interface address are the same. Using **SPECIFIED** defines a particular IP address used as the NAPT address.

PUBLIC IP ADDRESS

This menu only appears when the **PUBLIC IP ADDRESS MODE** is set to **SPECIFIED**, and allows the user to enter a specific NAPT address.

TRANSLATE BODY OF UNMAPPED PARTS

Enabling this function forces NAPT to translate the body of any unmapped solicited traffic originating from the LAN. Default is **DISABLED**.

TRANSLATION TABLE

Table used for defining addresses and port translations. This is an indexed list of all translations defined for the router. It specifies the translations for specified public addresses/ports to private addresses/ports. To insert a new translation entry, highlight the index number of the first translation and press the **<I>** key. To delete a particular entry, highlight the index number of the entry and press the **<D>** key. The **TRANSLATION TABLE** parameter descriptions follow.

PUBLIC ADDRESS MODE

Choose **NAPT ADDR** (default) or **SPECIFIED** to choose which address to use for this translation. Choosing **SPECIFIED** allows the user to define a different public IP address to use for this translation.

PUBLIC ADDRESS

This menu appears when the **PUBLIC ADDRESS MODE** is set to **SPECIFIED**, and allows the user to enter a specific IP address as the NAPT address for this translation.

PROTOCOL MODE

Defines the protocol of the data for this translation. Choices are **TCP**, **UDP**, **ICMP**, **TCP OR UDP**, **ICMP**, **ALL**, **SPECIFIED**, or **NONE** (default). Use this option to specify whether you want to translate a specific protocol, group of protocols, or all protocols.

PROTOCOL

This menu appears when the **PROTOCOL MODE** is set to **SPECIFIED**. Use this option to specify a protocol number that does not appear in the list of choices under the Protocol Mode menu. The most common protocols are:

Protocol Number	Keyword	Protocol
1	ICMP	Internet Control Message
6	TCP	Transmission Control
8	EGP	Exterior Gateway Protocol
17	UDP	User Datagram
47	GRE	General Routing Encapsulation
50	ESP	IPSEC Encap Security Payload
51	AH	IPSEC Authentication Header

PROTOCOL TYPE

(Read only) This menu appears when the **PROTOCOL MODE** is set to **SPECIFIED** and displays the name of the specified protocol number (if the name is known by the Total Access 850). For example, entering a value of 47 in the **PROTOCOL** field will cause the **PROTOCOL TYPE** field to display **GRE**.

PUBLIC PORT MODE

This option appears when the **PROTOCOL MODE** is configured with a single protocol (such as TCP, UDP, or ICMP). Choices are **ANY PORT** (default) and **SPECIFIED**. The public destination port associated with this entry can be specified to add more control over certain types of traffic. Leave this configured as **ANY PORT** to cover all port types.

PUBLIC PORT

This menu appears when the **PUBLIC PORT MODE** is set to **SPECIFIED**. Use this option to specify the public port number to translate. Some well known TCP/UDP port numbers are shown below:

Port Number	Keyword	Port Type
20	FTP (data)	File Transfer Protocol Data
21	FTP (control)	File Transfer Protocol Control
23	Telnet	TCP/IP terminal emulation utility
666	DOOM	DOOM
53	DNS	Domain Name Server
69	TFTP	Trivial File Transfer Protocol
80	HTTP	Hypertext Transfer Protocol
110	POP3	Post Office Protocol ver. 3

PRIVATE ADDRESS MODE

Choose **ANY INTERNAL** (default) or **SPECIFIED** to choose which address to use for the private address. The private IP address can be specified to filter certain protocols and ports to specific servers in the private network. Likewise, internal hosts can be steered to certain servers on the public network. A new request from the public network that matches this entry's public parameters is dropped if the **PRIVATE ADDRESS MODE** is set to **ANY INTERNAL** (with the exception of protocols that the internal router is expected to respond to, such as ICMP or SNMP).

PRIVATE ADDRESS

This menu appears when the **PRIVATE ADDRESS MODE** is set to **SPECIFIED**, and allows the user to enter a specific private IP address for this translation. Packets destined for the public IP address (of this translation) are redirected to the private IP address specified here.

PRIVATE PORT MODE

Select **ANY PORT** (default) or a **SPECIFIED** port number for this translation. The private destination port associated with this entry can be specified to provide more control over certain types of traffic. Leave configured as **ANY PORT** to cover all port types.

PRIVATE PORT MODE

This menu appears when the **PRIVATE PORT MODE** is set to **SPECIFIED**, and allows the user to enter the port number that replaces the public port number during the translation of incoming packets. Outgoing packets from the private address space that match this protocol are sent to the specified public address and port, if any.

TRANSLATE BODY

If set to **YES**, the application payload in the packet is scanned for occurrences of the private/public IP address in binary or ASCII form. Set this to **NO** for applications where scanning payload data is undesirable.

NAT VIEW

Provides the user a dynamic view of current active router translations. Once the router has translated an inbound or outbound packet, the translation appears in this table. The main view is a listing of all the translations performed thus far. In order to see the detailed view of one of the entries, select the entry index number and press **<ENTER>**. The NAT View parameters are as follows:

PRIVATE ADDRESS

Private IP address of the active translation.

PUBLIC ADDRESS

Public IP address of the active translation.

SERVER ADDRESS

Server IP address of the public device.

PROTOCOL

Type of protocol active on the translation.

PRIVATE PORT

Private port number used for the translation.

SPOOFED PORT

Spoofed port number for the translation. The Total Access 850 often needs to use the spoofed ports to determine which private device to translate the packet to. This would be necessary if multiple applications using the same private port were occurring simultaneously.

SERVER PORT

Port number used by the server (public device).

TOTAL TIME UNUSED

Time the translation has been unused, in seconds.

IN COUNT

Number of inbound packets using this translation.

OUT COUNT

Number of outbound packets using this translation.

NAPT ADDRESS

(Read only) Displays the NAPT address for the router. This will either be the interface address or the user-specified NAPT address.

ENTRY COUNT

The number of translation entries that are currently available in the **NAT VIEW** table. The Total Access 850 supports up to 2000 active translations at any one time.

ENTRY OVERFLOW COUNT

The number of overflow **NAT VIEW** entries. After the maximum number of translations is reached, the Total Access 850 will not add new translations, but continues to keep a count of any new translation requests it cannot accommodate.

RIP

Use this menu to enable RIP on this interface.

VERSION

Enables or disables RIP and specifies the RIP protocol. Choices are: **OFF** (which disables RIP), **V1** (RIP Version 1) or **V2** (RIP Version 2). The default is **OFF**

METHOD

Specifies the way the RIP protocol sends out its advertisements. The following options are available:

SPLIT HORIZON

(Default) Only routes not learned from this circuit are advertised.

POISON REVERSE

All routes are advertised, but the routes learned from this point are “poisoned” with an infinite metric.

DIRECTION

Allows the direction at which RIP advertisements are sent and received to be specified.

ROUTER > CONFIG > ROUTES

Configures the default gateway and static routes from this menu.

ROUTER > CONFIG > ROUTES > DEFAULT GATEWAY

The default gateway is used by the unit to send IP packets whose destination addresses are not found in the route table (otherwise known as the gateway of last resort). Default is **0.0.0.0**. This is a default gateway for the entire unit, not just for the Ethernet port.

ROUTER > CONFIG > ROUTES > STATIC ROUTES

Use this menu to enter static routes to other networks.

NUM

Displays the index number in the static route table.

ACTIVE

Adds this static route entry to the IP routing table when set to **YES** and removes it (if it was previously added) if set to **NO**. Default is **NO**.

IP ADDRESS

The IP address of the host or network address of the device being routed to. Default is **0.0.0.0**.

SUBNET MASK

Determines the bits in the previous IP address that are used. If this is to be a host route, it must be set to all ones (255.255.255.255). Default is **0.0.0.0**.

GATEWAY

The IP address of the router to receive the forwarded IP packet. Default is **0.0.0.0**.

HOPS

The number of router hops required to get to the network or host. Maximum distance is 16 hops. Default is **1**.

PRIVATE

When set to **No**, the unit will advertise this static route using RIP. Setting to **Yes** means that the route is kept private. Default is **No**.

ROUTER > CONFIG > DHCP SERVER

Use this menu to set up the DHCP server.

ROUTER > CONFIG > DHCP SERVER > DHCP SERVER

Use this menu to enable the DHCP server (**ON** or **OFF**).

ROUTER > CONFIG > DHCP SERVER > DHCP ADDRESS POOLS

Configures the parameters for the various defined DHCP address pools. Multiple DHCP address pools may be defined using these menus.

NUM

Displays the index number of the defined DHCP address pools. Multiple address pools are valid, and all will be listed in sequential order. This number is for reference only.

NAME

Enter a user-defined alphanumeric text string for the defined DHCP address pool. This text string is for easy identification and reference only.

TYPE

Configures the DHCP address pool as either a Network or Host pool.

LEASE CONFIG

Configures the lease duration for an IP address from this pool assigned by the DHCP server to a host on the network.

LEASE DAYS, HOURS, MINUTES

Defines the lease duration (in days, hours, and minutes) for an IP address from this pool assigned by the DHCP server to a host on the network.

NETWORK ADDRESS

Defines the network address for the configured address pool (for example, 172.24.0.0). The **NETWORK ADDRESS** and **NETWORK MASK** determine the number of addresses available on the network for the configured pool.

NETWORK MASK

Defines the network mask associated with the network address for the configured address pool (for example, 255.255.0.0). The **NETWORK ADDRESS** and **NETWORK MASK** determine the number of addresses available on the network for the configured pool.

POOL INFO

Configures various network parameters assigned to all hosts given an IP address from the configured address pool.

NETWORK MASK

Defines the network mask associated with the network address for the configured address pool (for example, 255.255.0.0). The **NETWORK ADDRESS** and **NETWORK MASK** determine the number of addresses available on the network for the configured pool.

DEFAULT ROUTER (PRI)

Defines the primary default router IP address (in dotted decimal notation) for all hosts given an IP address from the configured pool. When specifying a router to use as the primary/secondary preferred router, verify that the listed router is on the same subnet as the DHCP client.

DEFAULT ROUTER (SEC)

Defines the secondary default router IP address (in dotted decimal notation) for all hosts given an IP address from the configured pool. When specifying a router to use as the primary/secondary preferred router, verify that the listed router is on the same subnet as the DHCP client.

DNS SERVER (PRI)

Defines the primary Domain Name Server IP address (in dotted decimal notation) for all hosts given an IP address from the configured pool.

DNS SERVER (SEC)

Defines the secondary Domain Name Server IP address (in dotted decimal notation) for all hosts given an IP address from the configured pool.

NBNS SERVER (PRI)

Defines the primary NetBIOS Windows Internet Naming Service (WINS) name server IP address (in dotted decimal notation) available for use by the Dynamic Host Configuration Protocol (DHCP) clients.

NBNS SERVER (SEC)

Defines the secondary NetBIOS Windows Internet Naming Service (WINS) name server IP address (in dotted decimal notation) available for use by the Dynamic Host Configuration Protocol (DHCP) clients.

NBNS NODE TYPE

Defines the type of NetBIOS node used with Dynamic Host Configuration Protocol (DHCP) clients. The following node types are available:

- b-node (1) - **BROADCAST** node
- p-node (2) - **PEER-TO-PEER** node
- m-node (4) - **MIXED** node
- h-node (8) - **HYBRID** node (Recommended)

ROUTER > CONFIG > DHCP SERVER > EXCLUSION RANGES

Defines any IP address (or range of addresses) that should not be used the Total Access 850 DHCP server when making IP assignments to hosts on the network.

NUM

Displays the index number of the listed IP address exclusion ranges. Multiple address exclusions are valid, and all will be listed in sequential order. This number is for reference only.

START

Configures the start IP address (in dotted decimal notation) for the range of IP addresses to exclude from the DHCP address pool. Use in conjunction with the **END** field to establish a range of IP addresses. To exclude a single IP address, enter the same address in both the **START** and **END** fields.

END

Configures the ending IP address (in dotted decimal notation) for the range of IP addresses to exclude from the DHCP address pool. Use in conjunction with the **START** field to establish a range of IP addresses. To exclude a single IP address, enter the same address in both the **START** and **END** fields.

ROUTER > CONFIG > DHCP SERVER > GLOBAL SERVER OPTIONS

Configures various network parameters that apply to all hosts given an IP address from the configured address pools (regardless of the pool). Use these commands to configure parameters for all address pools when customizing between the address pools is not necessary. Refer to *Pool Info* on page 159 for more details on the available parameters.

ROUTER > CONFIG > UDP RELAY

This menu configures the unit to act as a UDP relay agent for applications requiring a response from UDP hosts that are not on the same network segment as their clients.

ROUTER > CONFIG > UDP RELAY > MODE

When this option is set to **ON**, the unit will act as a relay agent. Default is **OFF**.

ROUTER > CONFIG > UDP RELAY > UDP RELAY LIST

Up to four relay destination servers can be specified in this list.

#

Indicates the entry number in the UDP Relay List table.

RELAY ADDRESS

This is the IP address of the server that will receive the relay packet. Default is **0.0.0.0**.

UDP PORT TYPE

The choices are **STANDARD** (def) and **SPECIFIED**. The following standard UDP protocols are relayed when set: DHCP, TFTP, DNS, NTP (Network Time Protocol, port 123), NBNS (NetBios Name Server, port 137), NBDG (NetBIOS Datagram, port 138), and BootP. When **SPECIFIED** is set, the UDP port (1 to 65535) can be specified in the UDP Port columns (up to three per server).

UDP PORT 1, 2, 3

Used for specifying UDP ports to be relayed. These fields only apply when **UDP PORT TYPE** is set to **SPECIFIED**. Default is **0**.

ROUTER > STATUS

View the **IP ROUTES**, **IP STATS**, **ARP CACHE**, **DHCP SERVER**, and **DHCP CLIENT** statistics from this menu.

ROUTER > STATUS > IP ROUTES

This lists the contents of the unit's IP route table.

ROUTER > STATUS > IP ROUTES > IP ADDRESS

Network or host destination address.

ROUTER > STATUS > IP ROUTES > NETMASK

Network mask applied to the destination address.

ROUTER > STATUS > IP ROUTES > GATEWAY

Host or router to receive this packet.

ROUTER > STATUS > IP ROUTES > PORT

Port gateway is located on:

LOCAL	Sent directly to the unit's router
ETH0	The unit's Ethernet port
WAN0	The unit's first PPP bundle
FR 0 . . . FR 9	The unit is connected up to 10 DLCIs

ROUTER > STATUS > IP ROUTES > USE

Number of times the unit has referenced the route.

ROUTER > STATUS > IP ROUTES > FLAGS

Important tags associated with this route entry

H	route is a host route
G	route is a gateway route
S	static route, or learned via IPCP, IARP, DHCP
R1	learned from RIP Version 1
R2	learned from RIP Version 2
I	route learned from an ICMP redirect
C	directly connected interface
P	route is private and is not advertised with RIP
T	route is to a triggered port (updates only when table changes)
U	learned by unknown method

ROUTER > STATUS > IP ROUTES > HOPS

Number of routers that must go through to get to destination. Ranges from **0-15** or **16** for infinite (can't get there from here).

ROUTER > STATUS > IP ROUTES > TTL

Seconds until address is removed from table. Value of 999 means route is static.

ROUTER > STATUS > IP STATS

This section describes the following **STATISTICS** submenus (and see the tables on the pages following):

- IP
- ICMP
- TCP
- UDP

All of these statistics are taken from the MIB-II variables in RFC 1156. To clear the accumulated statistics, press the **<ENTER>** key on **CLEAR COUNTS**.

ROUTER > STATUS > IP STATS > IP

View the IP statistics from this menu.

DEFAULT TTL

The default value inserted into the Time-To-Live field of the IP header of datagrams originated at this unit, whenever a TTL value is not supplied by the transport layer protocol.

IP DATAGRAMS RECEIVED

The total number of input datagrams received from interfaces, including those received in error.

BAD HEADER PACKETS

The number of input datagrams discarded due to errors in their IP headers, including bad check sums, version number mismatch, other format errors, time-to-live exceeded, errors discovered in processing their IP options, etc.

BAD IP ADDRESSES

The number of input datagrams discarded because the IP address in their IP header's destination field was not a valid address to be received at this unit. This count includes invalid addresses (e.g., 0.0.0.0) and addresses of unsupported Classes (e.g., Class E). For entities which are not IP Gateways and therefore do not forward datagrams, this counter includes datagrams discarded because the destination address was not a local address.

TOTAL FORWARDED DATAGRAMS

The number of input datagrams for which this unit was not their final IP destination, as a result of which an attempt was made to find a route to forward them to that final destination. In entities which do not act as IP Gateways, this counter will include only those packets which were Source-Routed via this unit, and the Source-Route option processing was successful.

BAD PROTOCOL DISCARDS

The number of locally-addressed datagrams received successfully but discarded because of an unknown or unsupported protocol.

DATAGRAMS DISCARDED

The number of input IP datagrams for which no problems were encountered to prevent their continued processing, but which were discarded (e.g., for lack of buffer space). Note that this counter does not include any datagrams discarded while awaiting re-assembly.

SENT DATAGRAMS TO UPPER LYERS

The total number of input datagrams successfully delivered to IP user-protocols (including ICMP).

IP DATAGRAMS SENT

IP packets from the unit's IP stack.

ERRORFREE DISCARDS

The number of output IP datagrams for which no problem was encountered to prevent their transmission to their destination, but which were discarded (e.g., for lack of buffer space). Note that this counter would include datagrams counted in **TOTAL FORWARDED DATAGRAMS** if any such packets met this (discretionary) discard criterion.

ROUTELESS DISCARDS

The number of IP datagrams discarded because no route could be found to transmit them to their destination. Note that this counter includes any packets counted in **TOTAL FORWARDED DATAGRAMS** which meet this "no-route" criterion. Note also that this includes any datagrams which a host cannot route because all of its default gateways are down.

IP REASSEMBLY TIMEOUT

The maximum number of seconds received fragments are held while awaiting reassembly at this unit.

DISASSEMBLED FRAGMENTS

The number of IP fragments received which needed to be reassembled at this unit.

IP DATAGRAMS REASSEMBLED

The number of IP datagrams successfully reassembled.

IP REASSEMBLY FAILURES

The number of failures detected by the IP reassembly algorithm (for whatever reason: timed out, errors, etc.). Note that this is not necessarily a count of discarded IP fragments since some algorithms (notably RFC 815s) can lose track of the number of fragments by combining them as they are received.

SUCCESSFUL FRAGMENTS

The number of IP datagrams that have been successfully fragmented at this unit.

FAILED FRAGMENTS

The number of IP datagrams that have been discarded because they needed to be fragmented at this unit but could not be e.g., because their “Don't Fragment” flag was set.

TOTAL IP FRAGMENTS

The number of IP datagram fragments that have been generated as a result of fragmentation at this unit.

DISCARDED ROUTING ENTRIES

A packet the unit couldn't route.

CLEAR COUNTS

Setting this activator clears the IP Statistics.

ROUTER > STATUS > IP STATS > ICMP**ICMP MESSAGES RECEIVED**

The total number of ICMP messages the unit received. Note that this counter includes all those counted by **ICMP SPECIFIC ERRORS**.

ICMP SPECIFIC ERRORS

The number of ICMP messages the unit received but determined as having errors (bad ICMP checksums, bad length, etc.)

ICMP DEST. UNREACHABLE MSGS RCVD

The number of ICMP Destination Unreachable messages received.

ICMP TIMEOUTS RECEIVED

The number of ICMP Time Exceeded messages received.

ICMP PARAMETER PROBLEM MSGS RCVD

The number of ICMP Parameter Problem messages received.

ICMP SOURCE QUENCH MSGS RCVD

The number of ICMP Source Quench messages received.

ICMP REDIRECTED MESSAGES RCVD

The number of ICMP Redirect messages received.

ICMP ECHO REQUEST MSGS RCVD

The number of ICMP Echo (request) messages received.

ICMP ECHO REPLY MSGS RCVD

The number of ICMP Echo Reply messages received.

ICMP TIMESTAMP REQUEST MSGS RCVD

The number of ICMP Timestamp (request) messages received.

ICMP TIMESTAMP REPLY MSGS RCVD

The number of ICMP Timestamp Reply messages received.

ICMP ADDRESS MASK REQUEST MSGS RCVD

The number of ICMP Address Mask Request messages received.

ICMP ADDRESS MASK REPLY MSGS RCVD

The number of ICMP Address Mask Reply messages received.

ICMP MESSAGES SENT

The total number of ICMP messages this unit attempted to send. Note that this counter includes all those counted by **ICMP PACKET ERRORS**.

ICMP PACKET ERRORS

The number of packets the unit did not send due to problems discovered within ICMP such as a lack of buffers. This value should not include errors discovered outside the ICMP layer such as the inability of IP to route the resultant datagram. In some implementations there may be no types of error which contribute to this counter's value.

ICMP DEST. UNREACHABLE MSGS SENT

The number of ICMP Destination Unreachable messages sent.

ICMP TIME EXCEEDED MSGS SENT

The number of ICMP Time Exceeded messages sent.

ICMP PARAMETER PROBLEM MSGS SENT

The number of ICMP Parameter Problem messages sent.

ICMP SOURCE QUENCH MSGS SENT

The number of ICMP Source Quench messages sent.

ICMP REDIRECT MSGS SENT

The number of ICMP Redirect messages sent.

ICMP ECHO REQUEST MSGS SENT

The number of ICMP Echo (request) messages sent.

ICMP ECHO REPLY MSGS SENT

The number of ICMP Echo Reply messages sent.

ICMP TIMESTAMP REQUEST MSGS SENT

The number of ICMP Timestamp (request) messages sent.

ICMP TIMESTAMP REPLY MSGS SENT

The number of ICMP Timestamp Reply messages sent.

ICMP ADDR MASK REQUEST MSGS SENT

The number of ICMP Address Mask Request messages sent.

ICMP ADDR MASK REPLY MSGS SENT

The number of ICMP Address Mask Reply messages sent.

CLEAR COUNTS

Selecting this activator will clear the ICMP statistics.

ROUTER > STATUS > IP STATS > UDP

View the UDP statistics from this menu.

UDP DATAGRAMS RECEIVED

The total number of UDP datagrams delivered to UDP users.

NO APPLICATION AT DEST. PORT

The total number of received UDP datagrams for which there was no application at the destination port.

UDP BAD PACKETS

The number of received UDP datagrams that could not be delivered for reasons other than the lack of an application at the destination port.

UDP DATAGRAMS SENT

The total number of UDP datagrams sent from this unit.

CLEAR COUNTS

Selecting this activator clears the UDP statistics.

ROUTER > STATUS > IP STATS > UDP TABLE

View the UDP table statistics from this menu.

LOCAL IP ADDRESS

The destination IP address of the packet

PORT

The destination UDP port of the packet.

ROUTER > STATUS > IP STATS > TCP

View the TCP statistics from this menu.

RETRANSMISSION TIMEOUT ALGORITHM

The algorithm used to determine the timeout value used for retransmitting unacknowledged octets.

MIN RETRANSMISSION TIMEOUT (MS)

The minimum value permitted by a **TCP** implementation for the retransmission timeout, measured in milliseconds. More refined semantics for objects of this type depend upon the algorithm used to determine the retransmission timeout. In particular, when the timeout algorithm is **rsre(3)**, an object of this type has the semantics of the **LBOUND** quantity described in RFC 793.

MAX RETRANSMISSION TIMEOUT (MS)

The maximum value permitted by a TCP implementation for the retransmission timeout, measured in milliseconds. More refined semantics for objects of this type depend upon the algorithm used to determine the retransmission timeout. In particular, when the timeout algorithm is **rsre(3)**, an object of this type has the semantics of the **UNBOUND** quantity described in RFC 793.

MAX TCP CONNECTIONS

The limit on the total number of **TCP** connections the unit can support. In entities where the maximum number of connections is dynamic, this object should contain the value -1.

ACTIVE TCP CONNECTIONS

The number of times **TCP** connections have made a direct transition to the **SYN-SENT** state from the **CLOSED** state.

TCP PASSIVE CONNECTIONS

The number of times **TCP** connections have made a direct transition to the **SYN-RCVD** state from the **LISTEN** state.

TCP FAILED ATTEMPTS

The number of times **TCP** connections have made a direct transition to the **CLOSED** state from either the **SYN-SENT** state or the **SYN-RCVD** state, plus the number of times **TCP** connections have made a direct transition to the **LISTEN** state from the **SYN-RCVD** state.

TOTAL TCP RESETS

The number of times **TCP** connections have made a direct transition to the **CLOSED** state from either the **ESTABLISHED** state or the **CLOSE-WAIT** state.

TCP CURRENT CONNECTIONS

The number of **TCP** connections for which the current state is either **ESTABLISHED** or **CLOSE-WAIT**.

TCP SEGMENTS RECEIVED

The total number of segments received, including those received in error. This count includes segments received on currently established connections.

TCP SEGMENTS SENT

The total number of segments sent, including those on current connections but excluding those containing only retransmitted octets.

TOTAL TCP RETRANSMITS

The total number of segments retransmitted -- that is, the number of **TCP** segments transmitted containing one or more previously transmitted octets.

CLEAR COUNTS

Selecting this activator clears the **TCP** statistics.

ROUTER > STATUS > IP STATS > TCP CONNS

View the TCP Conns Statistics from this menu. This table shows the different states of each TCP connection.

STATE

The possible states are **FREE**, **CLOSED**, **LISTEN**, **SYNC SENT**, **SYNC RECEIVED**, **ESTABLISHED**, **FINWAIT1**, **FINWAIT2**, **CLOSEWAIT**, **LASTACK**, **CLOSING**, and **TIMEWAIT**.

LOCAL IP ADDRESS

Local IP address of the TCP connection.

LOCAL PORT

Local port of the TCP connection.

REMOTE IP ADDRESS

Remote IP address of the TCP connection.

REMOTE PORT

Remote port of the TPC connection.

ROUTER > STATUS > ARP CACHE

This lists the contents of the units's ARP table. All resolved cache entries time out after 20 minutes. Unresolved entries time out in 3 minutes. The ARP cache can be cleared by pressing "f" while on the menu or by pressing "d" on the individual number for that entry.

ROUTER > STATUS > ARP CACHE > IP ADDRESS

IP address used for resolving MAC address.

ROUTER > STATUS > ARP CACHE > MAC ADDRESS

Ethernet address resolved (0=no resolution).

ROUTER > STATUS > ARP CACHE > TIME

Minutes since entry was first entered into the ARP cache.

SECURITY

Configure the **SECURITY FILTERS** and **RADIUS SERVER** parameters from this menu as shown in Figure 12.




Figure 12. Security Menu

SECURITY > FILTERS

Configure the filter characteristics from this menu.

SECURITY > FILTERS > FILTER DEFINES

The unit can filter packets based on certain parameters within the packet. The method used by the unit allows the highest flexibility for defining filters and assigning them to a PVC or PPP link. The filters are set up in two steps: (1) defining the filter types, and (2) applying them to a list under the PVC or PPP configuration. This menu is used to define the individual filter defines based on packet type.



The Filter Defines option applies to both Frame Relay and PPP operation.

SECURITY > FILTERS > FILTER DEFINES > MAC FILTER DEFINES

The MAC filter is applied to bridge packets only. Bridge packets which are forwarded by the bridge functionality of the unit are defined here. Up to 32 MAC defines can be specified.

NUM

Indicates the entry number in the MAC Filter Defines table.

NAME

Identifies the filter entry. Default is no entry in **NAME** field.

FILTER TYPE

Specifies a **NORMAL** or **DEBUG** filter. When a **NORMAL** filter is applied to an interface, traffic is blocked or forwarded according to the filter. When a **DEBUG** filter is applied, packets that match the filter are documented without affecting traffic flow. (Use the **DEBUG** filter with the Syslog or Terminal Mode logging to view the packet contents.)

SRC ADDR

48-bit MAC source address used for comparison. Values are in hexadecimal format. Default is **00:00:00:00:00:00**.

SRC MASK

Bits in the MAC source address which are compared. Values are in hexadecimal format. Default is **00:00:00:00:00:00**.

DEST ADDR

48-bit MAC destination address used for comparison. Values are in hexadecimal format. Default is **00:00:00:00:00:00**.

DEST MASK

Bits in the MAC destination address used for comparison. Values are in hexadecimal format. Default is **00:00:00:00:00:00**.

TYPE

16-bit type field used for comparison. Values are in hexadecimal format. Default is **00:00**.

TYPE MASK

Bits in the type field used for comparison. Values are in hexadecimal format. Default is **00:00**.

SECURITY > FILTERS > FILTER DEFINES > PATTERN FILTER DEFINES

The pattern filter is applied to bridge packets only. That is any packet which is forwarded by the bridge functionality of the unit. Up to 32 pattern defines can be specified.

NUM

Indicates the entry number in the Pattern Filter Defines table.

NAME

Identifies the filter entry. Default is no entry in **NAME** field.

FILTER TYPE

Specifies a **NORMAL** or **DEBUG** filter. When a **NORMAL** filter is applied to an interface, traffic is blocked or forwarded according to the filter. When a **DEBUG** filter is applied, packets that match the filter are documented without affecting traffic flow. (Use the **DEBUG** filter with the Syslog or Terminal Mode logging to view the packet contents.)

OFFSET

Offset from beginning of packet of where to start the pattern comparison. Default is **0**.

PATTERN

64 bits used for comparison. Values are in hexadecimal format. Default is **00:00:00:00:00:00:00:00**.

MASK

Bits in the pattern to be compared. Values are in hexadecimal format. Default is **00:00:00:00:00:00:00:00**.

SECURITY > FILTERS > FILTER DEFINES > IP FILTER DEFINES

The IP filter defines apply to any IP packet, whether it is routed or bridged. Up to 32 IP defines can be specified.

NUM

Indicates the entry number in the IP Filter Defines table.

NAME

Identifies the filter entry. Default is no entry in name field.

FILTER TYPE

Specifies a **NORMAL** or **DEBUG** filter. When a **NORMAL** filter is applied to an interface, traffic is blocked or forwarded according to the filter. When a **DEBUG** filter is applied, packets that match the filter are documented without affecting traffic flow. (Use the **DEBUG** filter with the Syslog or Terminal Mode logging to view the packet contents.)

SRC ADDR

IP address compared to the source address. Value is in dotted decimal format. Default is **0.0.0.0**.

SRC MASK

Bits which are used in the source comparison. Value is in dotted decimal format. Default is **0.0.0.0**.

DEST ADDR

IP address compared to the destination address. Value is in dotted decimal format. Default is **0.0.0.0**.

DEST MASK

Bits which are used in the destination comparison. Value is in dotted decimal format. Default is **0.0.0.0**.

SRC PORT

IP source port number used for comparison. Value is in decimal format. Range: **0 - 65535**. Default is **0**.

SRC PORT COMP

Type of comparison that is performed. Default is **NONE**.

= means ports equal to

NOT = means port not equal to

> means port greater than

< means port less than

None - means the source port is not compared

DEST PORT

IP destination port number used for comparison. Value is in decimal format. Range: **0 - 65535**. Default is **0**.

DEST PORT COMP

Type of comparison that is performed. Default is **NONE**.

= means ports equal to

NOT = means port not equal to

> means port greater than

< means port less than

None - means the source port is not compared

PROTOCOL

Protocol used for comparison. Value is in decimal format. Range: **0 - 255**. Default is **0**.

PROTOCOL COMP

Type of comparison that is performed. Default is **NONE**.

= means ports equal to

NOT = means port not equal to

> means port greater than

< means port less than

None - means the source port is not compared

TCP ESTAB

Yes - only when TCP established

No - only when TCP not established

Ignore - ignore TCP flags (def)

SECURITY > FILTERS > INTERFACES

The unit can block packets in and out of an interface by use of the filters. They are set up in two steps: 1) define the types of packets that would be of interest in the **SECURITY > FILTERS > FILTER DEFINES** menu, and 2) set up the filter type and combination of defines that will cause a packet block.

SECURITY > FILTERS > INTERFACES (ETH)

Define the filters for the Ethernet interface from this menu.

SECURITY > FILTERS > INTERFACES (ETH) > SUB-INTERFACE

The Ethernet sub-interface is 802.3[1.0]. This is a read-only field.

SECURITY > FILTERS > INTERFACES (ETH) > SET-UP

Enable the Ethernet interface filtering and define filters from this menu.

IN FROM VC

The packets which come into the unit can be filtered in three ways:

DISABLE (DEF)	Turns off packet input filtering. No incoming packets are blocked.
BLOCK ALL	All incoming packets from the WAN are blocked except as defined in the SECURITY > FILTERS > INTERFACES > SETUP > IN EXCEPTIONS list.
FORWARD ALL	All incoming packets from the WAN are not blocked except as defined in the SECURITY > FILTERS > INTERFACES > SETUP > IN EXCEPTIONS list.

IN EXCEPTIONS

This is a list of up to 32 filter entries which can be combined using the operations field. The operations are performed in the order they appear on the list.

#

Indicates the entry number in the In Exceptions table.

ACTIVE

Turns this entry active when set to **YES**. Default is **NO**.

TYPE

Selects the filter define list to reference (default is **MAC**).

MAC	from the SECURITY > FILTERS > FILTER DEFINES > MAC FILTER DEFINES list.
PATTERN	from the SECURITY > FILTERS > FILTER DEFINES > PATTERN FILTER DEFINES list.
IP	from the SECURITY > FILTERS > FILTER DEFINES > IP FILTER DEFINES list.

FILTER LIST NAME

Selects between filters defined in the list. Default is no entry in filter list name.

NEXT OPER

The next operation to use to combine with the next filter in the list (default is **END**).

END	the last filter to combination.
AND	logically AND this filter with the next filter in the list.
OR	logically OR this filter with the next filter in the list.

HIT COUNT

Displays the number of packets that match the criteria for the defined filter.

OUT TO VC

The packets which come from the unit to the WAN can be filtered in three ways:

DISABLE (DEF)	Turns off packet outputs filtering. No outgoing packets are blocked.
BLOCK ALL	All outgoing packets to the WAN are blocked except as defined in the SECURITY > FILTERS > INTERFACES > SETUP > OUT EXCEPTIONS list.
FORWARD ALL	All outgoing packets to the WAN are not blocked except as defined in the SECURITY > FILTERS > INTERFACES > INTERFACES > SETUP > OUT EXCEPTIONS list.

OUT EXCEPTIONS

This is a list of up to 32 filter entries which can be combined using the operations field. The operations are performed in the order they appear on the list.

#

Indicates the entry number in the In Exceptions table.

ACTIVE

Turns this entry active when set to **YES**. Default is **NO**.

TYPE

Selects the filter define list to reference (default is **MAC**):

MAC	from the SECURITY > FILTERS > FILTER DEFINES > MAC FILTER DEFINES list.
PATTERN	from the SECURITY > FILTERS > FILTER DEFINES > PATTERN FILTER DEFINES list.
IP	from the SECURITY > FILTERS > FILTER DEFINES > IP FILTER DEFINES list.

FILTER LIST NAME

Selects between filters defines in the list. Default is no entry in filter list name.

NEXT OPER

The next operation to use to combine with the next filter in the list (default is **END**):

- END** the last filter to combination.
- AND** logically AND this filter with the next filter in the list.
- OR** logically OR this filter with the next filter in the list.

HIT COUNT

Displays the number of packets that match the criteria for the defined filter.

SECURITY > RADIUS SERVER

The parameters for the **RADIUS SERVER** are configured in this menu.



Telnet radius is only available in A.04 firmware or later.

SECURITY > RADIUS SERVER > SERVER 1

This is the IP address of the first **RADIUS SERVER** that the unit should attempt to communicate with when authenticating a Telnet session. Default is **0.0.0.0**.

SECURITY > RADIUS SERVER > SERVER 2

This is the IP address of the second **RADIUS SERVER** that the unit should attempt to communicate with when the primary server does not respond. Default is **0.0.0.0**.

SECURITY > RADIUS SERVER > SERVER 3

This is the IP address of the third **RADIUS SERVER** that the unit should attempt to communicate with when the primary server does not respond. Default is **0.0.0.0**.

SECURITY > RADIUS SERVER > UDP PORT

This is the UDP port the unit should use when communicating with the **RADIUS SERVER**. The default is **1812**, which the commonly used port.

SECURITY > RADIUS SERVER > SECRET

The **RADIUS SERVER** and unit share this text string. It is used by the **RADIUS SERVER** to authenticate the unit, the **RADIUS** client. The factory default is not to use a secret.

SECURITY > RADIUS SERVER > RETRY COUNT (1-10)

This is the number of times the unit should send a request packet to the **RADIUS SERVER** without a response before giving up. If the number of attempts to communicate with the primary server is equal to the retry count, the second server (if defined) is tried. If the second server does not respond within the retry count the third server (if defined) is tried. If the third server does not respond within the retry count, the Telnet session is not authenticated and is dropped. The default is **5**.

DS0 MAPS



The DS0 Maps configuration fields only apply for T1 TDM applications.

The **DS0 MAPS** menu allows you to map data and voice ports to the network T1 time slots. You may edit either of the two maps at any time. If you make changes to the current map, only those DS0s that have changed will be updated (unchanged DS0s will not be affected.) The DS0 menu is shown in Figure 13.




Figure 13. DS0 Maps Menu

DS0 MAPS > ACTIVE MAP

Activates one of the two dedicated maps (**MAP 1** or **MAP 2**), or the **DUAL T1 MAP**. In the **DUAL T1** mode, the built-in DSX-1 interface DSX[3] can be utilized as a secondary T1 connection. In **DUAL T1** mode, the second T1 is limited to voice connections on FXS and FXO modules. For example, the user may map all 24 DS0s on the network T1 to the router, and on the second T1 (DSX-1 interface) map all 24 DS0s to the FXS cards. Default is **MAP 1**.

DS0 MAPS > APPLY TEMPLATE TO MAP 1

Choices are **CURRENT MAP 1**, **CURRENT MAP 2**, **D4 MAP**, **D1D MAP**, **FULL ROUTER**, and **CLEAR MAP**. Default is **CURRENT MAP 1**. **D4 MAP** automaps the voice port in a 1-to-1 configuration. **D1D MAP** maps voice ports in an SLC-96 configuration. **FULL ROUTER** maps all 24 DS0s to the router at 64K. **CLEAR MAP** clears the entire map.

DS0 MAPS > EDIT/VIEW MAP 1

Define map 1. The map allows the user to assign services and ports to the individual DS0s 1-24.



In the default configuration for TDM A.04.XX firmware, DS0 24 is mapped to the router at 64K on Map 1.

DS0 MAPS > EDIT/VIEW MAP 1 > DS0

Displays the network T1 time slot to be assigned.

DS0 MAPS > EDIT/VIEW MAP 1 > SLOT

When you select this option, a list of all of the slots and the modules displays. This first option **OPEN**, when unassigns the slot if selected. For modules, the slot number and name are shown. For example, **FXS** indicates that an FXS card is installed. Use **TA IAD** to map network timeslot to the **V.35** port or to the router. Pick the appropriate server, and press **<ENTER>**. Default is **OPEN**.

DS0 MAPS > EDIT/VIEW MAP 1 > PORT

When you select this option, a list of ports appears. Pick the appropriate port, and press **<ENTER>**. The selection list shows only the remaining ports available to be assigned. It may be necessary to unassign a port in order to reassign it elsewhere.

DS0 MAPS > EDIT/VIEW MAP 1 > RBS

Robbed Bit Signaling. Default is **N/A**. Once a **SLOT** and port are assigned, this will automatically change to **ON** or **OFF**. The unit automatically assigns **OFF** where **RBS** is not an option. **ON** preserves the signaling bits between the connections. **OFF** ignores the signaling bits. For the **FXS**, **RBS** defaults to **ON**. The **RBS** parameter remains at **N/A** for the **TA IAD**, because **RBS** is not applicable to data connections.

**NOTE**

Map 2 menus are identical to Map 1. Please use the menu explanations above for Map 2.

4. APPENDICES (T1 TDM APPLICATIONS)

Appendix A. Configuring the Unit for Routing

Initial Setup

It is best to configure Total Access 850 TDM applications by following the order of the top-level menus. For example, first configure the system parameters using the **SYSTEM INFO** and **SYSTEM CONFIG** menus. Next, configure the Layer 1 parameters using the **INTERFACES** menu. Once the Layer 1 information is configured, proceed to the Layer 2 setup using the **L2 PROTOCOL** menus. Follow the Layer 2 setup with the data “routing” menus (either **BRIDGE** or **ROUTER**). Establish packet forwarding and blocking using the **SECURITY** menus. Lastly, configure the physical mappings using the **DS0 MAPS** menu.



The following example provides step by step instructions for configuring the Total Access 850 T1 TDM system (**INTERFACES** through **DS0 MAPS**) for a standard routing application. System Info and System Config parameters should be set according to your system need. Refer to *System Info* on page 73 and *System Config* on page 75 for more details.

1. Setting up the Interfaces

For more details on the configuration parameters discussed in this section, refer to the following pages:

Network T1 menus beginning on page 94

Ethernet menus beginning on page 101

T1 Interface Setup Instructions	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the T1 interface and press <ENTER> .
3	Right arrow to select FORMAT and choose ESF or SF .
 NOTE	<i>This format must match the format used by the other units in the network.</i>
4	Set the LINE CODE to B8ZS or AMI .
 NOTE	<i>This line code must match the line code used by the other units in the network.</i>
5	Set the EQUALIZATION or line build out. The default setting of 0 dB is usually sufficient.
6	Set the CSU LPBK option to ENABLE , DISABLE , or DISABLE ALL based on whether looping to this unit from another unit will be allowed.

Ethernet Interface Setup Instructions	
Most applications should not require a manual setup for the Ethernet interface. By default, the Ethernet interface is configured to auto-detect the data rate (as either 10 or 100 Mbps). The following steps disable the auto-negotiation parameter and manually configure the interface.	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the ETH interface and press <ENTER> .
3	Use the right arrow to select AUTONEGOTIATION and press <ENTER> . Use the down arrow to choose OFF .
4	Select the DATA RATE field and specify either 10BASET or 100BASET .
5	Select the DUPLEX TYPE field and specify either HALF DUPLEX or FULL DUPLEX .


2. Configuring the Layer 2 Protocol

For more details on the configuration parameters discussed in this section, refer to the following pages:

Layer 2 Frame Relay Protocol menus beginning on [page 121](#)

Layer 2 PPP Protocol menus beginning on [page 118](#)

Layer 2 Ethernet menus beginning on [page 144](#)

Layer 2 Protocol (FRE) Configuration – T1 Interface	
Step	Action
1	From the main menu, select L2 PROTOCOL and press <ENTER> .
2	Use the arrow keys to select the PROTOCOL field for the T1 interface. Press <ENTER> . Select FRE from the list of available protocols.
3	Highlight the CONFIG menu for the T1 interface and press <ENTER> .
4	Set the MAINTENANCE PROTOCOL to ANNEX D (ANSI) , ANNEX A (q933a) , LMI , or STATIC (no sig) .
 NOTE	<i>The MAINTENANCE PROTOCOL should be set based on the Frame Relay switch.</i>
5	Down arrow and press <ENTER> on DLCI MAPPING . Press the right arrow key to create an entry. To create additional entries, highlight the NUM field and press the <I> key. To delete an entry, highlight the NUM field for the entry to delete and press the <D> key.
6	Set ACTIVE to YES .

Layer 2 Protocol (FRE) Configuration – T1 Interface (Continued)	
7	Set DLCI to the DLCI number. This DLCI should match what is programmed in the network Frame Relay switch.
8	Set mode to ROUTE IP . Using this menu you also have the option to route only IP packets and bridge all other data packets (ROUTE IP/BRIDGE OTHER) or bridge all data packets on this PVC (BRIDGE ALL).
9	Left arrow back to the main menu to save the changes.

Layer 2 Protocol (PPP) Configuration – T1 Interface	
Step	Action
1	From the main menu, select L2 PROTOCOL and press <ENTER> .
2	Use the arrow keys to select the PROTOCOL field for the T1 interface. Press <ENTER> . Select PPP from the list of available protocols.
3	Highlight the CONFIG menu for the T1 interface and press <ENTER> .
4	Set mode to ROUTE IP . Using this menu you also have the option to route only IP packets and bridge all other data packets (ROUTE IP/BRIDGE OTHER) or bridge all data packets on this connection (BRIDGE ALL).
5	Highlight AUTHENTICATION and press <ENTER> to change options related to how the link is established. Default is TX METHOD = NONE and RX METHOD = NONE . If TX METHOD and RX METHOD are set to any option other than NONE , TX/RX USERNAME and PASSWORD options appear. The Total Access 850 supports various combinations of PAP, CHAP, and EAP for PPP authentication. Refer to <i>L2 Protocol (T1 TDM-T1-PPP) > Config > Authentication</i> on page 118 for more details.
6	Left arrow out of the AUTHENTICATION menus, highlight the PPP menu, and press <ENTER> . Use the PPP menus to configure parameters associated with the PPP link. Refer to <i>L2 Protocol (T1 TDM-T1-PPP) > Config</i> on page 118 for more details.
7	Left arrow back to the main menu to save the changes.

Layer 2 Protocol Configuration – Ethernet Interface	
Step	Action
1	From the main menu, select L2 PROTOCOL and press <ENTER> .
2	Highlight the CONFIG menu for the ETH (Ethernet) interface and press <ENTER> .

Layer 2 Protocol Configuration – Ethernet Interface (Continued)	
3	Set mode to ROUTE IP . Using this menu you also have the option to route only IP packets and bridge all other data packets (ROUTE IP/BRIDGE OTHER) or bridge all data packets on this connection (BRIDGE ALL). Refer to <i>L2 Protocol (ALL-ETH-802.3) > Config > Mode</i> on page 144 for more details.
4	Left arrow back to the main menu to save the changes.

3. Setting the Router Options

For more details on the configuration parameters discussed in this section, refer to the following pages:

Router Ethernet Interface Configuration menus beginning on [page 148](#)

Router Network Interface Configuration menus beginning on [page 148](#)

Router Default Gateway menus beginning on [page 157](#)

Router Options – Ethernet Interface	
Step	Action
1	From the main menu, select ROUTER and press <ENTER> .
2	Use the right arrow key to highlight CONFIG and press <ENTER> .
3	Select INTERFACES and press <ENTER> . Use the right arrow key to highlight the SETUP field for the ETH (Ethernet) interface and press <ENTER> .
4	Highlight the PRIMARY IP field and press <ENTER> .
5	Set the IP ADDRESS of the Ethernet port.
6	Set the SUBNET MASK for the Ethernet port.
7	By default, RIP is disabled on the Ethernet interface. If RIP needs to be enabled, highlight the RIP field and press <ENTER> . Set the appropriate VERSION , RIP METHOD , DIRECTION , and V2 SECRET (where applicable) to configure RIP on the interface. For more details, refer to <i>Router > Config > Interfaces (ETH) > Sub-Interface</i> on page 148.
8	Press the left arrow key to return to the Ethernet sub-interface menu (displays PRIMARY IP and SECONDARY IP).
9	If your application requires additional secondary IP address, highlight the SECONDARY IP field and press <ENTER> . The Total Access 850 supports up to 5 additional LAN segments. Enter each additional secondary IP address and corresponding subnet mask. To add a new IP address entry, highlight the NUM field and press the <I> key. To delete an existing entry, highlight the NUM field for the entry to delete and press the <D> key.
10	Left arrow back to the main menu to save the changes.


Router Options – T1 Interface (L2 Protocol = FRE or PPP)	
Step	Action
1	From the main menu, select ROUTER and press <ENTER>.
2	Use the right arrow key to highlight CONFIG and press <ENTER>.
3	Select INTERFACES and press <ENTER>. Use the right arrow key to highlight the SETUP field for the T1 interface and press <ENTER>. Each PVC (frame relay) on the T1 interface defined in the DLCI MAP has a separate listing in the ROUTER INTERFACES table.
4	Set ACTIVE to YES to activate the virtual circuit.
5	Select the desired ADDRESS MODE . Refer to <i>Address Mode</i> on page 151 for more details.
6	Enter the Total Access 850 LOCAL IP ADDRESS and corresponding IP NETMASK for the selected virtual circuit.
7	Enter the IP address for the next hop router in the FAR-END IP ADDRESS field.
8	For NAT configuration, refer to <i>Appendix C. RFC1483 Quick Start (IP Routing with NAT)</i> on page 209.
9	Left arrow back to the main menu to save the changes.

Router Options – Setting the Default Gateway	
Step	Action
1	From the main menu, select ROUTER and press <ENTER>.
2	Use the right arrow key to highlight CONFIG and press <ENTER>.
3	Select ROUTES and press <ENTER>. Set the DEFAULT GATEWAY field to the appropriate IP address.
4	Left arrow back to the main menu to save the changes.

4. Mapping the DS0s

For more details on the configuration parameters discussed in this section, refer to the following pages:

DS0 Map menus beginning on page 180

DS0 Mapping Instructions	
Step	Action
1	From the main menu, select DS0 MAPS .
2	<p>Verify that the ACTIVE MAP is set to either MAP 1 or MAP 2. This is the map that is actively running on the unit. The unit has the ability to store two maps.</p> <ul style="list-style-type: none"> • To edit the current map, press <ENTER> on EDIT/VIEW MAP 1 to view the map. (If Map 1 is the Active Map) • To edit the standby map, press <ENTER> on EDIT/VIEW MAP 2 to view the map. (If Map 2 is the Active Map)
 NOTE	<i>The DS0 listed on the left side of the menu corresponds to DS0s (1 through 24) on the network T1 interface. At least one DS0 must be mapped to the ROUTER to utilize the Total Access 850 for routing purposes.</i>
3	Scroll down to the DS0 that will be mapped. (Any DS0 can be mapped to the router.)
4	Set the SERVICE for the DS0 that you are mapping to TA IAD .
5	Set the PORT of the DS0 that you are mapping to ROUTER 64K or ROUTER 56K .
6	Map all the DS0s as desired, and exit this menu by pressing the left arrow button. Your changes will automatically save when exiting the map.
7	Make sure the ACTIVE MAP is set to the correct map (the map you want running) before exiting the DS0 MAPS menu.
8	Left arrow back to the main menu.

Appendix B. Configuring the Unit for Bridging

Initial Setup

It is best to configure Total Access 850 TDM applications by following the order of the top-level menus. For example, first configure the system parameters using the **SYSTEM INFO** and **SYSTEM CONFIG** menus. Next, configure the Layer 1 parameters using the **INTERFACES** menu. Once the Layer 1 information is configured, proceed to the Layer 2 setup using the **L2 PROTOCOL** menus. Follow the Layer 2 setup with the data “routing” menus (either **BRIDGE** or **ROUTER**). Establish packet forwarding and blocking using the **SECURITY** menus. Lastly, configure the physical mappings using the **DS0 MAPS** menus.



The following example provides step by step instructions for configuring the Total Access 850 T1 TDM system (**INTERFACES** through **DS0 MAPS**) for a standard bridging application. System Info and System Config parameters should be set according to your system need. Refer to *System Info* on page 73 and *System Config* on page 75 for more details.

1. Setting up the Interfaces

For more details on the configuration parameters discussed in this section, refer to the following pages:

Network T1 menus beginning on [page 94](#)

Ethernet menus beginning on [page 101](#)

T1 Interface Setup Instructions	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the T1 interface and press <ENTER> .
3	Right arrow to select FORMAT and choose ESF or SF .
 NOTE	<i>This format must match the format used by the other units in the network.</i>
4	Set the LINE CODE to B8ZS or AMI .
 NOTE	<i>This line code must match the line code used by the other units in the network.</i>
5	Set the EQUALIZATION or line build out. The default setting of 0 dB is usually sufficient.
6	Set the CSU LPBK option to ENABLE , DISABLE , or DISABLE ALL based on whether looping to this unit from another unit will be allowed.

Ethernet Interface Setup Instructions	
Most applications should not require a manual setup for the Ethernet interface. By default, the Ethernet interface is configured to auto-detect the data rate (as either 10 or 100 Mbps). The following steps disable the auto-negotiation parameter and manually configure the interface.	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the ETH interface and press <ENTER> .
3	Use the right arrow to select AUTONEGOTIATION and press <ENTER> . Use the down arrow to choose OFF .
4	Select the DATA RATE field and specify either 10BASET or 100BASET .
5	Select the DUPLEX TYPE field and specify either HALF DUPLEX or FULL DUPLEX .


2. Configuring the Layer 2 Protocol

For more details on the configuration parameters discussed in this section, refer to the following pages:

Layer 2 Frame Relay Protocol menus beginning on [page 121](#)

Layer 2 PPP Protocol menus beginning on [page 118](#)

Layer 2 Ethernet menus beginning on [page 144](#)

Layer 2 Protocol (FRE) Configuration – T1 Interface	
Step	Action
1	From the main menu, select L2 PROTOCOL and press <ENTER> .
2	Use the arrow keys to select the PROTOCOL field for the T1 interface. Press <ENTER> . Select FRE from the list of available protocols.
3	Highlight the CONFIG menu for the T1 interface and press <ENTER> .
4	Set the MAINTENANCE PROTOCOL to ANNEX D (ANSI) , ANNEX A (q933a) , LMI , or STATIC (no sig) .
 NOTE	<i>The MAINTENANCE PROTOCOL should be set based on the Frame Relay switch.</i>
5	Down arrow and press <ENTER> on DLCI MAPPING . Press the right arrow key to create an entry. To create additional entries, highlight the NUM field and press the <I> key. To delete an entry, highlight the NUM field for the entry to delete and press the <D> key.
6	Set ACTIVE to YES .

Layer 2 Protocol (FRE) Configuration – T1 Interface (Continued)	
7	Set DLCI to the DLCI number. This DLCI should match what is programmed in the network Frame Relay switch.
8	Set mode to BRIDGE ALL . Using this menu you also have the option to route only IP packets and bridge all other data packets (ROUTE IP/BRIDGE OTHER) or route all IP data packets on this PVC (ROUTE IP).
9	Left arrow back to the main menu to save the changes.

Layer 2 Protocol (PPP) Configuration – T1 Interface	
Step	Action
1	From the main menu, select L2 PROTOCOL and press <ENTER> .
2	Use the arrow keys to select the PROTOCOL field for the T1 interface. Press <ENTER> . Select PPP from the list of available protocols.
3	Highlight the CONFIG menu for the T1 interface and press <ENTER> .
4	Set mode to BRIDGE ALL . Using this menu you also have the option to route only IP packets and bridge all other data packets (ROUTE IP/BRIDGE OTHER) or route all IP data packets on this connection (ROUTE IP).
5	Highlight AUTHENTICATION and press <ENTER> to change options related to how the link is established. Default is TX METHOD = NONE and RX METHOD = NONE . If TX METHOD and RX METHOD are set to any option other than NONE , TX/RX USERNAME and PASSWORD options appear. The Total Access 850 supports various combinations of PAP, CHAP, and EAP for PPP authentication.
6	Left arrow out of the AUTHENTICATION menus, highlight the PPP menu, and press <ENTER> . Use the PPP menus to configure parameters associated with the PPP link. Refer to <i>L2 Protocol (T1 TDM–T1–PPP) > Config</i> on page 118 for more details.
7	Left arrow back to the main menu to save the changes.

Layer 2 Protocol Configuration – Ethernet Interface	
Step	Action
1	From the main menu, select L2 PROTOCOL and press <ENTER> .
2	Highlight the CONFIG menu for the ETH (Ethernet) interface and press <ENTER> .
3	Set mode to BRIDGE ALL . Using this menu you also have the option to route only IP packets and bridge all other data packets (ROUTE IP/BRIDGE OTHER) or route all IP data packets on this connection (ROUTE IP). Refer to <i>L2 Protocol (ALL–ETH–802.3) > Config</i> on page 144 for more details.
4	Left arrow back to the main menu to save the changes.

3. Verifying the Bridge Options

For more details on the configuration parameters discussed in this section, refer to the following pages:


Bridge menus beginning on page 145

Bridge Options	
Step	Action
1	From the main menu, select BRIDGE and press <ENTER> .
2	Use the right arrow key to highlight CONFIG and press <ENTER> .
3	Select INTERFACES and press <ENTER> . Verify that the desired interface is listed in this table.
4	Left arrow back to the BRIDGE > CONFIG menu.
5	Select BRIDGE TABLE and set the BRIDGE TABLE AGING to the desired time (in minutes) it takes an entry to age out of the Bridge table.
6	Left arrow back to the main menu to save the changes.

4. Mapping the DS0s

For more details on the configuration parameters discussed in this section, refer to the following pages:

DS0 Map menus beginning on page 180

DS0 Mapping Instructions	
Step	Action
1	From the main menu, select DS0 MAPS .
2	Verify that the ACTIVE MAP is set to either MAP 1 or MAP 2 . This is the map that is actively running on the unit. The unit has the ability to store two maps. <ul style="list-style-type: none"> To edit the current map, press <ENTER> on EDIT/VIEW MAP 1 to view the map. (If Map 1 is the Active Map) To edit the standby map, press <ENTER> on EDIT/VIEW MAP 2 to view the map. (If Map 2 is the Active Map)
 NOTE	<i>The DS0 listed on the left side of the menu corresponds to DS0s (1 through 24) on the network T1 interface. At least one DS0 must be mapped to the ROUTER to utilize the Total Access 850 for routing purposes.</i>
3	Scroll down to the DS0 that will be mapped. (Any DS0 can be mapped to the router.)
4	Set the SERVICE for the DS0 that you are mapping to TA IAD .

DS0 Mapping Instructions (Continued)	
5	Set the PORT of the DS0 that you are mapping to ROUTER 64K or ROUTER 56K .
6	Map all the DS0s as desired, and exit this menu by pressing the left arrow button. Your changes will automatically save when exiting the map.
7	Make sure the ACTIVE MAP is set to the correct map (the map you want running) before exiting the DS0 MAPS menu.
8	Left arrow back to the main menu.

Appendix C. Configuring the Unit for Voice Applications

Initial Setup

It is best to configure Total Access 850 TDM applications by following the order of the top-level menus. For example, first configure the system parameters using the **SYSTEM INFO** and **SYSTEM CONFIG** menus. Next, configure the Layer 1 parameters using the **INTERFACES** menu. Once the Layer 1 information is configured, proceed to the Layer 2 setup using the **L2 PROTOCOL** menus. Follow the Layer 2 setup with the data “routing” menus (either **BRIDGE** or **ROUTER**). Establish packet forwarding and blocking using the **SECURITY** menus. Lastly, configure the physical mappings using the **DS0 MAPS** menus.



The following example provides step by step instructions for configuring the Total Access 850 T1 TDM system (**INTERFACES** through **DS0 MAPS**) for a standard voice application. System Info and System Config parameters should be set according to your system need. Refer to *System Info* on page 73 and *System Config* on page 75 for more details.


1. Setting up the Interfaces


For more details on the configuration parameters discussed in this section, refer to the following pages:

Network T1 menus beginning on page 94

FXS menus beginning on page 103

T1 Interface Setup Instructions	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the T1 interface and press <ENTER> .
3	Right arrow to select FORMAT and choose ESF or SF .
 NOTE	<i>This format must match the format used by the other units in the network.</i>
4	Set the LINE CODE to B8ZS or AMI .
 NOTE	<i>This line code must match the line code used by the other units in the network.</i>
5	Set the EQUALIZATION or line build out. The default setting of 0 dB is usually sufficient.
6	Set the CSU LPBK option to ENABLE , DISABLE , or DISABLE ALL based on whether looping to this unit from another unit will be allowed.


FXS Interface Setup Instructions	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the FXS interface and press <ENTER> .
3	Right arrow to select MODE and choose LOOP START , GROUND START , TANDEM (E&M) , TR08 SINGLE , TR08 UVG , or DPO .
 NOTE	<i>This mode should be set based on the network configuration and the operation of each FXS port. All FXS ports are independent and do not need to have the same mode.</i>
4	Set the Tx (dB) or transmit direction level for each port. The default value is recommended.
5	Set the Rx (dB) or received direction level for each port. The default value is recommended.
6	Set the SVC MODE to IN SERVICE to activate the port.
7	Set the LINE Z (line impedance) of each port based on the size of the network. The default value is recommended.
8	Set the MSG IND to DISABLE or ENABLE . When set to ENABLE , talk path is always open, even in on-hook conditions, in order for FXS message tones to pass through. Disabling this feature will allow higher on-hook voltage but will not allow on-hook messaging other than caller ID.
9	Configure the on-hook battery voltage using the BATT MODE field. For most IAD installs, the FXS loop is short with 6 to 7 V present on tip / ring. To reduce power dissipated during off-hook conditions, the battery is lowered for short loop lengths. When set to AUTO SWITCH , the IAD uses a higher on-hook battery voltage (48-52 V). When off-hook, it automatically switches to low battery (24-26 V) to minimize power dissipation. When set to LOW BATTERY mode, the higher battery is not used and the voltage is a constant 26 V even while on-hook. The tip/ring voltage is reduced to 26 V when using the LOW BATTERY mode.
10	Specify the interval of battery removal during a forward disconnect state using the FWD DISC TIMER field. Choices are FOLLOW SWITCH (default), 500MS , 750MS , 1000MS , and 2000MS . When using ATM mode, there is an additional choice of IGNORE SWITCH . If the timer is set to FOLLOW SWITCH , the Total Access 850 will follow the switch at all times; this is normal operation. If a time period has been selected, the Total Access 850 will remove battery for the specified time period OR as long as the switch requests battery removal, whichever is longer. For example, if the timer expires but the switch continues to request battery removal, the Total Access 850 will follow the switch and continue to remove battery. For ATM mode, if the timer is set to IGNORE SWITCH , the IAD will never remove battery.

FXS Interface Setup Instructions (Continued)	
11	Press <ENTER> on the TANDEM [+] option to view the TANDEM options if the port mode is set to TANDEM (E&M) .
12	Set the CONVERSION MODE of the port to either LOOP START or GROUND START .
13	Set the SUPERVISION of the port to either IMMEDIATE or WINK .
 NOTE	<i>Be sure to set the TANDEM options for each port set to TANDEM E&M.</i>

2. Mapping the DS0s

For more details on the configuration parameters discussed in this section, refer to the following pages:

DS0 Map menus beginning on [page 180](#)

DS0 Mapping Instructions	
Step	Action
1	From the main menu, select DS0 MAPS .
2	Verify that the ACTIVE MAP is set to either MAP 1 or MAP 2 . This is the map that is actively running on the unit. The unit has the ability to store two maps. <ul style="list-style-type: none"> To edit the current map, press <ENTER> on EDIT/VIEW MAP 1 to view the map. (If Map 1 is the Active Map) To edit the standby map, press <ENTER> on EDIT/VIEW MAP 2 to view the map. (If Map 2 is the Active Map)
 NOTE	<i>The DS0 listed on the left side of the menu corresponds to DS0s (1 through 24) on the network T1 interface.</i>
3	Scroll down to the DS0 that will be mapped.
4	Set the SERVICE for the DS0 that you are mapping to FXS .
5	Set the PORT of the DS0 that you are mapping. The port number entered must match the voice port the DS0 is being mapped to. RBS (robbed bit signaling) will automatically turn on when a port number has been selected.
6	Map all the DS0s as desired, and exit this menu by pressing the left arrow button. Your changes will automatically save when exiting the map.
7	Make sure the ACTIVE MAP is set to the correct map (the map you want running) before exiting the DS0 MAPS menu.
8	Left arrow back to the main menu.

Appendix D. Configuring the Unit for DSX-1 Applications

The Total Access 600 Series systems are available with an integrated DSX-1 interface for both voice and data applications. Regardless of the application (either voice or data), the Total Access 850 has the ability to map DS0s from the network T1 to DS0s on the DSX-1 interface (cross-connect) without affecting the data present on the DS0s. This feature allows the Total Access 850 to support voice with dedicated signaling channels (ISDN), voice with in-channel signaling information (Robbed Bit Signaling (RBS) to a PBX, key system, etc.), as well as clear channel data to an external T1 router.

Initial Setup

It is best to configure Total Access 850 TDM applications by following the order of the top-level menus. For example, first configure the system parameters using the **SYSTEM INFO** and **SYSTEM CONFIG** menus. Next, configure the Layer 1 parameters using the **INTERFACES** menu. Once the Layer 1 information is configured, proceed to the Layer 2 setup using the **L2 PROTOCOL** menus. Follow the Layer 2 setup with the data “routing” menus (either **BRIDGE** or **ROUTER**). Establish packet forwarding and blocking using the **SECURITY** menus. Lastly, configure the physical mappings using the **DS0 MAPS** menu.

The following example provides details for configuring the Total Access 850 to pass analog voice over the DSX-1 interface (using RBS), digital voice (fractional PRI with D-Channel), and data bandwidth. The Total Access 850 provides a single DSX-1 interface, so it is unlikely that your application will require all three features on the DSX-1 interface simultaneously; therefore ignore any steps that do not pertain to your application.


Perform the following steps in order to configure the applications (**INTERFACES** through **DS0 MAPS**). **SYSTEM INFO** and **SYSTEM CONFIG** parameters should be set according to your system need. Refer to *System Info* on page 73 and *System Config* on page 75 for more details.


1. Setting up the Interfaces



For more details on the configuration parameters discussed in this section, refer to the following pages:

Network T1 menus beginning on [page 94](#)

DSX-1 menus beginning on [page 109](#)

T1 Interface Setup Instructions	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the T1 interface and press <ENTER> .
3	Right arrow to select FORMAT and choose ESF or SF .
 NOTE	<i>This format must match the format used by the other units in the network.</i>
4	Set the LINE CODE to B8ZS or AMI .


T1 Interface Setup Instructions (Continued)	
 NOTE <i>This line code must match the line code used by the other units in the network.</i>	
5	Set the EQUALIZATION or line build out. The default setting of 0 dB is usually sufficient.
6	Set the CSU LPBK option to ENABLE , DISABLE , or DISABLE ALL based on whether looping to this unit from another unit will be allowed.

DSX-1 Interface Setup Instructions	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the DSX interface and press <ENTER> .
3	Right arrow to select FORMAT and choose ESF or SF .
 NOTE <i>This FORMAT must match the format used by the equipment connected to the DSX-1 interface. A FORMAT mismatch normally results in a Red Alarm condition.</i>	
4	Set the LINE CODE to B8ZS or AMI .
 NOTE <i>This line code must match the line code used by the equipment connected to the DSX-1 interface.</i>	
5	Set the EQUALIZATION or line build out. The default setting of 0 dB is usually sufficient.
6	Set the CSU LPBK option to ENABLE , DISABLE , or DISABLE ALL based on whether looping to this unit from another unit will be allowed.

2. Mapping the DS0s

For more details on the configuration parameters discussed in this section, refer to the following pages:

DS0 Map menus beginning on [page 180](#)

DS0 Mapping Instructions	
Step	Action
1	From the main menu, select DS0 MAPS .
2	<p>Verify that the ACTIVE MAP is set to either MAP 1 or MAP 2. This is the map that is actively running on the unit. The unit has the ability to store two maps.</p> <ul style="list-style-type: none"> • To edit the current map, press <ENTER> on EDIT/VIEW MAP 1 to view the map. (If Map 1 is the Active Map) • To edit the standby map, press <ENTER> on EDIT/VIEW MAP 2 to view the map. (If Map 2 is the Active Map)
	<p><i>The DS0 listed on the left side of the menu corresponds to DS0s on the network T1 interface. The PORT number identifies the DS0 on the DSX-1 interface. The DS0 and PORT do not need to match; DS0s can be cross-connected from the network T1 to any DS0 on the DSX-1 interface.</i></p>
3	Scroll down to the DS0 that will be mapped. (Any DS0 can be mapped to the DSX-1 interface.)
4	Set the SERVICE for the DS0 that you are mapping to DSX-1 .
5	Set the PORT of the DS0 that you are mapping. The port number entered specifies the DS0 on the DSX-1 interface and can be set to any available DS0. When mapping voice circuits with dedicated signaling channels, be sure to map the signaling channel to the proper DS0 on the DSX-1 interface. For example, ISDN D channel signaling is normally carried on DS0 24. Unless the equipment connected to the Total Access 850 DSX-1 interface has been specifically programmed, it will expect a D channel on DS0 24. Map DS0 24 to Port 24 to provide the D channel in the appropriate timeslot.
6	Set RBS to OFF or ON depending on the application. When passing voice circuits with in-channel signaling through to the DSX-1 interface, signaling bits are preserved by setting RBS to ON . For clear channel service to the DSX-1 interface (for voice circuits with a dedicated signaling channel and all data) set RBS to OFF (which ignores the signaling bits).
7	Map all the DS0s as desired, and exit this menu by pressing the left arrow button. Your changes will automatically save when exiting the map.
8	Make sure the ACTIVE MAP is set to the correct map (the map you want running) before exiting the DS0 MAPS menu.
9	Left arrow back to the main menu.

5. APPENDICES (T1 ATM APPLICATIONS)



The following example is for configuring T1 units with ATM firmware. However, all units using ATM firmware (SDSL, ADSL, SHDSL) may be configured in the same manner. To configure ATM Voice applications with other network types, disregard the T1 Interface Setup Instructions and configure your network interface as needed.

Appendix A. Voice Gateway Quick Start Procedure (Voice Turn Up)

A typical VoATM application (see Figure 7) uses a Total Access 850 connected to an ATM network. For voice applications, a Voice Gateway is needed to interface with the PSTN. Jetstream, Tollbridge, CopperCom, and LES-CAS are popular Gateway types.




Figure 7. Application Diagram

To configure a Total Access 850 for use with the Voice Gateway, you need to know the VPI and VCI used on the ATM network to access the Gateway from this Total Access 850. You also need to know the format for **IDLE CELLS** and whether **DATA SCRAMBLING** is used on this ATM network. The following procedure will help you navigate the Total Access 850 menus for configuring the necessary elements for VoATM with the Voice Gateway.

Perform the following steps in order to configure the application.

Initial Setup

It is best to configure Total Access 850 ATM applications by following the order of the top-level menus. For example, first configure the system parameters using the **SYSTEM INFO** and **SYSTEM CONFIG** menus. Next, configure the Layer 1 parameters using the **INTERFACES** menu. Once the Layer 1 information is configured, proceed to the Layer 2 setup using the **L2 PROTOCOL** menus.



The following example provides step by step instructions for configuring the Total Access 850 T1 ATM system (**INTERFACES** and **L2 PROTOCOL**) for a standard voice application. System Info and System Config parameters should be set according to your system need. Refer to *System Info* on page 73 and *System Config* on page 75 for more details.


1. Setting up the Interfaces


For more details on the configuration parameters discussed in this section, refer to the following pages:

Network T1 menus beginning on page 94

FXS menus beginning on page 103

T1 Interface Setup Instructions	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the T1 interface and press <ENTER> .
3	Right arrow to select FORMAT and choose ESF or SF .
 NOTE	<i>This format must match the format used by the other units in the network.</i>
4	Set the LINE CODE to B8ZS or AMI .
 NOTE	<i>This line code must match the line code used by the other units in the network.</i>
5	Set the EQUALIZATION or line build out. The default setting of 0 dB is usually sufficient.
6	Set the CSU LPBK option to ENABLE , DISABLE , or DISABLE ALL based on whether looping to this unit from another unit will be allowed.

FXS Interface Setup Instructions	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the FXS interface and press <ENTER> .
3	Right arrow to select MODE and choose LOOP START , GROUND START , TANDEM (E&M) , TR08 SINGLE , TR08 UVG , or DPO .
 NOTE	<i>This mode should be set based on the network configuration and the operation of each FXS port. All FXS ports are independent and do not need to have the same mode.</i>
4	Set the Tx (dB) or transmit direction level for each port. The default value is recommended.
5	Set the Rx (dB) or received direction level for each port. The default value is recommended.
6	Set the SVC MODE to IN SERVICE to activate the port.
7	Set the LINE Z (line impedance) of each port based on the size of the network. The default value is recommended.
8	Set the MSG IND to DISABLE or ENABLE . When set to ENABLE , talk path is always open, even in on-hook conditions, in order for FXS message tones to pass through. Disabling this feature will allow higher on-hook voltage but will not allow on-hook messaging other than caller ID.
9	Configure the on-hook battery voltage using the BATT MODE field. For most IAD installs, the FXS loop is short with 6 to 7 V present on tip / ring. To reduce power dissipated during off-hook conditions, the battery is lowered for short loop lengths. When set to AUTO SWITCH , the IAD uses a higher on-hook battery voltage (48-52 V). When off-hook, it automatically switches to low battery (24-26 V) to minimize power dissipation. When set to LOW BATTERY mode, the higher battery is not used and the voltage is a constant 26 V even while on-hook. The tip/ring voltage is reduced to 26 V when using the LOW BATTERY mode.
10	Specify the interval of battery removal during a forward disconnect state using the FWD DISC TIMER field. Choices are FOLLOW SWITCH (default), 500MS , 750MS , 1000MS , and 2000MS . When using ATM mode, there is an additional choice of IGNORE SWITCH . If the timer is set to FOLLOW SWITCH , the Total Access 850 will follow the switch at all times; this is normal operation. If a time period has been selected, the Total Access 850 will remove battery for the specified time period OR as long as the switch requests battery removal, whichever is longer. For example, if the timer expires but the switch continues to request battery removal, the Total Access 850 will follow the switch and continue to remove battery. For ATM mode, if the timer is set to IGNORE SWITCH , the IAD will never remove battery.

FXS Interface Setup Instructions (Continued)	
11	Press <ENTER> on the TANDEM [+] option to view the TANDEM options if the port mode is set to TANDEM (E&M) .
12	Set the CONVERSION MODE of the port to either LOOP START or GROUND START .
13	Set the SUPERVISION of the port to either IMMEDIATE or WINK .
 NOTE Be sure to set the TANDEM options for each port set to TANDEM E&M .	

2. Configuring the Layer 2 Protocol

For more details on the configuration parameters discussed in this section, refer to the following pages:

Layer 2 ATM Network T1 menus beginning on [page 129](#)

Layer 2 Protocol Configuration – T1 Interface	
Step	Action
1	From the main menu, select L2 PROTOCOL and press <ENTER>.
2	Use the arrow keys to select the PROTOCOL field for the T1 interface. Press <ENTER>. Select ATM from the list of available protocols.
3	Use the arrow keys to select the CONFIG menu for the T1 interface and press <ENTER>.
4	Highlight the ATM CONFIG menu for the T1 interface and press <ENTER>.
5	Enter the IDLE CELLS format for your network.
6	Set DATA SCRAMBLING appropriately for your network.
7	Back all the way out to one level to the PVC CONFIG menu, and press <ENTER>. Enter the VPI and VCI values for communicating with that Gateway. (From this menu, the appropriate Voice information for working with the Voice Gateway is entered by selecting VOICE under the CONNECTION field.)

Layer 2 Protocol Configuration – T1 Interface (Continued)	
8	<p>Select SETUP, and from the SETUP menu, enter the Gateway type under CALL CONTROL and enter the VPI and VCI values for communicating with that Gateway.</p> <p>For this application, CALL CONTROL and virtual identifier (VPI and VCI) values should be set appropriately for your network.</p>
9	<p>To verify correct setup, use the PVC STATUS menu (under the STATUS menu located at L2 PROTOCOL [0] > STATUS) to look at the current status of the voice connection.</p> <p>Under STATUS, view information about the voice PVC along with information about the POTS ports available on the unit.</p>

Appendix B. RFC1483 Quick Start (IP Routing)

The Total Access 850 allows for complete integration of voice and data delivery from one compact platform (see Figure 10). Once you have completed the voice turn up procedure from the previous example, adding data to the circuit requires some additional setup.




Figure 10. Application Diagram

To configure a Total Access 850 for IP routing, you need to know the VPI and VCI values for the data circuit on your network. You also need the IP address of the next hop router in the circuit.

Perform the following steps in order to configure the application.

Initial Setup

It is best to configure Total Access 850 ATM applications by following the order of the top-level menus. For example, first configure the system parameters using the **SYSTEM INFO** and **SYSTEM CONFIG** menus. Next, configure the Layer 1 parameters using the **INTERFACES** menu. Once the Layer 1 information is configured, proceed to the Layer 2 setup using the **L2 PROTOCOL** menu. Follow the Layer 2 setup with the data “routing” menus (either **BRIDGE** or **ROUTER**). Finally, establish packet forwarding and blocking using the **SECURITY** menus.



The following example provides step by step instructions for configuring the Total Access 850 T1 ATM system (**INTERFACES** and **L2 PROTOCOL**) for a standard routing application. System Info and System Config parameters should be set according to your system need. Refer to *System Info* on page 73 and *System Config* on page 75 for more details.

1. Setting up the Interfaces

For more details on the configuration parameters discussed in this section, refer to the following pages:

Network T1 menus beginning on [page 94](#)

Ethernet menus beginning on [page 101](#)

T1 Interface Setup Instructions	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the T1 interface and press <ENTER> .
3	Right arrow to select FORMAT and choose ESF or SF .
 <i>NOTE This format must match the format used by the other units in the network.</i>	
4	Set the LINE CODE to B8ZS or AMI .
 <i>NOTE This line code must match the line code used by the other units in the network.</i>	
5	Set the EQUALIZATION or line build out. The default setting of 0 dB is usually sufficient.
6	Set the CSU LPBK option to ENABLE , DISABLE , or DISABLE ALL based on whether looping to this unit from another unit will be allowed.

Ethernet Interface Setup Instructions	
<p>Most applications should not require a manual setup for the Ethernet interface. By default, the Ethernet interface is configured to auto-detect the data rate (as either 10 or 100 Mbps). The following steps disable the auto-negotiation parameter and manually configure the interface.</p>	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the ETH interface and press <ENTER> .
3	Use the right arrow to select AUTONEGOTIATION and press <ENTER> . Use the down arrow to choose OFF .
4	Select the DATA RATE field and specify either 10BASET or 100BASET .
5	Select the DUPLEX TYPE field and specify either HALF DUPLEX or FULL DUPLEX .

2. Configuring the Layer 2 Protocol

For more details on the configuration parameters discussed in this section, refer to the following pages:

Layer 2 ATM Network Interface Protocol menus beginning on [page 129](#)

Layer 2 Protocol (ATM) Configuration – T1 Interface	
Step	Action
1	From the main menu, select L2 PROTOCOL and press <ENTER> .
2	Use the arrow keys to select the PROTOCOL field for the T1 interface. Press <ENTER> . Select ATM from the list of available protocols.
3	Use the arrow keys to select the CONFIG menu for the T1 interface and press <ENTER> .
4	Highlight the ATM CONFIG menu for the T1 interface and press <ENTER> .
5	Enter the IDLE CELLS format for your network.
6	Set DATA SCRAMBLING appropriately for your network.
7	Back all the way out to one level to the PVC CONFIG menu, and press <ENTER> . Enter the VPI and VCI values for communicating with that Gateway. Select ROUTER under the CONNECTION field.
8	Select the SETUP menu and configure the virtual circuit for IP or PPP operation. (Our example selects IP .) Refer to <i>L2 Protocol (T1 ATM–T1–ATM) > Config > PVC Config > Connection</i> on page 131 for more details.
9	Set mode to ROUTE IP . Using this menu you also have the option to route only IP packets and bridge all other data packets (ROUTE IP/BRIDGE OTHER) or bridge all data packets on this connection (BRIDGE ALL). Refer to <i>L2 Protocol (T1 ATM–T1–ATM) > Config > PVC Config > Setup (Router)</i> on page 131 for more details.
10	Left arrow back to the main menu to save the changes.

3. Setting the Router Options

For more details on the configuration parameters discussed in this section, refer to the following pages:

Router Ethernet Interface Configuration menus beginning on [page 148](#)

Router Network Interface Configuration menus beginning on [page 148](#)

Router Default Gateway menus beginning on [page 157](#)

Router Options – Ethernet Interface	
Step	Action
1	From the main menu, select ROUTER and press <ENTER> .
2	Use the right arrow key to highlight CONFIG and press <ENTER> .
3	Select INTERFACES and press <ENTER> . Use the right arrow key to highlight the SETUP field for the ETH (Ethernet) interface and press <ENTER> .
4	Highlight the PRIMARY IP field and press <ENTER> .
5	Set the IP ADDRESS of the Ethernet port.
6	Set the SUBNET MASK for the Ethernet port.
7	By default, RIP is disabled on the Ethernet interface. If RIP needs to be enabled, highlight the RIP field and press <ENTER> . Set the appropriate VERSION , RIP METHOD , DIRECTION , and V2 SECRET (where applicable) to configure RIP on the interface. For more details, refer to <i>Router > Config > Interfaces (ETH) > Sub-Interface</i> on page 148.
8	Press the left arrow key to return to the Ethernet sub-interface menu (displays PRIMARY IP and SECONDARY IP).
9	If your application requires additional secondary IP address, highlight the SECONDARY IP field and press <ENTER> . The Total Access 850 supports up to 5 additional LAN segments. Enter each additional secondary IP address and corresponding subnet mask. To add a new IP address entry, highlight the NUM field and press the <I> key. To delete an existing entry, highlight the NUM field for the entry to delete and press the <D> key.
10	Left arrow back to the main menu to save the changes.

Router Options – T1 Interface (L2 Protocol = ATM)	
Step	Action
1	From the main menu, select ROUTER and press <ENTER> .
2	Use the right arrow key to highlight CONFIG and press <ENTER> .

Router Options – T1 Interface (L2 Protocol = ATM) (Continued)	
3	Select INTERFACES and press <ENTER> . Use the right arrow key to highlight the SETUP field for the T1 interface and press <ENTER> . Each virtual circuit on the T1 interface defined in the PVC CONFIG has a separate listing in the ROUTER INTERFACES table.
4	Set ACTIVE to YES to activate the virtual circuit.
5	Enter the appropriate VPI and VCI values.
6	Select the desired ADDRESS MODE . Refer to <i>Address Mode</i> on page 151 for more details.
7	Enter the Total Access 850 LOCAL IP ADDRESS and corresponding IP NETMASK for the selected virtual circuit.
8	Enter the IP address for the next hop router in the FAR-END IP ADDRESS field.
9	For NAT configuration, refer to <i>Appendix C. RFC1483 Quick Start (IP Routing with NAT)</i> on page 209.
10	Left arrow back to the main menu to save the changes.


Router Options – Setting the Default Gateway	
Step	Action
1	From the main menu, select ROUTER and press <ENTER> .
2	Use the right arrow key to highlight CONFIG and press <ENTER> .
3	Select ROUTES and press <ENTER> . Set the DEFAULT GATEWAY field to the appropriate IP address.
4	Left arrow back to the main menu to save the changes.

Appendix C. RFC1483 Quick Start (IP Routing with NAT)

To illustrate the use of NAT, consider the example from *Appendix B. RFC1483 Quick Start (IP Routing)* on page 204. To add NAT to the IP routing example, use the **NAT** menus.

For more details on the configuration parameters discussed in this section, refer to the following pages:

Router Network Interface Configuration menus beginning on [page 148](#)

IP Routing with NAT	
Step	Action
1	The NAT menu is found under ROUTER > CONFIGURATION > INTERFACES > SETUP > NAT . The NAT menu can easily be accessed by pressing <CTRL+N> .
	<i>The network interface will not appear if a virtual circuit is not defined using the L2 PROTOCOL menus.</i>
2	From the NAT menu, set PORT TRANSLATION to ENABLED . (This will enable translation and populate the corresponding NAT menu options.)
3	Set PUBLIC IP ADDRESS MODE to either INTERFACE or SPECIFIED . <ul style="list-style-type: none"> INTERFACE (default) configures NAT to use the IP address already assigned to the interface. (In other words, the interface address and the NAPT address are the same.) SPECIFIED allows you to define a different IP address for the NAPT address (public address for private addresses to be translated into). <p>For basic NAT, this is all of the configuration that needs to be done. For specific port translations or 1:1 mapping, you can enter TRANSLATION TABLE.</p>
4	From the TRANSLATION TABLE menu, create a new entry by using the right arrow to enter the table. Additional entries can be created by highlighting the first entry index number and pressing the <I> key. Entries can be deleted by highlighting the selected entry index number and pressing the <D> key.
5	Create specific NAT translations based on your application. <p>PUBLIC IP ADDRESS MODE Use the configured interface IP address as the NAPT address or use SPECIFIED to set a different public address to be used for the translation.</p> <p>PROTOCOL MODE Protocol for this translation. (TCP, UCP, ICMP, TCP or UDP, TCP UDP or ICMP, All, Specified, and NONE.)</p> <p>PRIVATE ADDRESS MODE SPECIFIED or ANY INTERNAL. Choosing SPECIFIED brings up the PRIVATE ADDRESS option.</p> <p>TRANSLATE BODY YES or NO. If set to YES, this will translate the body of the data packet and replace the private address with the NAPT address. Default is NO, which is used for most applications.</p>

Appendix D. RFC 1483 Quick Start (Bridging)

Initial Setup

It is best to configure Total Access 850 ATM applications by following the order of the top-level menus. For example, first configure the system parameters using the **SYSTEM INFO** and **SYSTEM CONFIG** menus. Next, configure the Layer 1 parameters using the **INTERFACES** menu. Once the Layer 1 information is configured, proceed to the Layer 2 setup using the **L2 PROTOCOL** menus. Follow the Layer 2 setup with the data “routing” menus (either **BRIDGE** or **ROUTER**). Finally, establish packet forwarding and blocking using the **SECURITY** menus.



The following example provides step by step instructions for configuring the Total Access 850 T1 ATM system (**INTERFACES** and **L2 PROTOCOL**) for a standard bridging application. System Info and System Config parameters should be set according to your system need. Refer to *System Info* on page 73 and *System Config* on page 75 for more details.

1. Setting up the Interfaces

For more details on the configuration parameters discussed in this section, refer to the following pages:

Network T1 menus beginning on [page 94](#)

Ethernet menus beginning on [page 101](#)

T1 Interface Setup Instructions	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the T1 interface and press <ENTER> .
3	Right arrow to select FORMAT and choose ESF or SF .
 NOTE	<i>This format must match the format used by the other units in the network.</i>
4	Set the LINE CODE to B8ZS or AMI .
 NOTE	<i>This line code must match the line code used by the other units in the network.</i>
5	Set the EQUALIZATION or line build out. The default setting of 0 dB is usually sufficient.
6	Set the CSU LPBK option to ENABLE , DISABLE , or DISABLE ALL based on whether looping to this unit from another unit will be allowed.

Ethernet Interface Setup Instructions	
Most applications should not require a manual setup for the Ethernet interface. By default, the Ethernet interface is configured to auto-detect the data rate (as either 10 or 100 Mbps). The following steps disable the auto-negotiation parameter and manually configure the interface.	
Step	Action
1	From the main menu, select INTERFACES .
2	Highlight the CONFIG menu for the ETH interface and press <ENTER> .
3	Use the right arrow to select AUTONEGOTIATION and press <ENTER> . Use the down arrow to choose OFF .
4	Select the DATA RATE field and specify either 10BASET or 100BASET .
5	Select the DUPLEX TYPE field and specify either HALF DUPLEX or FULL DUPLEX .

.2. Configuring the Layer 2 Protocol

For more details on the configuration parameters discussed in this section, refer to the following pages:

Layer 2 ATM Network Interface Protocol menus beginning on [page 129](#)

Layer 2 Protocol (ATM) Configuration – T1 Interface	
Step	Action
1	From the main menu, select L2 PROTOCOL and press <ENTER> .
2	Use the arrow keys to select the PROTOCOL field for the T1 interface. Press <ENTER> . Select ATM from the list of available protocols.
3	Use the arrow keys to select the CONFIG menu for the T1 interface and press <ENTER> .
4	Highlight the ATM CONFIG menu for the T1 interface and press <ENTER> .
5	Enter the IDLE CELLS format for your network.
6	Set DATA SCRAMBLING appropriately for your network.
7	Back all the way out to one level to the PVC CONFIG menu, and press <ENTER> . Enter the VPI and VCI values for communicating with that Gateway. Select ROUTER under the CONNECTION field.
8	Select the SETUP menu and configure the virtual circuit for IP or PPP operation. (Our example selects IP .) Refer to <i>L2 Protocol (T1 ATM–T1–ATM) > Config > PVC Config > Setup (Router)</i> on page 131 for more details.

Layer 2 Protocol (ATM) Configuration – T1 Interface (Continued)	
9	Set mode to ROUTE IP . Using this menu you also have the option to route only IP packets and bridge all other data packets (ROUTE IP/BRIDGE OTHER) or bridge all data packets on this connection (BRIDGE ALL). Refer to <i>L2 Protocol (T1 ATM–T1–ATM) > Config > PVC Config > Setup (V35)</i> on page 133 for more details.
10	Left arrow back to the main menu to save the changes.

3. Verifying the Bridge Options

For more details on the configuration parameters discussed in this section, refer to the following pages:

Bridge menus beginning on page 145

Bridge Options	
Step	Action
1	From the main menu, select BRIDGE and press <ENTER> .
2	Use the right arrow key to highlight CONFIG and press <ENTER> .
3	Select INTERFACES and press <ENTER> . Verify that the desired interface is listed in this table.
4	Left arrow back to the BRIDGE > CONFIG menu.
5	Select BRIDGE TABLE and set the BRIDGE TABLE AGING to the desired time (in minutes) it takes an entry to age out of the Bridge table.
6	Left arrow back to the main menu to save the changes.

DETAIL LEVEL PROCEDURES

DLP-1	Connecting a VT100 Terminal or PC to the CRAFT Port.	215
DLP-2	Logging in to the System	217
DLP-3	Setting IP Parameters for the Total Access 850	219
DLP-4	Verifying Communications Over an IP LAN	221
DLP-5	Connecting to the Total Access 850 Using Telnet.	225
DLP-6	Adding/Removing Users and Changing Password Security Levels.	229
DLP-7	Updating the Firmware using TFTP	233
DLP-8	Updating the Firmware using XMODEM	237
DLP-9	Saving the Current Configuration Using TFTP.	239
DLP-10	Loading a Configuration Using TFTP.	241
DLP-11	Saving and Transferring a Current Configuration Using XMODEM.	245
DLP-12	Loading a Configuration Using XMODEM	247
DLP-13	Saving and Loading Text Configuration using Terminal Command Line.	249
DLP-14	A.03 to A.04 Firmware Upgrade.	253
DLP-15	Using the ADTRAN Utility Syslog.	257
DLP-16	Connecting the Alarm Contacts and the External Input.	261
DLP-17	Configuring the Total Access 850 for Dual T1 Maps	265

DLP-1 Connecting a VT100 Terminal or PC to the CRAFT Port

Introduction

Total Access 850 shelf management and provisioning are facilitated by a series of intuitive menus that are accessible on a computer screen. Connecting either a VT100 terminal or a PC emulating a VT100 terminal to the RJ-45 **CRAFT** port on the rear of the unit or the DB-9 **CRAFT** interface on the RCU faceplate allows access to the menus and management features of Total Access 850. This section specifies how to connect the VT100 terminal or PC to the Total Access 850.

The front **CRAFT** interface for the Total Access 850 is located on the faceplate of the RCU and is a DB-9 connector. Access can also be made to the Total Access 850 from the back of the unit through the RJ-45 interface labeled **CRAFT**, located on the back of the unit. A special ADTRAN adapter is required for access to this rear port.

Prerequisite Procedures

The Total Access 850 must be powered for terminal communication to function.

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software. A VT100 emulation program is provided with your shipment as part of the ADTRAN Utilities software suite.
- Appropriate cable to connect terminal to the Total Access 850 (customer-provided)
- DB-9 male to DB-9 female serviceable (customer-provided) for connecting to the RCU faceplate **CRAFT** port
- DB-9 female to RJ-45 female adapter (ADTRAN proprietary) for connecting to the **CRAFT** port on the rear of the unit.

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Perform the steps below in the order listed.

1. Connecting a VT100 terminal to Total Access 850:

- Set the parameters of the VT100 terminal or PC to:
 - 9600 baud rate
 - 8 data bits
 - No parity
 - 1 stop bit
 - No flow control
- If the terminal has a parallel setting, disable it and use the serial port.

Using the RCU CRAFT Port

- Plug the DB-9 male end of the data cable into the Total Access 850 **CRAFT** port on the front of the RCU. Make the connection to the VT100 terminal as appropriate for your equipment.

Using the rear CRAFT Port

- Plug the RJ-45 end of the data cable into the Total Access 850 **CRAFT** port on the back of the unit. Make the connection to the VT100 terminal as appropriate for your equipment.

2. Connect a PC emulating a VT-100 terminal to Total Access 850.

Most personal computers (PCs) or laptops can run communications software that emulates a VT100 terminal. Examples include Windows programs such as Terminal® or Hyperterminal®. However, there are many other adequate, commercially available software packages which will allow your PC or laptop to emulate a VT100 terminal.

- Set the parameters of the communications software to:
 - 9600 baud rate
 - 8 data bits
 - No parity
 - 1 stop bit
 - No flow control
- Set the PC for direct connect on the appropriate com port (instead of dial up connection).

Using the RCU CRAFT Port

- Plug the DB-9 male end of the data cable into the Total Access 850 **CRAFT** port on the front of the unit. Make connection to the PC or laptop as appropriate for your equipment.

Using the rear CRAFT Port

- Plug the RJ-45 end of the data cable into the Total Access 850 **CRAFT** port on the back of the unit. Make connection to the PC or laptop as appropriate for your equipment.

You are now ready to log in to the Total Access 850, as described in *DLP-2, Logging in to the System*.

DLP-2 Logging in to the System

Introduction

Once connected to the Total Access 850, you must login to the system to gain access to the management and provisioning functions. This DLP assumes you are connected to the Total Access 850 and provides specific steps for logging into the system.

Prerequisite Procedures

Complete DLP-1, *Connecting a VT100 Terminal or PC to the CRAFT Port*.

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.



*After the IP parameters have been provisioned (see DLP-3, *Setting IP Parameters for the Total Access 850*), you can also log in via Telnet.*

DLP-3 Setting IP Parameters for the Total Access 850

Introduction

The Total Access 850 comes pre-programmed for default Telnet access. The following IP parameters apply:



- IP Address: 10.0.0.1
- Subnet Mask: 255.255.255.0
- User: guest
- Password: password

For security purposes, change the default Telnet password during the initial unit configuration. (Refer to System Config > Management > Telnet Access > User List on page 77 for more details.)

If the Total Access 850 is connected to an IP network for Telnet, TFTP, or SNMP management, there are several IP parameters which must be set for the unit to communicate with the network. These parameters are described in this DLP along with the procedures for setting them.



*Please see your Network Administrator for the proper assignment of the following parameters: **IP ADDRESS**, **SUBNET MASK**, and **DEFAULT GATEWAY**.*

Prerequisite Procedures

This procedure assumes that the Total Access 850 unit is connected to an IP network and is powered up.

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the Total Access 850 (customer-provided)
- DB-9 male to DB-9 female adapter (customer-provided) for connecting to the RCU faceplate **CRAFT** port
- DB-9 female to RJ-45 female adapter (ADTRAN proprietary) for connecting to the **CRAFT** port on the rear of the unit



To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Perform the steps below in the order listed.

1. Connect the Total Access 850 unit to your VT100 system (details found in DLP-1, *Connecting a VT100 Terminal or PC to the CRAFT Port*).
2. Log in to the system.
3. From the **ROUTER/CONFIG** menu, select the **INTERFACES** option and press **<Enter>**.
4. Select **SETUP** for the **ETH** interface, then **PRIMARY IP**.
5. Highlight the **IP ADDRESS** field and press **<Enter>**. Enter the appropriate IP address (as given by your system administrator).
6. Highlight the **SUBNET MASK** field and press **<Enter>**. Enter the appropriate subnet mask (as given by your system administrator).
7. Highlight the **DEFAULT GATEWAY** field and press **<Enter>**. Enter the appropriate default gateway (as given by your system administrator).
8. Press the left arrow key to highlight the **PRIMARY IP** submenu. This action saves your changes and requires confirmation.
9. Escape out to the **ROUTER** menu and log off by pressing **<CTRL+L>**.

DLP-4 Verifying Communications Over an IP LAN

Introduction

When the Ethernet port is connected to a local area network (LAN), test steps must be performed on the Total Access 850 to ensure that the unit is communicating properly over the network. This procedure outlines those steps.

Prerequisite Procedures

Before beginning this procedure, the unit should be physically connected to the LAN and the provisioning tasks detailed in DLP-3, *Setting IP Parameters for the Total Access 850*, should be complete.

Tools and Materials Required

- Access to a PC or other computer connected to the LAN

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Perform the steps below in the order listed.

1. Verify the Total Access 850 IP address.

If you do not already have the IP Address for the Total Access 850, obtain it from the network administrator or manually check for the address in the **ROUTER CONFIG/INTERFACE/SETUP/PRIMARY IP/IP ADDRESS** menu of the Network Management interface.



You must log in with a security level of 2 to modify the IP parameters on the Total Access 850. (See DLP-2, Logging in to the System for more details.)

2. Ping the Total Access 850 unit from a remote computer on the network.

Using a remote computer system connected to the LAN, perform an ICMP Ping on the IP Address of the Total Access 850. Verify that the unit responds properly.

If the Total Access 850 fails to respond, try the following:

- Verify that the proper IP Address, Subnet Mask, and Default Gateway are provisioned in the unit (see DLP-2, *Logging in to the System*, for details).
- Verify that the Total Access 850 is properly cabled into the LAN and that the Ethernet cable is properly seated in the RJ-45 LAN jack on the rear of the unit.
- Verify the link light on the RCU is lit. If not lit, check the cabling between the hub and the shelf.
- If the Total Access 850 is connected to a hub or other network device that provides a carrier sense light for each port, verify that the carrier sense light for the port to which the Total Access 850 is connected is lit. If this light is not lit, check the cabling between the hub and the shelf.
- Verify the IP Address, Subnet Mask, and Default Gateway on the remote computer system.
- Use Ethernet straight-through cable for connection to hub or switch. Use Ethernet crossover if connecting to PC.

If none of these steps are successful, contact the LAN Administrator for assistance.



*Refer to the documentation of the computer system if you are unsure how to perform a Ping command. Most computers running a networked version of Microsoft Windows™ or UNIX allow a Ping to be performed by simply typing **ping <IP Address>** at a command line prompt. Typically, the Ping program will respond by indicating that the remote IP Address has responded in a certain amount of time or that no response was received.*



*Some versions of Ping will continue running until you explicitly tell them to stop. If the program does not terminate on its own, press **<CTRL+C>** to get the program to stop.*

3. Telnet to the Total Access 850.

From the same computer used in the previous step, Telnet to the Total Access 850 and verify that the Telnet session is properly opened (see DLP-5, *Connecting to the Total Access 850 Using Telnet*). Once the Telnet session is established, press <CTRL+L> to logout and close the session.



*Refer to the documentation of the computer system if you are unsure how to perform a Telnet. Most computers running a networked version of Microsoft Windows™ or UNIX allow a Telnet to be performed by simply typing **Telnet <IP Address>** at a command line prompt. Telnet is a utility common on many local area networks that allows remote access to another computer or piece of equipment.*

DLP-5 Connecting to the Total Access 850 Using Telnet

Introduction

The Total Access 850 comes pre-programmed for default Telnet access. The following IP parameters apply:



- IP Address: 10.0.0.1
- Subnet Mask: 255.255.255.0
- User: guest
- Password: password

For security purposes, change the default Telnet password during the initial unit configuration. (Refer to System Config > Management > Telnet Access > User List on page 77 for more details.)

If the Total Access 850 is part of a management cluster connected to the local network, you may use a PC connected to the network to Telnet into the unit. This procedure details the steps which must be performed to Telnet into the unit.

Prerequisite Procedures

Complete DLP-3, *Setting IP Parameters for the Total Access 850* and DLP-4, *Verifying Communications Over an IP LAN*.

Tools and Materials Required

- Access to a PC or other computer connected to the LAN.



To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Perform the steps below in the order listed.

1. Connect the computer to the Total Access 850 RCU faceplate **CRAFT** or rear **CRAFT** port (details in DLP-1, *Connecting a VT100 Terminal or PC to the CRAFT Port*).
2. Log in to the unit.
3. Select the **SYSTEM CONFIG/MANAGEMENT/TELNET ACCESS** menu and set the **TELNET ACCESS** to **ON**.
4. Under the **SYSTEM CONFIG/MANAGEMENT/TELNET ACCESS** menu, select the **TELNET USER LIST**; press **<Enter>**. The following screen appears.

```

Telnet - 10.200.3.197
Connect Edit Terminal Help
TA 850 RCU/System Config/Management/Telnet Access/User List
User List
IP Access List
#      Name      Password      Idle Time<mins>  Level
1      adtran     *****      100              Full

MODE: T1 IAD      SLOTS 1:FXS 2:FXS 3: 4:FXO 5: 6:      NET: down
^Z=help 23:03

```


5. Use the right arrow key to select the **NAME** field; press **<Enter>**. Enter a username to use for Telnet logins.
6. Use the right arrow key to select **PASSWORD**; press **<Enter>**. Enter a password to use for Telnet logins.
7. Use the right arrow key to select **IDLE TIME (MINS)**; press **<Enter>**. This field defines the amount of time in minutes the Telnet session may be idle before the user is logged off. The range is 1-255 and the default value is 10 minutes. Enter the appropriate **IDLE TIME**.
8. Use the right arrow key to select **LEVEL**; press **<Enter>**. Select the appropriate security level. (Reference DLP-6, *Adding/Removing Users and Changing Password Security Levels*, for security level definitions.)
9. Press the left arrow key until prompted to save the Telnet changes. Respond with **Y** to confirm the request.
10. This completes the addition of one Telnet user. Repeat steps 1-11 for each additional Telnet user access.
11. Press **<CTRL+L>** to log off the Total Access 850 terminal menu system.

- From a remote computer system connected to the LAN, Telnet to the Total Access 850.




Refer to the documentation of the computer system if you are unsure how to perform a Telnet. Most computers running a networked version of Microsoft Windows™ or UNIX allow a Telnet to be performed by simply typing “Telnet <IP Address>” at a command line prompt. Telnet is a utility common on many local area networks that allows remote access to another computer or piece of equipment.

The following screen appears.




- Enter the user name assigned in step 5 and press enter. The following screen appears.



14. Enter the password assigned in step 6.

After entering the correct password, the Total Access 850 main menu is displayed (see below):



15. After completing your configuration changes they are automatically saved (or manually save them by pressing **<CTRL+W>**), press **<CTRL+L>** to log off the menus, and close the Telnet window.

DLP-6 Adding/Removing Users and Changing Password Security Levels

Introduction



*Password security levels only apply to users connecting to the Total Access 850 system through Telnet access. All connections made through the **CRAFT** interface ALWAYS have maximum security rights.*

All menu items in the Total Access 850 are protected by passwords of varying security levels. By assigning different passwords to different security levels, the Total Access 850 System Administrator can control which users can view or change various menu items. You can assign multiple passwords at the same access level. This way, different users with the same access privileges can have different passwords. This procedure details the steps which must be performed to add/remove user profiles and assign password security levels in the Total Access 850.

Tools and Materials Required

- VT100 compatible terminal or PC with VT100 terminal emulation software



To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Perform the steps below in the order listed.

1. Connect to the Total Access 850 using either the **10BASET**, rear **CRAFT**, or RCU faceplate **CRAFT** interfaces.

If you are not already connected to the unit's RCU faceplate **CRAFT** or rear **CRAFT** interface (either with a VT100 compatible terminal or with a PC running VT100 emulation software), follow the procedure in DLP-1, *Connecting a VT100 Terminal or PC to the CRAFT Port*.

Alternately, if the unit is part of a management cluster connected to the local network, you may use a PC connected to the network to Telnet into the unit. Use the procedures in DLP-3, *Setting IP Parameters for the Total Access 850* and DLP-5, *Connecting to the Total Access 850 Using Telnet*, to connect to the **10BASET** interface.

2. Log in to the unit using the read-write password (see DLP-2, *Logging in to the System*, for more details).



*Password security levels only apply to users connecting to the Total Access 850 system through Telnet access. All connections made through the **CRAFT** interface ALWAYS have maximum security rights.*

3. Go to the **SYSTEM CONFIG/MANAGEMENT/TELNET ACCESS** menu, select the **USER LIST** menu, and press **<Enter>**.
4. Add a new user profile and password by selecting the first column (0) and pressing **<I>** (for insert).
5. Give the new user profile a name by selecting the **NAME** field, pressing **<Enter>**, and typing the user defined name.
6. Personalize the password for the appropriate level by selecting the **PASSWORD** field, pressing **<Enter>**, then typing the appropriate password. You will have to type the new password again to confirm it.

Passwords for the Total Access 850 system are case sensitive. There is no default password for a new user (i.e., you can configure a user as blank with no password). The current password displays as a series of asterisks (*****).

7. Select the **IDLE TIME** field and press **<Enter>**. This field defines the amount of time in minutes the session may be idle before the user is logged off. The range is **1-255** and the default value is **10**.

8. Determine the password level for the corresponding label. The Total Access 850 contains seven different password levels. The following chart gives a brief description of each level.

Select Level...	If you want the user to....
STATUS	Have read-only permission for all menu items - minimum rights
VOICE	Have read permission for all menu items and permission to use test commands
ROUTER	Have access to all commands except passwords, flash download, authentication methods, interface configurations, and Telnet security levels.
CONFIG	Have access to all commands except passwords, flash download, authentication methods, and Telnet security levels.
SUPPORT	Have access to all commands except passwords and Telnet security levels.
FULL	Have permission to edit every menu item, including creating and editing passwords -- maximum rights
ROUTER ONLY	Have read access to all menu items and write access to only the router menu.

9. Assign the password level to the appropriate label by selecting the **LEVEL** field and choosing the level decided upon in Step 8.

DLP-7 Updating the Firmware using TFTP

Introduction

The Total Access 850 supports firmware updates using TFTP or XMODEM. (Use the **10/100BASE-T** Ethernet port and TFTP from a network server, or use XMODEM and the RCU faceplate **CRAFT** or rear **CRAFT** interfaces.) This DLP provides the steps for a successful firmware upgrade using the **10/100BASE-T** Ethernet port and a TFTP server. (See DLP-8, *Updating the Firmware using XMODEM*, for instructions on using XMODEM.)

Tools and Materials Required

- A PC with Telnet client software
- A TFTP server accessible on the local network



A TFTP server is provided as part of the ADTRAN Utilities software suite supplied with your shipment.



To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Perform the steps below in the order listed.

1. Connect to the Total Access 850 using the **10/100BASET** interface.

If you are not already connected to the unit's **ETHERNET** port using Telnet client software, use the procedure in DLP-5, *Connecting to the Total Access 850 Using Telnet*, to connect to the unit.

2. Log in to the unit using the read-write password (see DLP-2, *Logging in to the System* for details).
3. Verify the TFTP server is running on the network. The user may ping the TFTP server from the Total Access 850 to verify communication.



*A TFTP server ships as part of the ADTRAN Utilities. If using ADTRAN Utilities, choose **START > PROGRAMS > ADTRAN UTILITIES > TFTP SERVER** to start the server.*

4. Download the firmware upgrade file to your computer.



*If using ADTRAN Utilities, save the upgrade file to the "**ADTNUTIL**" directory on your hard drive.*

5. Go to the **SYSTEM UTILITY** menu and select the **UPDATE FIRMWARE** menu; press **<Enter>**.
6. Go to the **TRANSFER METHOD** menu and select **TFTP**.
7. Set the **TFTP SERVER ADDRESS** to the IP address of the machine running the TFTP server program.



*If using ADTRAN Utilities, this will be the IP address that appears in the **TFTP SERVER STATUS** window.*

8. Enter the filename of the update file into the **TFTP SERVER FILENAME** field. If the file is located in a directory other than **ADTNUTIL**, the entire path and filename are required.

9. Select **START TRANSFER** to start the update. Enter **Y** to confirm the upgrade.

Prior to the start of the upgrade, the transfer status will display **IDLE**. During the TFTP upload process, various status messages display in **CURRENT UPDATE STATUS** to indicate progress. The following table describes these messages.

Message	Meaning
Transferring... [X KB]	Indicates communication with the TFTP network server has been established and the update file is being transferred between the Total Access 850 and the TFTP network server.
Flash Programmed Successfully	The unit has been upgraded successfully.
Loaded code ver x.x.x chksum = xxxx	Unit displays the version and checksum of the upgraded code.
Resetting	Unit is power cycling.
RECV Error	Unit will display this message if server filename is incorrect.
Can not start tftp client **Reload	Unit will display this message if TFTP server address is incorrect.
Transfer aborted	User has selected ABORT TRANSFER .

10. When the update has successfully completed, **FLASH PROGRAMMED SUCCESSFULLY** displays briefly in the **TRANSFER STATUS** field. This will be followed by a **LOADED CODE VER X.X.X CHKSUM = XXXX** message. Finally the **TRANSFER STATUS** field displays **RESETTING ...**

The Total Access 850 will restart immediately and resume operation. After giving the unit sufficient time to reboot, the user may Telnet back into the unit and log in.

DLP-8 Updating the Firmware using XMODEM

Introduction

The Total Access 850 supports firmware updates using TFTP or XMODEM. (Use the **10/100BASET** Ethernet port and TFTP from a network server, or use XMODEM and the rear **CRAFT** or RCU faceplate **CRAFT** interface.) This procedure outlines the steps for a successful firmware upgrade using the rear **CRAFT** or RCU faceplate **CRAFT** interface and XMODEM software. (See *DLP-7, Updating the Firmware using TFTP*, for instructions on using TFTP.)

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software
- XMODEM software

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Updating Firmware via the Console Menus

Perform the steps below in the order listed.

1. Connect to the Total Access 850 using the RCU faceplate **CRAFT** (DB-9) or rear **CRAFT** (RJ-45) interface. Selecting a higher baud rate connection makes the file transfer process faster. Verify that the baud rate setting on the Total Access 850 matches the VT100 emulation software COM port settings.

If you are not already connected to the shelf's RCU faceplate **CRAFT** or rear **CRAFT** interface (either with a VT100 compatible terminal or with a PC running VT100 emulation software), follow the procedure in *DLP-1, Connecting a VT100 Terminal or PC to the CRAFT Port*. Connecting to the RCU faceplate **CRAFT** or rear **CRAFT** interface limits the upgrade procedure to XMODEM only.

2. Log in to the unit.
3. Go to the **SYSTEM UTILITY** menu and select the **UPGRADE FIRMWARE** menu; press **<Enter>**.
4. Go to the **TRANSFER METHOD** menu and select **XMODEM**.



Total Access 850 XMODEM transfers are compatible with 1K XMODEM on the VT100 terminal system. Selecting 1K XMODEM on your terminal session will make the configuration transfer faster.

5. Select **START TRANSFER** to start the update process. Enter **Y** to confirm the upgrade.
6. From the terminal emulation software, begin the XMODEM upload by using the appropriate command sequence. If necessary, refer to the terminal emulation software documentation for help.

Also, when specifying the filename, ensure that the file transferred is the one provided by ADTRAN, otherwise, the update will not complete successfully. This may take several minutes.

Because XMODEM data is being transferred in-band through the menu interface, the VT100 menus of the Total Access 850 will be inoperable from the RCU faceplate **CRAFT** or rear **CRAFT** interface. You can cancel the update at any time within the terminal emulation software. (Please consult the documentation provided by the terminal emulation software to determine how to do this.)

7. When the update process has successfully completed, the following messages will display:

Verifying downloaded FLASH image...

Erasing FLASH...

Programming FLASH...

FLASH programmed successfully.

The Total Access 850 will restart immediately and the user may then log back into the system.

Alternately, if the unit is part of a management cluster connected to the local network, you may use a PC connected to the network to Telnet into the unit. By utilizing the **ETHERNET** port, the Total Access 850 may be quickly upgraded using TFTP, provided there is a TFTP server on the local network. The Total Access 850 ships with ADTRAN Utilities software, which includes a TFTP server. See *DLP-7, Updating the Firmware using TFTP*, for more details.

DLP-9 Saving the Current Configuration Using TFTP

Introduction

The Total Access 850 supports configuration transfers from the unit (via the **10/100BASET** Ethernet port) to a TFTP server located on the network. This DLP provides the steps to follow for a successful configuration transfer using the **10/100BASET** Ethernet port and a TFTP Server.

Tools and Materials Required

- A PC with a Telnet client software
- A TFTP Server accessible on the local network (A TFTP server is provided with the unit as part of the ADTRAN Utilities software.)

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Perform the steps below in the order listed.

1. Connect to the Total Access 850 using the **10/100BASET** interface.

If you are not already connected to the unit's **10/100BASET** port using Telnet client software, use the procedure in DLP-5, *Connecting to the Total Access 850 Using Telnet*, to connect to the unit.

2. Log in to the unit using the read-write password (see DLP-2, *Logging in to the System*, for details).
3. Verify the TFTP server is running on the network.



*A TFTP server ships as part of the ADTRAN Utilities. If using ADTRAN Utilities, choose **START > PROGRAMS > ADTRAN UTILITIES > TFTP SERVER** to start the server.*

4. Go to the **SYSTEM UTILITY** menu and select the **CONFIGURATION TRANSFER** menu; press **<Enter>**.
5. Verify the **TRANSFER METHOD** is set to **TFTP**.
6. Set the **TFTP SERVER IP ADDRESS** to the IP address of the machine running the TFTP Server Program.



*If you are using the ADTRAN TFTP server, the IP address displays in the **STATUS** field. For other TFTP servers, please refer to the appropriate documentation.*

7. Change **TFTP SERVER FILENAME** to a unique filename (for example, **ta850.cfg**). This will be the name of the configuration file saved to the remote server.

Some TFTP servers constrain the format of the filename depending on the operating system of the server. For example, a TFTP server running on a PC under Windows 3.1 may only permit 8.3 format filenames (8 characters, period and three extension characters).
8. Select the **SAVE CONFIG REMOTELY** menu field and press **<Enter>**. Respond with **Y** to confirm the request.
9. View **CURRENT TRANSFER STATUS** to verify the progress of the current transfer. During a successful transfer, you will first see **DOWNLOAD: COPYING INTERNAL CONFIG**, and then **DOWNLOAD IN PROGRESS....**
10. When the transfer process has successfully completed, **IDLE** displays in the **CURRENT TRANSFER STATUS** field and **DOWNLOAD COMPLETE** displays in the **PREVIOUS TRANSFER STATUS** field.



*TFTP is **not** secure. No passwords are required for client access. Anyone can access files through the IP port on the server machine if they know the target filename.*

DLP-10 Loading a Configuration Using TFTP

Introduction

The Total Access 850 supports configuration uploads from a unit (via the **10/100BASET** Ethernet port) to a TFTP server located on the network. This DLP provides the steps to follow for a successful configuration upload using the **10/100BASET** Ethernet port and a TFTP Server.

Tools and Materials Required

- A PC with a Telnet client software
- A TFTP Server accessible on the local network (A TFTP server is provided with the unit as part of the ADTRAN Utilities software.)

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Perform the steps below in the order listed.

1. Connect to the Total Access 850 using the **10/100BASET** interface.

If you are not already connected to the unit's **10/100BASET** port using Telnet client software, use the procedure in DLP-5, *Connecting to the Total Access 850 Using Telnet*, to connect to the unit.

2. Log in to the unit using the read-write password (see DLP-2, *Logging in to the System*, for details).
3. Verify the TFTP server is running on the network.



*A TFTP server ships as part of the ADTRAN utilities. If using ADTRAN utilities, choose **START > PROGRAMS > ADTRAN UTILITIES > TFTP SERVER** to start the server.*

4. Go to the **SYSTEM UTILITY** menu and select the **CONFIGURATION TRANSFER** menu; press **<Enter>**.
5. Verify the **TRANSFER METHOD** is set to **TFTP**.



*TFTP is **not** secure. No passwords are required for client access. Anyone can access files through the IP port on the server machine if they know the target file's name.*

6. Set the **TFTP SERVER IP ADDRESS** to the IP address of the machine running the TFTP Server Program.



*If you are using the ADTRAN TFTP server, the IP address displays in the **STATUS** field. For other TFTP servers, please refer to the appropriate documentation.*

7. Change **TFTP SERVER FILENAME** to a unique filename. (This will be the name of the configuration file retrieved from the remote server.) If the ADTRAN Utilities TFTP server is used and no path is specified, the configuration file is retrieved from the default **ADTNUTIL** directory. To retrieve a configuration file from a particular folder, enter the entire filename including path.

Some TFTP servers constrain the format of the filename depending on the operating system of the server. For example, a TFTP server running on a PC under Windows 3.1 may only permit 8.3 format filenames (8 characters, period and three extension characters).

8. Select the **LOAD AND USE CONFIG** menu field and press **<Enter>**. Respond with **Y** to confirm the request.



The Total Access 850 system is rebooted immediately after a configuration is successfully loaded. No additional confirmation is requested, and any online sessions will be terminated.

9. View **CURRENT TRANSFER STATUS** to verify the progress of the current upload.

10. When the upload process has successfully completed, **IDLE** displays in the **CURRENT TRANSFER STATUS** field and **DOWNLOAD COMPLETE** displays in the **PREVIOUS TRANSFER STATUS** field.
11. After an appropriate length of time, the user may Telnet back into the unit.

DLP-11 Saving and Transferring a Current Configuration Using XMODEM

Introduction

The Total Access 850 supports configuration transfers from the unit via the rear **CRAFT** or RCU faceplate **CRAFT** interfaces using a VT100 terminal or terminal emulator (with XMODEM). This DLP provides the steps for a successful configuration transfer using either the rear **CRAFT** or RCU faceplate **CRAFT** port and XMODEM.

Tools and Materials Required

- VT100 terminal or PC with VT100 terminal emulation software
- XMODEM software

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Perform the following steps in the order listed.

1. Connect to the Total Access 850 using the rear **CRAFT** (RJ-45) port on the back of the Total Access 850 or the RCU faceplate **CRAFT** (DB-9) interface.

If you are not already connected to the unit's rear **CRAFT** or RCU faceplate **CRAFT** interface, either with a VT100 compatible terminal or with a PC running VT100 emulation software, follow the procedure in DLP-1, *Connecting a VT100 Terminal or PC to the CRAFT Port*. Connecting to the rear **CRAFT** or RCU faceplate **CRAFT** interface limits the configuration transfer procedure to **XMODEM** only.

2. Log in to the unit.
3. Go to the **SYSTEM UTILITY** menu and select **CONFIGURATION TRANSFER** menu; press **<Enter>**.
4. Set the **TRANSFER METHOD** menu to **XMODEM**.
5. Select **SAVE CONFIG REMOTELY** to start the transfers. Enter **Y** to confirm the transfer and prepare the Total Access 850 for the transfer download.

The following message is displayed: **This will begin sending a copy of the current system configuration.**

6. Configure the VT100 terminal or terminal emulation software to **RECEIVE** (and prompt for a filename).
7. View the **CURRENT TRANSFER STATUS** to verify the progress of the current transfer.
8. From the terminal emulation software, begin the **XMODEM** transfer by using the appropriate command sequence. For Windows HyperTerminal, select **TRANSFER>RECEIVE FILE**. Enter the filename (including path) and select **XMODEM** as the transfer method.

If necessary, refer to the terminal emulation software documentation for help.



When specifying the filename, ensure that the saved file has a .cfg extension; otherwise, the file may not be available for uploading into other Total Access 850 units.

- Because XMODEM data is being transferred inband through the menu interface, the VT100 menus of the Total Access 850 will be inoperable from the rear **CRAFT** or RCU faceplate **CRAFT** interfaces. You can cancel the update at any time within the terminal emulation software. (Please consult the documentation provided by the terminal emulation software to determine how to do this.)
9. When the transfer has successfully completed, **IDLE** displays in the **CURRENT TRANSFER STATUS** field and **XMODEM DOWNLOAD COMPLETE** displays in the **PREVIOUS TRANSFER STATUS** field.

DLP-12 Loading a Configuration Using XMODEM

Introduction

The Total Access 850 supports configuration uploads from a unit via the rear **CRAFT** or RCU faceplate **CRAFT** interface using a VT100 terminal or terminal emulator (with XMODEM). This DLP provides the steps for a successful configuration upload using either the rear **CRAFT** or RCU faceplate **CRAFT** port and XMODEM protocol.

Tools and Materials Required

- VT100 terminal or PC with VT100 terminal emulation software
- XMODEM software

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Perform the following steps in the order listed.

1. Connect to the Total Access 850 using the rear **CRAFT** (RJ-45) or the RCU faceplate **CRAFT** (DB-9) interface located on the front of the RCU.

If you are not already connected to the unit's rear **CRAFT** or RCU faceplate **CRAFT** interface, either with a VT100 compatible terminal or with a PC running VT100 emulation software, follow the procedure in DLP-1, *Connecting a VT100 Terminal or PC to the CRAFT Port*. Connecting to the rear **CRAFT** or RCU faceplate **CRAFT** interface limits the configuration transfer procedure to XMODEM only.

2. Log in to the unit using the read-write password (see DLP-2, *Logging in to the System*, for details).
3. Go to the **SYSTEM UTILITY** menu and select **CONFIGURATION TRANSFER** menu; press **<Enter>**
4. Set the **TRANSFER METHOD** menu to **XMODEM**.
5. Select **LOAD AND USE CONFIG** to start the transfer. Enter **Y** to confirm the transfer and prepare the Total Access 850 for the transfer download.



The Total Access 850 system is rebooted immediately after a configuration is successfully loaded. No additional confirmation is requested, and any online sessions will be terminated.

When the Total Access 850 is ready to receive the XMODEM configuration file, the menu screen clears and displays **AWAITING XMODEM UPLOAD...<CTRL+X> TWICE TO CANCEL**. If this does not appear, please review the preceding steps above for possible configuration errors.

6. From the terminal emulation software, begin the XMODEM transfer by using the appropriate command sequence. For Windows HyperTerminal, select **TRANSFER>SEND FILE**. Enter the filename (including path) and select **XMODEM** as the transfer method. Total Access 850 configuration files should have a .cfg extension.

If necessary, refer to the terminal emulation software documentation for help.

Because XMODEM data is being transferred inband through the menu interface, the VT100 menus of the Total Access 850 will be inoperable during this procedure from the rear **CRAFT** or RCU faceplate **CRAFT** interfaces. You can cancel the update at any time within the terminal emulation software. (Please consult the documentation provided by the terminal emulation software to determine how to do this.)

7. View **CURRENT TRANSFER STATUS** to verify the progress of the current upload.
8. When the transfer is complete, the Total Access 850 reboots and the **LOGIN** screen appears. The unit is now operational.

DLP-13 Saving and Loading Text Configuration using Terminal Command Line

Introduction

The Total Access 850 RCU has the ability to download a text file which contains the configuration of the entire unit. This configuration may then be altered in a text editor and uploaded to any Total Access 850 RCU.

This DLP will explain how to save and load the text configuration file for the ADTRAN Total Access 850.

Prerequisite Procedures

You must connect to the Total Access 850 with a VT100 terminal session (reference DLP-1, *Connecting a VT100 Terminal or PC to the CRAFT Port*).

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.




Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.


Perform the steps below in the order listed.

Saving the router's configuration

1. Establish a connection to the router with the VT100 terminal software either through the rear **CRAFT** or RCU faceplate **CRAFT** port.
2. From the main menu, select **SYSTEM UTILITY**, then **TERMINAL MODE**; press **<Enter>**.
3. The following screen appears.



4. At the terminal prompt, type **DOWNLOAD**; press **<Enter>**. The following screen appears.



Do not enter further key commands until completing Step 5.

5. Enable "capture" or "logging" in the terminal software, saving it to a file on your computer.
6. Press the **SPACE BAR** to continue. The router will then print its configuration to the terminal screen. (With capture enabled, the terminal software will capture the configuration and write it to the designated file.)
7. When the configuration stops printing, end the capture. The router's configuration is now saved to the designated file.
8. At the terminal prompt, type **EXIT** to enter the configuration menu of the router.



Always use <CTRL+L> to exit the configuration menu before closing the Telnet or terminal software.

Loading a configuration into the router

The following steps explain the process for uploading the text file back into the Total Access 850 RCU. These text files can be the entire configuration, or just partial commands that affect specific configuration changes. The uploading steps are the same, regardless of the size of the file.

1. Establish a connection to the router with the VT100 terminal software either through the rear **CRAFT** or RCU faceplate **CRAFT** port.
2. From the main menu, select **SYSTEM UTILITY**, then **TERMINAL MODE**; press <Enter>.
3. In the terminal software, initiate a SEND TEXT FILE or SEND CFG FILE using the saved configuration file.
4. Once the file transfer is complete, type **SAVE** to save the configuration in the unit. Type **EXIT** to enter the configuration menu of the router.



Always use <CTRL+L> to exit the configuration menu before closing the Telnet or terminal software.

Entering commands at the command prompt

Precede each instruction with a ">" when manually entering commands at the command prompt. After entering commands, type **SAVE** at the command prompt. (This applies ALL commands to current operation and saves all changes.) To save the changes to flash only (without affecting current operation), return to the menu system and press <CTRL+W>.

The commands are based on string comparisons with the menu system (with spaces replaced with underscores). For example, the config command appears at the command prompt exactly as it appears in the RCU terminal menus. To change a configuration, type in the desired option exactly as it appears on the menu. For example, to change the T1 timing mode, the command line should read

- >sysconfig t1_timing_mode network (sets timing to recover from the network) **or**
- >sysconfig t1_timing_mode internal (sets timing to internal Total Access 850 oscillator) **or**
- >sysconfig t1_timing_mode dsx-1 (sets timing to recover from the DSX-1 interface).

DLP-14 A.03 to A.04 Firmware Upgrade

Introduction

The Total Access line of Integrated Access Devices includes both the ATM and TDM versions of the Total Access 850. Until now, the Total Access TDM units have been running firmware version A.03.xx. Recently, A.04.xx has been released to support the TDM Total Access IADs. The development of A.04.xx code is a significant step in the evolution of the Total Access product line, as it allows all Total Access family members to share the same base code. This means that features and fixes are more easily implemented and are propagated across the product line.

The two possible A.03 to A.04 upgrade paths are described in this DLP.



The choice of upgrade path will determine whether the unit's configuration is saved.



Since the A.03 and A.04 firmware loads are significantly different, the text configuration files for the two revisions are also different. It is recommended that the customer save a text configuration file for both the A.03 revision (prior to the upgrade) and for the A.04 revision (after completion of the upgrade). Refer to DLP-9, Saving the Current Configuration Using TFTP, DLP-11, Saving and Transferring a Current Configuration Using XMODEM, or DLP-13, Saving and Loading Text Configuration using Terminal Command Line, for further instructions on how to save the configuration.



To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.

Prerequisite Procedures

Obtain the A.04 firmware and the A.03.90 (Transition Build) firmware from the ADTRAN website (<http://www.ADTRAN.com>).



*For the Total Access 850 units, select **SERVICE/SUPPORT > TECHNICAL SUPPORT > TOTAL ACCESS PRODUCTS > TOTAL ACCESS 850.***

If further assistance is required, contact ADTRAN Technical Support at 1-888-4ADTRAN.

Tools and Materials Required

- VT100 compatible terminal or computer with terminal emulation software
- Appropriate cable to connect terminal to the unit (customer-provided)
- DB-9 male to DB-9 female cable (customer provided) for connecting to the **CRAFT** port on the front of the RCU
- DB-9 female to RJ-45 female adapter (customer provided) for connecting to the **CRAFT** port on the rear of the unit

Perform the steps below in the order listed.

Upgrade From A.03 to A.03.90 (Transition Build) to A.04

1. Upgrade the firmware from A.03 to A.03.90 (Transition Build) firmware. See DLP-7 (TFTP) or DLP-8 (XMODEM) for instructions on how to perform this upgrade.
2. Once the upgrade to A.03.90 is complete, immediately upgrade the unit to A.04. See DLP-7 (TFTP) or DLP-8 (XMODEM) for instructions on how to perform this upgrade.



Upgrading from A.03 to A.03.90 (Transition Build) to A.04 will save the unit's configuration.

Upgrade From A.03 to A.04 Directly

1. Upgrade the firmware from A.03 to A.04 firmware. See DLP-7 (TFTP) or DLP-8 (XMODEM) for instructions on how to perform this upgrade.
2. The unit must then be factory defaulted by one of the following methods:
 - Select **SYSTEM UTILITY>TERMINAL MODE**. At the > prompt, type **fac**. You will then see "Restore Factory Defaults and Reset Unit? (press 'y')." Press the **y** key to confirm default. The unit will then automatically reset.
3. If connected to the RCU faceplate **CRAFT** or rear **CRAFT** port, set DIP-switch 2 (on the RCU) to the on position and power reset the unit. You will then be prompted to confirm the factory default.



DIP-switch services are not available on 3rd Generation RCUs.



To avoid a configuration loss in the event of a power failure, return DIP-switch 2 to the off position before resuming normal operation.

4. Reconfigure the unit for the specific application.



Upgrading from A.03 to A.04 directly (or from A.04 to A.03 directly) will erase the unit's configuration.

DLP-15 Using the ADTRAN Utility Syslog

Introduction

The Total Access 850 Syslog Utility records various message types at settable threshold levels to an external Syslog server (software supplied with the Total Access 850 system ADTRAN Utilities).

Prerequisite Procedures

This procedure assumes that the Total Access 850 unit is connected to an IP network and is powered up.

Tools and Materials Required

- Syslog server (provided on Total Access 850 System CD in ADTRAN Utilities)

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.




Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Setting up the Total Access 850 to use Syslog:

1. Log in to the system with maximum rights (see DLP-2, *Logging in to the System*). Once you have logged into the Total Access 850, go to **SYSTEM CONFIG/SYSLOG**. Set the options as follows:
 - **SYSLOG IP**: Enter the IP address of the PC where the Syslog host resides
 - **SYSLOG FORMAT**: Specify the Syslog format as either **ADTRAN** (to work with ADTRAN Utilities) or **UNIX** (to work with a standard UNIX Syslog server)
 - **SYSLOG FACILITY**: Specify the facility destination of log events; Options are **LOCAL0** to **LOCAL7**


Setting Up the Syslog Host:

1. On your PC, go to **START/PROGRAMS/ADTRAN UTILITIES/SYSLOG**. When the Syslog window opens, you will see **LOCAL0** through **LOCAL7** listed on the left. This should correspond with the **HOST FACILITY** specified in the Total Access 850. The Syslog program must be open on your PC in order for it to record Total Access 850 information. The Syslog files can be viewed through the Syslog window, and they are also available under the ADTRAN Utilities Folder named **LOCALX.TXT**, where X can equal 0 through 7. You can also view the **LOCALX.TXT** file by clicking on **EDIT LOG**.




Additional Syslog Features:


- The **MONITOR** feature allows all Syslog messages to be prefiltered by **SYSTEM NAME**, **SOURCE**, **SLOT**, and **PORT** before displaying these messages to the user and logging the message to the pre-designated monitor log file. Various filter options may be defined by selecting **SOURCE**. The figure below shows the **SOURCE FILTER** window. When the **MONITOR** button is selected, the file will be logged to **LOCAL8.TXT**. To look at the text file, click on the **EDIT LOG** button on the left side of the Syslog screen. Only the **SOURCE** options that are selected with an 'x' will be displayed in the Syslog file. In this example, all options are displayed.



- Under the **LOG FILES** menu option, the user may erase log files, define Red events, set priorities, and clear Red events. The **ERASE LOG FILES** option erases the specified text log file.
 - **DEFINE RED EVENTS** allows the user to predefine a message priority condition so that if the condition occurs, the file is highlighted in red. In the figure below, any **CRITICAL** or **MAJOR** condition causes any **LOCAL0** through **LOCAL7** facility to become highlighted in red if it receives a critical or major alarm.



- The **PROPERTIES** menu allows the user to specify the types of messages to be logged to an ASCII text file. Mark the lowest priority Syslog message you want to log to the Syslog server text file. For example, the figure below shows that all messages will be logged to the text file.



- The **HELP** menu also explains these features. Click on **HELP/CONTENTS/SYSLOG HOST DAEMON** for further explanation of Syslog features.

DLP-16 Connecting the Alarm Contacts and the External Input

Introduction

Alarm connections alert the user when a selected alarm condition exists. Pressing the Alarm Cut-Off (**ACO**) switch on the front panel of the Total Access 850 PSU clears the alarm. This procedure details the steps which must be performed to use the Total Access 850 alarm connections and the **ACO** switch.

This procedure should be performed at installation on each Total Access 850 shelf that is wired out to external office alarm equipment.

Prerequisite Procedures

Before beginning this procedure, the Total Access 850 should be mounted in its permanent location.

Tools and Materials Required

- Wire strippers
- Small Phillips screwdriver
- 22 or 24 AWG 2-conductor twisted pair cross-connect wire
- VT100 terminal or PC with VT100 terminal emulation software

WARNING

To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.




Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.


Perform the steps below in the order listed.

1. Backplane alarm connections (P5) are labeled as shown in the table below and illustrated in the figure.

P3 Wire-Wrap Connections		
T1 Connections		
1	R1	DS1 Ring input from network
2	T1	DS1 Tip input from network
3	R	DS1 Ring output from network
4	T	DS1 Tip output from network
5	Gnd	Ground
P5 Wire-Wrap Connections		
Alarm Connections		
1	-48 ALM	DC Alarm output
2	MJVR	Major Alarm Visual Common
3	MJV	Major Alarm Visual
4	MJR	Major Alarm Audible Common
5	MJ	Major Alarm Audible



NOTE *You will have to remove the cover to access the contacts. Refer to the Total Access 850 rear view illustration on the next page.*



2. Alarm relay contacts are open during normal operation. The alarm relay contacts close in the event of a local alarm condition or the receipt of an alarm from the T1 Carrier.
3. In a carrier alarm condition such as a Red, Yellow, or Blue (unframed all 1s), various alarm contacts in the PSU close.
4. Carrier alarm conditions cause the Total Access 850 to initiate trunk processing. The following chain of events then occur:
 - MJ will be directly shorted to MJR.
 - MJV will be directly shorted to MJVR.
5. Contacts MJ and MJR can be overridden manually during an alarm condition by pressing the ACO pushbutton on the PSU faceplate.
6. If the 3-Amp power fuse on the PSU trips, the -48 ALM relay will close, providing a -48 VDC signal on that pin. This alarm cannot be overridden by the ACO pushbutton. Refer to the table below for alarm notifications.

Alarm Condition	Relays Activated		
	MJR	MJVR	-48 ALM
RED ALARM	X	X	
YELLOW ALARM	X	X	
AIS ALARM	X	X	
PSU POWER FUSE FAILS	X	X	X
ALARMS ACO DEACTIVATES	X	X	
Note: ACO will not deactivate MJR after a power fuse failure.			

DLP-17 Configuring the Total Access 850 for Dual T1 Maps

Introduction

The Total Access 850 with firmware A.04.02 or higher has a **DUAL T1 MAP** feature that allows two network T1 connections for the termination of data and voice applications. The primary network **T1 MAP** can be configured for internal router usage (FT1/24 DS0s maximum) and to any access module installed. The **DSX MAP** can be used for FXS/FXO modules in slots 1-6 only. There are several steps that must be followed in order for the Dual T1 Map to be configured successfully. These steps are described in this DLP.

Prerequisite Procedures

This procedure assumes that the user has access to the Total Access 850 system menus.



Refer to DLP-1, Connecting a VT100 Terminal or PC to the CRAFT Port, for details on making a terminal connection to the Total Access 850.



To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.



Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

Perform the steps below in the order listed.

1. Connect the Total Access 850 unit to your VT100 system (details found in DLP-1, *Connecting a VT100 Terminal or PC to the CRAFT Port*).
2. Log in to the system with maximum rights (details are in DLP-2, *Logging in to the System*).
3. From the **DS0 MAPS** menu, select the **ACTIVE MAP** option and press **<Enter>**.
4. From the **DS0 MAPS > ACTIVE MAPS** menu, select the **DUAL T1 MAP** option; press **<Enter>**. Select "Y" for yes to confirm the Active Map change and press **<Enter>**. The following screen appears.



The second T1 connected to the DSX port may only be used for voice connections (FXS/FXO). The second T1 must be connected to the integrated DSX port, not the DSX-1 Card.




Figure 1. Dual T1 Map

5. Edit the Primary T1 Map by pressing <Enter> on EDIT/VIEW T1 MAP [+]. The following screen appears.




Figure 2. Primary T1 Map

NOTE *The T1 Map can be mapped to the internal router or other available access module.*

- Edit the Secondary T1 Map (DSX Map) by pressing **<Enter>** on **EDIT/VIEW DSX MAP [+]**. The following screen appears.




Figure 3. DSX Map

NOTE *The DSX Map can be mapped to the FXS and FXO access modules only.*

- Left arrow back to **DS0 MAPS** and log off by pressing **<CTRL+L>**.

ADTRAN UTILITIES

This section provides instructions for configuring and using the ADTRAN Utilities software programs including Telnet, VT100, Syslog, and TFTP.

ADTRAN delivers several PC software utilities with the Total Access 850. These utilities are located on the CD-ROM that came with your shipment. The utilities make it easier to interface with the terminal menu and transfer configuration files to and from TFTP servers. The utilities all run on Microsoft Windows 3.1 or higher. The following sections describe the Syslog, Telnet, VT100, and TFTP Server utilities.



Review the readme file (Readme.txt) on the CD-ROM for the latest information about the utilities.

CONTENTS

Telnet Utility	270
Session Menu	271
Edit Menu	272
Options Menu	272
Capture Menu	272
Help Menu	273
VT100 Utility	273
Session Menu	274
Edit Menu	274
Port Menu	274
Options Menu	274
Capture Menu	275
Help Menu	275
TFTP Server	275
Server Menu	276
Print Log	276
Help	277
Status Field	277
Meter Field	277
Log Field	277

FIGURES

Figure 1. Telnet Menu Tree	270
Figure 2. VT100 Menu Tree	273
Figure 3. TFTP Server Interface Menu Tree	275
Figure 4. TFTP Server Interface	276

1. TELNET UTILITY

Access the Telnet program remotely through the Ethernet port. For a detailed description of how to work within the terminal menu, refer to *Navigating the Terminal Menu* on page 67 (in the User Interface Guide section of this manual). The Telnet menus include **SESSION**, **EDIT**, **OPTIONS**, **CAPTURE**, and **HELP** (see the menu tree in Figure 1).

Telnet	Session	Connect	Host Name
			Port
		Disconnect	Edit Entry
		Transfer Cfg	Add New
		Exit	Delete
		Connect	
	Edit	Copy	
		Paste	
	Options	Colors	Background
		Local Echo	Bold
		Auto Repeat	Text
		File	Start Cfg Capture
			Stop Cfg Capture
	Capture	Buffer Size	
		Save Buffer As	
		Screen Capture	
	Help	Contents	
		IP Status	
		About	


Figure 1. Telnet Menu Tree

Session Menu

Click on **SESSION** to open the Telnet session.

Connect

Opens dialog box for setting **HOST NAME** and **PORT** parameters for a Telnet session. Also lets you **EDIT ENTRY**, **ADD NEW** entry, and **DELETE** stored entries. When the parameters are set, click **CONNECT** to make the connection. Click **CANCEL** to end the session.



Host Name

Accepts and stores host names. You may enter either a name, an IP address, or a domain name directly from this field. Click on the drop-down arrow to display a complete list of previously stored host names.


Port

Provides several port options. You may enter port numbers directly into this field to connect to non-standard ports or select the drop-down combo-box to display the following options:

TELNET	establishes a Telnet session
ECHO	provides a loopback for troubleshooting
DISCARD	bit bucket; discards data
DAYTIME	returns the time
CHARGEN	displays as a unique character stream; used for self-tests

Edit Entry

Changes either the unit name or the IP address of each host. Press either **Tab**, **Return**, or a **period (.)** after each number in the IP address to move to the next field. If you press **Return** or enter a period while the cursor is located in an IP field, that field entry is deleted.



Add New

Prompts you for the same information as the **EDIT ENTRY** dialog box for new host. When enabled, the **USE DNS** (Domain Name Server) feature allows users to request **DOMAIN LOOK UP** via a DNS server on the network, rather than specifying an IP address. The name then appears in the **HOST NAME** field.

Delete

Removes a host name from the list; select the host name you want to remove, and, at the prompt, click **DELETE**.

Connect

Establishes the Telnet session.

Disconnect

Terminates the Telnet session.

To re-establish the session, select **CONNECT** from **SESSION MENU** or press **ENTER** three times. This action restores the previous connection.

Transfer Cfg

This feature is used with ADTRAN products to send configuration files to the unit.

Exit

Ends the Telnet session and closes the Telnet screen.

Edit Menu

Provides **COPY** and **PASTE** commands.

Options Menu

Provides viewing alternatives for the terminal screen.

Colors

Three options change the color of the background window (**BACKGROUND**), bold highlights (**BOLD**), and text (**TEXT**).

Local Echo

Echoes each character that you enter.

AutoRepeat

Repeats characters you select from the keyboard, if you hold down the key.

Capture Menu

Provides options for capturing screen images.

File

Sends screen options data to a file in the format options listed below:

Start Cfg Capture

Used with the ADTRAN product line to start sending the scrolling screen capture to a file storage location.

Stop Cfg Capture

Used with the ADTRAN product line to stop sending the scrolling screen capture to a file storage location.

Buffer Size

Disables terminal window scroll bars when set to zero. (This is the normal setting for Total Access 850.) This number represents the number of lines to capture in the memory buffer.

Save Buffer As

Save screen capture to a file.

Screen Capture

Copies the text on the current Telnet screen to the clipboard. You can open any word processor and paste the clipboard contents into the program. This option is helpful when debugging.

Help Menu

Provides online help for using the ADTRAN Utilities.

Contents

Opens the online help.

IP Status

Displays the local port address and the status of the connection.

About

Displays version and owner information.

2. VT100 UTILITY

Use the VT100 to configure an Total Access 850 which is directly connected to a PC. The VT100 display is almost identical to the Telnet display. For a detailed description of how to work within the terminal menu, refer to *Navigating the Terminal Menu* on page 67 (in the User Interface Guide section of this manual). If you need help setting up the Total Access 850 for a VT100 session, refer to DLP-1, *Connecting a VT100 Terminal or PC to the CRAFT Port*. VT100 menus include **SESSION**, **EDIT**, **PORT**, **OPTIONS**, **CAPTURE**, and **HELP** (see the menu tree in Figure 2).




Figure 2. VT100 Menu Tree

Session Menu

Opens VT100 terminal emulation session.

Connect

Opens a specified serial port for a VT100 session.

Disconnect

Closes a specified serial port at the end of a VT100 session.

File Transfer

Uploads and downloads files to and from an Total Access 850.

XMODEM CRC

Selects the XMODEM file transfer protocol.

ASCII Cfg Files


Selects ASCII transfer mode. Primarily useful for configuration transfers for the ADTRAN products.

Edit Menu

Identical to the Telnet **EDIT MENU** (see *Edit Menu* on page 272).

Port Menu

Changes serial COM port **SETTINGS**. Provides data rate settings from 300-57600 bps.



Options Menu

Provides terminal screen commands.

Refresh Screen

Redraws the screen.

Connect

Provides the options **TRANSMIT WAKEUP** and **TRANSMIT REFRESH**.

Transmit Wakeup

Provides a control sequence that puts the Total Access 850 Control Port online in terminal mode.

Transmit Refresh

Provides a control sequence to refresh the screen automatically when connecting. (This is the default setting for the Total Access 850.)

Colors

Identical to Telnet **COLORS MENU** (see *Colors* on page 272).

Local Echo

Echoes each character that you enter.

AutoRepeat

Repeats characters you select from the keyboard, if you hold down the key.

Capture Menu

Identical to the Telnet **CAPTURE MENU** (see *Capture Menu* on page 272).

Help Menu

Provides online help and information about the version number.

Contents


Opens online help.

About

Displays version and owner information.

3. TFTP SERVER

The TFTP Server utility transfers Total Access 850 configuration files to and from a TFTP server (see Figure 3 for the menu tree). You can install this program on a PC running any version of Microsoft Windows. The configuration of an Total Access 850 can be saved offline as a backup file. The saved file may also be used to send the same configuration to multiple Total Access 850 units. Transfer configuration files using the TFTP protocol (a TCP/IP user protocol) via the Ethernet port. The Total Access 850 must have a valid IP address, subnet mask, and default gateway (if required), and be connected to an Ethernet network before proceeding. Figure 4 shows the TFTP server interface. For information on transferring and saving configurations using TFTP, refer to DLP-9, *Saving the Current Configuration Using TFTP*.



NOTE

*Files must be placed in the Application directory where you installed the product.
Received files are also placed here.*




Figure 3. TFTP Server Interface Menu Tree




Figure 4. TFTP Server Interface

Only one configuration transfer session (upload or download) may be active at a time. The TCP/IP parameters are not saved or overwritten as part of an Total Access 850 unit's transferred configuration to allow sending identical configurations to multiple units. When you start this program, a port is automatically opened.

Server Menu

Provides enable, disable, abort, and exit options.

Enable

Enables the TFTP server. The IP address displays in the Status field and **Server Ready** displays in the Log field.

Disable

Disables the TFTP server. When you select this option, the message **Port Closed** displays in the **STATUS** field and in the **LOG** field.

Abort

Terminates a transfer that is in progress.

Exit

Terminates active transfers and closes the TFTP window.

Print Log

Provides print options.

...to Clipboard

Copies the information in the **LOG** field to the clipboard. You can then open any word processor and paste the information into the program for review.

...to Printer

Sends the information in the **LOG** field to the default printer.

Clear Log

Deletes the information stored in the **LOG** field.

Help

Provides online help and version information.

Contents

Opens online help.

About

Displays version and owner information.

4. STATUS FIELD

This field displays general information about port and transfer status. This field is read-only. The unlabeled field in the center of the screen displays prompts about the status of active transfers, such as bytes transferred and received.

5. METER FIELD

The **XMIT** meter provides a visual record of the transfer progress.

6. LOG FIELD

This field displays a record of all of the events that occur during the time the TFTP Server is enabled. Use the scroll bar to move up and down the list. To clear the information in this field, select **CLEAR LOG** from the **PRINT LOG** menu. Save this information to a file before deleting it with the **...TO CLIPBOARD** command.

MIBS

This section is divided into two parts: (1) SNMP information for TDM units and (2) SNMP information for ATM units. Each section details the Management Information Bases (MIBs) supported, MIB Compilation Order, Traps Supported, and MIB Variables supported.

CONTENTS

MIBs Supported by TDM Units	280
MIB Compilation Order For TDM Units	281
Traps Supported by TDM Units	281
MIB Variables Supported by TDM Units	282
MIBs Supported by ATM Units	282
MIB Compilation order for ATM Units	283
Traps Supported by ATM Units	283
MIB Variables Supported by ATM Units	283



For this section, TDM units refers to Total Access 850 units running A.04 firmware or later. ATM units refers to Total Access 850 units running C.02 firmware or previous.



The TDM units support SNMP Version 2. The ATM units support SNMP Version 1.

1. MIBS SUPPORTED BY TDM UNITS

Standard RFC MIBs:

RFC1573.mi2	IANAifType-MIB
RFC1907.mi2	SNMPv2-MIB
RFC2011.mi2	IP-MIB
RFC2096.mi2	IP-FORWARD-MIB
RFC2115.mi2	FRAME-RELAY-DTE-MIB
RFC2493.mi2	PerfHist-TC-MIB
RFC2494.mi2	DS0-MIB and DS0BUNDLE-MIB
RFC2495.mi2	DS1-MIB
RFC2665.mi2	EtherLike-MIB
RFC2863.mi2	IF-MIB
RFC3201.mi2	CIRCUIT-IF-MIB

Enterprise MIBs:

adtran.mi2	ADTRAN-MIB
adladSys.mi2	ADTRAN-ADIADSYS-MIB
adladRtr.mi2	ADTRAN-ADIADROUTER-MIB
adladVoi.mi2	ADTRAN-ADIADVOICE-MIB



SNMPv2-SMI, SNMPv2-TC, SNMPv2-TM, and SNMPv2-CONF should be included with the SNMP manager.



All TDM MIBs are SNMPv2.

2. MIB COMPILATION ORDER FOR TDM UNITS

IANAifType-MIB
 PerfHist-TC-MIB
 SNMPv2-MIB (if not included with SNMP manager)
 IF-MIB
 IP-MIB
 IP-FORWARD-MIB
 FRAME-RELAY-DTE-MIB
 DS1-MIB
 DS0-MIB
 DS0BUNDLE-MIB
 EtherLike-MIB
 CIRCUIT-IF-MIB
 ADTRAN-MIB
 ADTRAN-IADSYS-MIB
 ADTRAN-IADROUTER-MIB

3. TRAPS SUPPORTED BY TDM UNITS

From RFC1215-MIB:	coldStart linkDown linkUp authenticationFailure
From ADTRAN-IADSYS-MIB:	adladWanDown - 1003203 adladWanUp - 1003204 adladBatteryAlarmAct - 1003207 adladBatteryAlarmDeact - 1003208
(T1 WAN interface only):	adladDs1RedAlarmON - 1003209 adladDs1YellowAlarmON - 1003210 adladDs1BlueAlarmON - 1003211 adladDs1RedAlarmOFF - 1003212 adladDs1YellowAlarmOFF - 1003213 adladDs1RedAlarmON - 1003209 adladDs1YellowAlarmON - 1003210 adladDs1BlueAlarmON - 1003211 adladDs1RedAlarmOFF - 1003212 adladDs1YellowAlarmOFF - 1003213 adladDs1BlueAlarmOFF - 1003214 adladDs1SEF - 1003215 adladDs1FS - 1003216

(T1 WAN interface only):	adladDs1CRC - 1003217 adladDs1LCV - 1003218 adladDs1SLP - 1003219
From ADTRAN-IADVOICE-MIB:	adladVoiceTestStatusActive - 1003401 adladVoiceTestStatusClear - 1003402 adladVoiceAlarmBitActive - 1003403 adladVoiceAlarmBitInactive - 1003404 adladVoiceGatewayDown - 1003405 adladVoiceGatewayUp - 1003406 adladVoiceaLifeLineActivated - 1003407 adladVoiceaLifeLineDeactivated - 1003408

4. MIB VARIABLES SUPPORTED BY TDM UNITS

SNMPv2 states the supported MIB variables by the following method:

The unit will have a MIB called TA 6XX.mi2 that will describe the SNMP variables supported. This MIB will contain an Agent Capabilities module that will describe the SNMP variables supported.

5. MIBs Supported by ATM Units

Standard RFC MIBs:

RFC1213.mib	RFC1213-MIB
RFC1406.mib	DS1-MIB (T1 interface only)
RFC1695.mib	ATM-MIB

Enterprise MIBs:

Adtran.mib	ADTRAN-MIB
adtartr_trap.mib	ADTRAN-ADTARTR_TRAP-MIB



RFC1155-SMI, RFC1212-MIB, and RFC1215-MIB are also needed and should come standard with any SNMP Management software.



All ATM MIBs are SNMPv1.

6. MIB COMPILATION ORDER FOR ATM UNITS

RFC1213-MIB
 RFC1406-MIB
 RFC1695-MIB
 ADTRAN-MIB
 ADTRAN-ADTARTR-TRAP-MIB

7. TRAPS SUPPORTED BY ATM UNITS

From ADTARTR_TRAP MIB:	coldStart
	linkUp
	linkDown
	authenticationFailure
	adTARouterWanDown - 6645503
	adTARouterWanUp - 6645504
	adTARouterBatteryAlarmAct - 6645507
	adTARouterBatteryAlarmDeact - 6645508
	adTARouterVoiceGatewayDown - 6645509
	adTARouterVoiceGatewayUp - 6645510
	adTARouterLifeLineActivated - 6645511
	adTARouterLifeLineDeactivated - 6645512

8. MIB VARIABLES SUPPORTED BY ATM UNITS



ATM units do not support write access for SNMP (except for sysName, sysLocation, and sysContact).

system:

sysDescr	RO
sysObjectID	RO
sysUpTime	RO
sysContact	RW
sysName	RW
sysLocation	RW
sysServices	RO

interfaces:

ifIndex	RO
ifDescr	RO
ifType	RO

ifMtu	RO
ifSpeed	RO
ifPhysAddress	RO
ifOperStatus	RO
ifInOctets	RO
ifInUcastPkts	RO
ifInNUcastPkts	RO
ifInDiscards	RO
ifInErrors	RO
ifInUnknownProtos	RO
ifOutOctets	RO
ifOutUcastPkts	RO
ifOutNUcastPkts	RO
ifOutDiscards	RO
ifOutErrors	RO
ifSpecific	RO

ip:

ipForwarding	RO
ipDefaultTTL	RO
ipInReceives	RO
ipInHdrErrors	RO
ipInAddrErrors	RO
ipForwDatagrams	RO
ipInUnknownProtos	RO
ipInDiscards	RO
ipInDelivers	RO
ipOutRequests	RO
ipOutDiscards	RO
ipOutNoRoutes	RO
ipReasmOKs	RO
ipReasmFails	RO
ipFragOKs	RO
ipFragFails	RO
ipFragCreates	RO

ipAddrTable:

ipAddrEntry		
	ipAdEntAddr	RO
	ipAdEntIfIndex	RO
	ipAdEntNetMask	RO
	ipAdEntBcastAddr	RO
	ipAdEntReasmMaxSize	RO
ipRouteTable:		
ipRouteEntry		
	ipRouteDest	RO
	ipRouteIfIndex	RO
	ipRouteMetric1	RO
	ipRouteMetric2	RO
	ipRouteMetric3	RO
	ipRouteMetric4	RO
	ipRouteNextHop	RO
	ipRouteType	RO
	ipRouteProto	RO
	ipRouteAge	RO
	ipRouteMask	RO
	ipRouteMetric5	RO
	ipRouteMetricInfo	RO
ipNetToMediaTable:		
ipNetToMediaEntry		
	ipNetToMediaIfIndex	RO
	ipNetToMediaPhysAddress	RO
	ipNetToMediaNetAddress	RO
	ipNetToMediaType	RO
	ipRoutingDiscards	RO
icmp:		
icmpInMsgs	RO	
icmpInErrors	RO	
icmpInDestUnreachs	RO	
icmpInTimeExcds	RO	
icmpInParmProbs	RO	
icmpInSrcQuenchs	RO	
icmpInRedirects	RO	
icmpInEchos	RO	
icmpInEchoReps	RO	
icmpInTimestamps	RO	
icmpInTimestampReps	RO	

icmpInAddrMasks	RO
icmpInAddrMaskReps	RO
icmpOutMsgs	RO
icmpOutErrors	RO
icmpOutDestUnreachs	RO
icmpOutTimeExcds	RO
icmpOutParmProbs	RO
icmpOutSrcQuenches	RO
icmpOutRedirects	RO
icmpOutEchos	RO
icmpOutEchoReps	RO
icmpOutTimestamps	RO
icmpOutTimestampReps	RO
icmpOutAddrMasks	RO
icmpOutAddrMaskReps	RO

tcp:

tcpRtoAlgorithm	RO
tcpRtoMin	RO
tcpRtoMax	RO
tcpMaxConns	RO
tcpActiveOpens	RO
tcpPassiveOpens	RO
tcpAttemptFails	RO
tcpEstabResets	RO
tcpCurrEstab	RO
tcpInSegs	RO
tcpOutSegs	RO
tcpRetransSegs	RO

tcpConnTable

tcpConnEntry

tcpConnState	RO
tcpConnLocalAddress	RO
tcpConnLocalPort	RO
tcpConnRemAddress	RO
tcpConnRemPort	RO

tcpInErrs	RO
-----------	----

tcpOutRsts	RO
------------	----

udp:

udpInDatagrams	RO
udpNoPorts	RO
udpInErrors	RO
udpOutDatagrams	RO
udpLocalAddress	RO
udpLocalPort	RO

udpTable

udpEntry

udpEntryLocalAddress	RO
udpLocalPort	RO

egp:

egpInMsgs	RO
egpInErrs	RO
egpOutMsgs	RO
egpOutErrors	RO
egpNeighState	RO
egpNeighAddr	RO
egpNeighAs	RO
egpNeighInMsgs	RO
egpNeighInErrs	RO
egpNeighOutMsgs	RO
egpNeighOutErrs	RO
egpNeighInErrMsgs	RO
egpNeighOutErrMsgs	RO
egpNeighStateUps	RO
egpNeighStateDowns	RO
egpNeighIntervalHello	RO
egpNeighIntervalPoll	RO
egpNeighMode	RO

dsx1:

dsx1ConfigTable

dsx1ConfigEntry

dsx1LineIndex	RO
dsx1IfIndex	RO
dsx1TimeElapsed	RO
dsx1ValidIntervals	RO
dsx1LineType	RO
dsx1LineCoding	RO
dsx1SendCode	RO
dsx1CircuitIdentifier	RO
dsx1LoopbackConfig	RO
dsx1LineStatus	RO
dsx1SignalMode	RO
dsx1TransmitClockSource	RO
dsx1Fdl	RO

dsx1CurrentTable

dsx1CurrentEntry

dsx1CurrentIndex	RO
dsx1CurrentESs	RO
dsx1CurrentSESs	RO
dsx1CurrentSEFs	RO
dsx1CurrentUASs	RO
dsx1CurrentCSSs	RO
dsx1CurrentPCVs	RO
dsx1CurrentLESs	RO
dsx1CurrentBESs	RO
dsx1CurrentLCVs	RO

dsx1IntervalTable

dsx1IntervalEntry

dsx1IntervalIndex	RO
dsx1IntervalNumber	RO
dsx1IntervalESs	RO
dsx1IntervalSESs	RO
dsx1IntervalSEFs	RO
dsx1IntervalUASs	RO
dsx1IntervalCSSs	RO
dsx1IntervalPCVs	RO
dsx1IntervalLESs	RO
dsx1IntervalBESs	RO
dsx1IntervalLCVs	RO

dsx1TotalTable

dsx1TotalEntry

dsx1TotalIndex	RO
dsx1TotalESs	RO
dsx1TotalSESs	RO
dsx1TotalSEFs	RO
dsx1TotalUASs	RO
dsx1TotalCSSs	RO
dsx1TotalPCVs	RO
dsx1TotalLESs	RO
dsx1TotalBESs	RO
dsx1TotalLCVs	RO

dsx1FracTable

dsx1FracEntry

dsx1FracIndex	RO
dsx1FracNumber	RO
dsx1FractIfIndex	RO

snmp:

snmpInPkts	RO
snmpOutPkts	RO
snmpInBadVersions	RO
snmpInBadCommunityNames	RO
snmpInBadCommunityUses	RO
snmpInASNParseErrs	RO
snmpInTooBig	RO
snmpInNoSuchNames	RO
snmpInBadValues	RO
snmpInReadOnly	RO
snmpInGenErrs	RO
snmpInTotalReqVars	RO
snmpInTotalSetVars	RO
snmpInGetRequests	RO
snmpInSetRequests	RO
snmpInGetRequests	RO
snmpInTraps	RO
snmpOutTooBig	RO
snmpOutNoSuchNames	RO
snmpOutBadValues	RO
snmpOutGenErrs	RO
snmpOutGetRequests	RO
snmpOutGetNexts	RO
snmpOutSetRequests	RO
snmpOutGetResponses	RO
snmpOutTraps	RO
snmpEnableAuthenTraps	RO

atm:

atmInterfaceTable

atmInterfaceEntry

atmInterfaceMaxVpcs	RO
atmInterfaceMaxVccs	RO
atmInterfaceConfVpcs	RO
atmInterfaceConfVccs	RO
atmInterfaceMaxActiveVpiBits	RO
atmInterfaceMaxActiveVciBits	RO
atmInterfaceLmiVpi	RO
atmInterfaceLmiVci	RO
atmInterfaceAddressType	RO
atmInterfaceAdminAddress	RO
atmInterfaceMyNeighborIpAddress	RO
atmInterfaceMyNeighborIfName	RO

atmInterfaceTCTable

atmInterfaceTCEntry

atmInterfaceOCDEvents	RO
atmInterfaceTCAlarmState	RO

atmTrafficDescrParamTable

atmTrafficDescrParamEntry

atmTrafficDescrParamIndex	RO
atmTrafficDescrType	RO
atmTrafficDescrParam1	RO
atmTrafficDescrParam2	RO
atmTrafficDescrParam3	RO
atmTrafficDescrParam4	RO
atmTrafficDescrParam5	RO
atmTrafficDescrQosClass	RO
atmTrafficDescrRowStatus	RO

atmVciTable

atmVciEntry

atmVciVpi	RO
atmVciVci	RO
atmVciAdminStatus	RO
atmVciOperStatus	RO

	atmVclLastChange	RO
	atmVclReceiveTrafficDescrIndex	RO
	atmVclTransmitTrafficDescrIndex	RO
	atmVccAalType	RO
	atmVccAal5CpcsTransmitSduSize	RO
	atmVccAal5CpcsReceiveSduSize	RO
	atmVccAal5EncapsType	RO
	atmVclCrossConnectIdentifier	RO
	atmVclRowStatus	RO
aal5VccTable		
aal5VccEntry		
	aal5VccVpi	RO
	aal5VccVci	RO
	aal5VccCrcErrors	RO
	aal5VccSarTimeOuts	RO
	aal5VccOverSizedSDUs	RO