



INSTALLATION INSTRUCTIONS

1. On the rear of the ATLAS 550 chassis, remove the cover plate covering the slot into which the option module carrying the 32 Channel ADPCM Resource Module is to be inserted.

If the ATLAS 550 option module is already in the ATLAS 550 chassis, simply loosen the thumbscrews at both edges of the option module faceplate and slide the module out of the chassis.

2. Carefully align the raised connector on the 32 Channel ADPCM Resource Module with the connector mate on the option module.

Using only fingertip pressure so that neither circuit board bends or flexes, ensure that the connectors are firmly seated.

Secure the opposite end of the 32 Channel ADPCM Resource Module to the option module using the screws and standoff posts supplied.

3. Slide the option module with the 32 Channel ADPCM Resource Module attached into the ATLAS 550 chassis until the module is positioned firmly against the front of the chassis.
4. Fasten the thumbscrews at both edges of the option module faceplate. Tighten with a screwdriver.
5. Install any additional modules into the base unit as specified in the Installation chapter of the ATLAS 550 User Manual.

MENU TREE

		Info	Part Number
Stt		Status	Serial Number
Type			Assembly Revision
ADPCM-32 Menus			Device
Alarm		Config	Status
Test			Configure Devices
Modules	State	Device	Algorithm
	Online		Connection
	Offline	Device	Device
Status		State	Enable
Rev			Disable
		Device	
		Usage Time	
		ATLAS Frms	
		ATLAS Drop	
		Mod Frms	
		Mod Drop	
		Clear	