

Article ID: 1419

What if the DSU III S2W displays "Waiting for PTS" when trying to dial?

	_	
•	_	
•	J	

What if the DSU III S2W displays "Waiting for PTS" when trying to dial?

A:

Call the telco. This message means that the unit is not receiving the Proceed To Select signal from the telco, so it is not able to dial the number.