



Q&A

What are the pinouts for the Express 5000 series DTE/DCE connector?

Q:

What are the pinouts for the Express 5000 series DTE/DCE connector?

A:

The DTE/DCE connector pin assignments are listed in the following matrix.

DB25 Pin #	V.35 Pin #	Function	DTE Port Direction	DCE Port Direction
1	A	FGND		
2		TD (RS232)	I	O
3		RD (RS232)	O	I
4	C	RTS	I	O
5	D	CTS	O	I
6	E	DSR	O	I
7	B	GND		
8	F	DCD	O	I
9		NEG		
10		POS		
11	AA	TC-B (V.35)	O	I
12	Y	TC-A (V.35)	O	I
13	V	RC-A (V.35)	O	I
14	T	RD-B (V.35)	O	I
15		TC (RS232)	O	I
16	R	RD-A (V.35)	O	I
17		RC		
18	S	TD-B (V.35)	I	O
19	P	TD-A (V.35)	I	O
20	H	DTR	I	O
21	W	ETC-B (V.35)	I	O
22				
23	U	ETC-A (V.35)	I	O
24		ETC (RS232)	I	O
25	X	RC-B (V.35)	O	I
I - INPUT				

O - OUTPUT