



Q&A

What are the default passwords (passcodes) for ADTRAN products?

Q: What are the default passwords (passcodes) for ADTRAN products

A:

Note: Where the product has no default password, **Default Password** will be listed as N/A.

Product	Key sequence (wake up unit)	Default Password
TSU/TDU XX0	<CTRL>PTT	N/A
TSU/TDU XX0"e" TSU XX0 "2nd Gen"	<CTRL>PTT	ADTRAN
TSU/TDU ESP	<CTRL>PTT	adtran (for Telnet only!)
TSU LT	<CTRL>PTT	N/A
HSU XX0	<CTRL>PTT	N/A
T3SU 300	Hit enter a few times	adtran
Agent card	<CTRL>PTT	ADTRAN
TSU Router Module/L128/L768/1.5	Hit enter a few times (CTRL-R to refresh screen)	N/A (Hit enter at login prompt)
ATLAS Products	<CTRL> R	password
NxIQ	Hit enter a few times	adtran
TSU IQ/DSU IQ	Hit enter a few times	adtran
FSU/FSU 5622 Express 5110/5200/5210	Hit enter a few times	adtran
Smart 16/16e	Hit enter a few times	PASSWORD (if enabled)
MX2800	Hit enter a few times	adtran
