



Article ID: 1460

Q&A

How do I configure ADTRAN TSU/Total Access/Express Routers for UDP Relay?

Q: How do I configure ADTRAN TSU/Total Access/Express Routers for UDP Relay?

A: To configure ADTRAN TSU/Total Access/Express Routers for UDP Relay, you will need to add the IP address of the server that will receive the relay packets to the UDP RELAY LIST in the ADTRAN Express routers. Go to **>CONFIGURE >IP >UDP RELAY** and turn the **MODE** set *ON*. Then go to **UDP RELAY LIST** and create an entry. (If there are no entries, one will be created. If there is already an entry, type **I** for insert and a new one will be created.) The **Relay Address** is the IP address of the server that will receive the relay packet. Change the **UDP Port Type** from *Standard* to *Specified* and type in the UDP port(s) under **UDP PORT 1**, **UDP PORT 2**, and **UDP PORT 3**.
