

**SPECIFICATIONS**

- Bandwidth (DTE):** 56K to 1472 kbps (56K or 64K steps; a BONDing Module is needed for speeds greater than 64kbps)
- Interfaces:** RS-366 dialing interface and DTE port (V.35, RS-449, EIA-530)
- RS-366:** Type II and III interfaces
- Dial Options:** Manual, DTR Dialing, or RS-366
- Tests (DTE):** Local Loopback (Bilateral)

**Smart Dial String:**


- C: Bearer Capability for call (3=56k data, 4=64k data)
- R: Specifies the number of channels to use for the call. [1=(56k or 64k) Clear Channel, No BONDING; 2-32=Nx (56k or 64k) BONDING Mode 1]
- S: Source ID used to route the call

**INSTALLATION INSTRUCTIONS**

- Remove the cover plate from the appropriate option slot in the ATLAS 800 Series Unit.
- Slide the Dual Video Module into the option slot until the module is firmly positioned against the front of the chassis.
- Secure the thumbscrews at both edges of the module. Tighten with a screwdriver.
- Connect the cables to the associated device(s).
- Complete installation of remaining modules and Base Unit as specified in the Installation chapter of the ATLAS 800 Series System Manual.

**DB-68 CONNECTION PINOUT**

Pin	Name	Pin	Name
1	UNUSED	35	CHASSIS GROUND
2	TD_A	36	NB1
3	RC_A	37	NB2
4	TD_B	38	NB4
5	RC_B	39	NB8
6	RD_A	40	DPR
7	TC_A	41	ACR
8	RD_B	42	CRQ
9	TC_B	43	PND
10	XC_A	44	RC
11	RTS_A	45	SC
12	XC_B	46	PWI
13	RTS_B	47	DSC
14	CTS_A	48	DLO
15	DTR_A	49	SIGNAL GROUND
16	CTS_B	50	MOD 0
17	DTR_B	51	SIGNAL GROUND
18	DCD_A	52	MOD 1
19	DSR_A	53	SIGNAL GROUND
20	DCD_B	54	MOD 2
21	DSR_B	55	SIGNAL GROUND
22	RI_A	56	CABLE SELECT
23-33	UNUSED	57-67	UNUSED
34	SIGNAL GROUND	68	SIGNAL GROUND

### MENU TREE

