



## NETWORK CONNECTION PINOUT

Pin	Name	Description
1	R1 RXDATA	Receive data from the Network - Ring
2	T1 RXDATA	Receive data from the Network - Tip
3, 6, 7, 8	UNUSED	n/a
4	R TXDATA	Transmit data towards the Network - Ring
5	T TXDATA	Transmit data towards the Network - Tip

## REAR PANEL DESCRIPTIONS

<b>Network Connector</b>	Connection to T1 circuit
<b>Test Interface</b>	Bantam jacks provided for monitoring and testing
<b>Control In/Out</b>	Connection to a VT100 terminal or emulator
<b>V.35 Connector</b>	High-speed DTE interface
<b>Power Switch</b>	Turns power to the TSU on or off
<b>115 VAC Connection</b>	Power cord connection for a reliably grounded 115 VAC, 60 Hz power source

## INSTALLATION INFORMATION

- An eight-position modular jack (labeled **NETWORK**) is provided to connect to the network T1 circuit. The pinout is provided on this Quick Start Guide. See *Chapter 2, Installation*, of the TSU User Manual for more information.
- The rear panel contains a single V.35 interface for connecting to DTE equipment. The pinout for this interface is located in *Appendix A* of the TSU User Manual.
- When shipped from the factory, the TSU is uninitialized and set to factory default conditions. Upon the first application of power, the unit will automatically execute self-tests followed by an initialization sequence.
- The TSU can be configured and controlled using the local front panel of the unit, a VT 100 terminal or emulator connected to the chain-in port, or from ADTRAN's PC Control Program, T-WATCH. A limited menu tree is provided on the back of this sheet. For more detailed menu information, refer to the TSU User Manual.
- Additional information can be found on the product CD which contains the TSU User Manual, FAQs, Data Sheets, Applications, and White Papers.

## MENU TREE - OVERVIEW

MAIN MENU	1) STATUS	1) NI PERF REPORTS		
		2) CURR ERR/ALM		
		3) ERR/ALM HISTORY		
	2) CONFIG	1) NETWORK (NI)		
		2) UNIT		
		3) PORT		
	3) UTIL	1) TIME/DATE		
		2) SOFTWARE REV	Displays the current software revision	
		3) REINIT UNIT		
		4) ADDRESS		
		5) FACTORY RESTORE	Restores all configurations to factory settings	
	4) TEST	1) NETWORK TESTS		
2) RUN SELF TEST				
3) PORT TESTS				