

Documentation for ADTRAN Carrier Networks products is available for viewing and download directly from the ADTRAN Support Community website.

Go to: <https://supportforums.adtran.com/welcome>

Registration is required.

ADTRAN offers training courses on our products, including customized training and courses taught at our facilities or at customer sites.

For inquiries, go to: <http://adtran.com/training>

The following Online documents and resources provide additional information for this product: ADTRAN Pluggable Optics Compatibility Matrix (online tool, go to: <http://www.adtran.com/pluggableoptics>)

DESCRIPTION

The Small Form-Factor Pluggable 9.95 to 11.3 Gigabit Single-Mode Fiber (SFP+) with Clock and Data Recovery (CDR) optical transceiver is a fully duplex serial electric, serial optical device with both transmit and receive functions contained in a single module. It provides a high speed serial link at a rate of 9.95 to 11.3 Gbps. When installed into an appropriate host module, the SFP+ provides a 9.95 to 11.3 Gigabit interface to the supporting system.

The transmit side of the SFP+ converts serial NRZ electrical data at the 9.95 to 11.3 Gbps line rate to a standard compliant optical signal. The receive side of the SFP+ converts the incoming DC balanced serial NRZ optical data at the 9.95 to 11.3 Gbps line rate into serial electrical data.

NOTE

To ensure compatibility, refer to the documentation provided with the host module.

FEATURES

The following features are supported on the SFP+:

- 1550 nm optical signals for up to 80 km reach
- Bit error rate (1×10^{-12})
- Excellent EMI performance

CAUTION

Due to compliance certification requirements, use only SFP+ modules supplied by ADTRAN with the host module. ADTRAN cannot certify system integrity with other SFP+ modules.

INSTALLATION

Before installation, inspect the SFP+. If damage has occurred during shipping, file a claim with the carrier, and then contact ADTRAN Customer Support. For more information, refer to "Warranty".

Installation Guidelines

The following are guidelines for this installation.

- The latch on the SFP+ is for removal only. When removing the SFP+, rotate the latch away from the SFP+. The SFP+ should slide easily out of the cage.

- It is recommended that the connector plug remain on whenever the transceiver optical fiber connector is not inserted.

Installation Steps

To install the SFP+, complete the following steps:

1. Insert the SFP+ into the SFP cage on the circuit board of the host module with the latch handle facing outward. Slide the SFP+ all the way into the cage.
2. Exert adequate pressure to ensure the SFP+ is completely seated in the SFP+ cage.
3. Do not remove the connector plug until the optical fiber connection is made.
4. Continue the installation and turn-up of the host module.

SPECIFICATIONS

- Optical
 - ◆ General
 - Optical connectors: LC
 - Optical distance: 80 km maximum
 - Data rate: 9.95 to 11.3 Gbps
 - Optical Path Penalty: 2.5 dB (10.52 Gbps), 3 dB (11.1 Gbps), 3.5 dB (11.35 Gbps)
 - Power Dissipation: 2 Watts max
 - ◆ Transmitter
 - Optical transmit level: 0.0 to +4.0 dBm
 - 1550 nm optical signals for up to 80 km reach
 - ◆ Receiver
 - Optical receive level sensitivity: -7.0 to -23.0 dBm
- Environmental
 - ◆ Controlled Protected Environment (Inside)
 - Operational temperature range: -5°C to +50°C
 - Case temperature hardened range from -5°C to +70°C
 - Storage temperature range: -40°C to +85°C
 - Relative humidity 5 to 85%

SAFETY AND REGULATORY

WARNING

Read all warnings and cautions before installing or servicing this equipment

CAUTION

This product uses a Class 1 Laser module that complies with 21 CFR 1040.10 and 1040.11 and IEC 60825-1, IEC 60825-2, EN 60825-1 and EN 60825-2. For continued compliance with the above standards, only approved Class 1 laser modules from an ADTRAN approved vendor list (located on the ADTRAN website) should be installed in this product. ADTRAN cannot certify system integrity with other laser modules.

CAUTION

- Electrostatic Discharge (ESD) can damage electronic modules. When handling modules, wear an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.
- Per GR-1089-CORE the ADTRAN system that this product is being deployed in is designed and intended for installation as part of a Common Bonding Network (CBN). The ADTRAN system that this product is being deployed in is not designed nor intended for installation as part of an Isolated Bonding Network (IBN).
- Per GR-1089-CORE Section 9, this product does not have an internal DC connection between battery return and frame ground. This product can be installed in a DC-I (isolated) or DC-C (common) installation. For installations where other cards or the host system have internal connections between battery return and frame ground, the system would be intended for deployment only in a DC-C installation.
- The ADTRAN system chassis frame ground terminal must be connected to a reliable earth ground to ensure that the metal enclosure of this product is properly grounded via the backplane connector.

NOTE

- The Gigabit Ethernet port(s) are optical and therefore are not classified as any type of port as defined in Appendix B of GR-1089-CORE.
- This product is compliant with SFF-8472 "Digital Diagnostics Monitoring Interface for Optical Transceivers," Revision 9.3.
- This product is compliant with the SFP+ Multi-Source Agreement (MSA).
- This product is designed to be deployed in GR-3108-CORE environmental class 1,2, or 3 as defined in GR-3108-CORE.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by ADTRAN could void the user's authority to operate this equipment.

This product is designed to meet the following environmental classes:

- ETSI EN 300 019-1-1 *Classification of environmental conditions; Storage*, Class 1.2
- ETSI EN 300 019-1-2 *Classification of environmental conditions; Transportation*, Class 2.3
- ETSI EN 300 019-1-3 *Classification of environmental conditions; Stationary use at weather-protected locations*, Class 3.3

The equipment is designed to function without degradation during exposure to all test severities per Class 3.3.

This product meets EU RoHS Directive. Refer to www.adtran.com for further information on RoHS/WEEE.

FRANÇAIS

⚠️ AVERTISSEMENT

Lisez tous les avertissements et mises en garde avant l'installation de cet équipement ou la réalisation de toute opération de maintenance.

⚠️ ATTENTION

Ce produit utilise un module laser de classe 1 qui conforme aux normes 21 CFR 1040.10, 1040.11 et IEC 60825-1 et -2. Pour assurer la conformité aux normes mentionnées plus haut, seuls des modules laser de classe 1 approuvés provenant d'une liste de fournisseurs certifiés par ADTRAN (disponible sur le site d'ADTRAN) doivent être installés sur ce produit. ADTRAN ne peut certifier l'intégrité d'un système doté d'autres modules laser.

⚠️ CAUTION

- L'ESD (décharge électrostatique) peut endommager les modules électroniques. Lors de la manipulation des modules, portez un bracelet de décharge antistatique pour éviter d'endommager les composants électroniques. Placez les modules dans un emballage antistatique lors du transport ou du stockage. Lorsque vous travaillez sur les modules, placez-les toujours sur un tapis antistatique certifié muni d'un branchement de mise à la terre.
- La borne de mise à la terre du châssis doit être branchée à une prise de terre afin d'assurer que le boîtier métallique de la SFP est correctement mis à la terre grâce au connecteur de face arrière.

REMARQUE

Ce produit est conforme à la directive européenne RoHS. Reportez-vous à www.adtran.com pour de plus amples renseignements sur RoHS.

DEUTSCH

⚠️ WARNUNG

Lesen Sie sich alle Warn- und Sicherheitshinweise durch, bevor Sie dieses Gerät installieren oder warten.

⚠️ CAUTION

Dieses Produkt nutzt ein mit den Richtlinien 21 CFR 1040.10 und 1040.11 und IEC 60825-1 und -2 konformes Class 1 Lasermodul. Damit die obigen Richtlinien auch in Zukunft eingehalten werden können, dürfen ausschließlich Class 1 Lasermodule von einem von ADTRAN zugelassenen Anbieter in dem Produkt installiert werden (erhältlich auf der Website von ADTRAN). ADTRAN garantiert nicht für die Systemintegrität bei anderen Lasermodulen.

⚠️ CAUTION

- Elektrostatische Entladungen können elektronische Module beschädigen. Tragen Sie beim Umgang mit Modulen ein Erdungsarmband, um Schäden an den elektronischen Komponenten zu vermeiden. Transportieren oder lagern Sie Module in antistatischem Verpackungsmaterial. Bei der Arbeit an den Modulen, achten Sie darauf, diese stets auf antistatische, elektrisch geerdete Matten zu legen.
- Die Erdungsschiene des Rahmens muss an eine Bodenstation angeschlossen werden, um sicherzustellen, dass das Metallgehäuse des SFP vorschriftsmäßig über den Rückwandanschluss geerdet ist.

HINWEIS

Dieses Produkt erfüllt die EU RoHS Richtlinie. Bitte besuchen Sie www.adtran.com für ausführlichere Informationen zu RoHS/WEEE.



Warranty: ADTRAN will replace or repair this product within the warranty period if it does not meet its published specifications or fails while in service. Warranty information can be found online at www.adtran.com/warranty.



ADTRAN CUSTOMER CARE:
From within the U.S. 1.800.726.8663
From outside the U.S. +1 256.963.8716
PRICING AND AVAILABILITY 1.800.827.0807

